

Description of Device Parameters

Proline Promag 100

HART

Electromagnetic flowmeter




Table of contents

1	Document information	4		
1.1	Document function	4		
1.2	Target group	4		
1.3	Using this document	4		
1.3.1	Information on the document structure	4		
1.3.2	Structure of a parameter description	6		
1.4	Symbols used	6		
1.4.1	Symbols for certain types of information	6		
1.4.2	Symbols in graphics	7		
2	Overview of the Expert operating menu	8		
3	Description of device parameters	10		
3.1	"System" submenu	13		
3.1.1	"Display" submenu	13		
3.1.2	"Administration" submenu	26		
3.1.3	"Diagnostic handling" submenu	29		
3.2	"Sensor" submenu	35		
3.2.1	"Measured values" submenu	35		
3.2.2	"System units" submenu	42		
3.2.3	"Process parameters" submenu	53		
3.2.4	"External compensation" submenu	65		
3.2.5	"Sensor adjustment" submenu	67		
3.2.6	"Calibration" submenu	72		
3.3	"Output" submenu	74		
3.3.1	"Current output 1" submenu	74		
3.3.2	"Pulse/frequency/switch output" submenu	86		
3.4	"Communication" submenu	106		
3.4.1	"HART input" submenu	106		
3.4.2	"HART output" submenu	112		
3.4.3	"Web server" submenu	127		
3.4.4	"Diagnostic configuration" submenu	130		
3.5	"Application" submenu	135		
3.5.1	"Totalizer 1 to 3" submenu	135		
3.6	"Diagnostics" submenu	140		
3.6.1	"Diagnostic list" submenu	143		
3.6.2	"Event logbook" submenu	146		
3.6.3	"Device information" submenu	149		
3.6.4	"Min/max values" submenu	152		
3.6.5	"Heartbeat" submenu	154		
3.6.6	"Simulation" submenu	155		
4	Country-specific factory settings	162		
4.1	SI units	162		
4.1.1	System units	162		
4.1.2	Full scale values	162		
4.1.3	Output current span	163		
4.1.4	Pulse value	163		
4.1.5	On value low flow cut off	163		
4.2	US units	164		
4.2.1	System units	164		
4.2.2	Full scale values	164		
4.2.3	Output current span	165		
4.2.4	Pulse value	165		
4.2.5	On value low flow cut off	166		
5	Explanation of abbreviated units	167		
5.1	SI units	167		
5.2	US units	167		
5.3	Imperial units	168		
	Index	170		

1 Document information

1.1 Document function


The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the Expert operating menu.


1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document



1.3.1 Information on the document structure


This document lists the submenus and their parameters according to the structure of the **Expert** menu (→  8) menu that are available once the **"Operator" user role** or the **"Maintenance" user role** is enabled.



A0022576-EN


 1 Sample graphic

 For information on the arrangement of the parameters according to the structure of the **Operation** menu, **Setup** menu, **Diagnostics** menu (→  140), along with a brief description, see the Operating Instructions for the device.






A0022577-EN

2 Sample graphic

 For information about the operating philosophy, see the "Operating philosophy" chapter in the device's Operating Instructions








1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

Complete parameter name	Write-protected parameter = 
Navigation	 Navigation path to the parameter via the local display (direct access code) or Web browser  Navigation path to the parameter via the operating tool The names of the menus, submenus and parameters are abbreviated to the form in which they appear on the display and in the operating tool.
Prerequisite	The parameter is only available under these specific conditions
Description	Description of the parameter function
Selection	List of the individual options for the parameter <ul style="list-style-type: none"> ▪ Option 1 ▪ Option 2
User entry	Input range for the parameter
User interface	Display value/data for the parameter
Factory setting	Default setting ex works
Additional information	Additional explanations (e.g. in examples): <ul style="list-style-type: none"> ▪ On individual options ▪ On display values/data ▪ On the input range ▪ On the factory setting ▪ On the parameter function

1.4 Symbols used

1.4.1 Symbols for certain types of information

Symbol	Meaning
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Operation via local display
	Operation via operating tool
	Write-protected parameter

1.4.2 Symbols in graphics

Symbol	Meaning	Symbol	Meaning
1, 2, 3 ...	Item numbers	A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections		

2 Overview of the Expert operating menu













The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.

Expert		
Direct access		→ 10
Locking status		→ 11
Access status display		→ 11
Access status tooling		→ 12
Enter access code		→ 13
▶ System		→ 13
▶ Display		→ 13
▶ Administration		→ 26
▶ Diagnostic handling		→ 29
▶ Sensor		→ 35
▶ Measured values		→ 35
▶ System units		→ 42
▶ Process parameters		→ 53
▶ External compensation		→ 65
▶ Sensor adjustment		→ 67
▶ Calibration		→ 72
▶ Output		→ 74
▶ Current output 1		→ 74
▶ Pulse/frequency/switch output 1		→ 86
▶ Communication		→ 106
▶ HART input		→ 106

▶ HART output	→ 112
▶ Web server	→ 127
▶ Diagnostic configuration	→ 130
▶ Application	→ 135
Reset all totalizers	→ 135
▶ Totalizer 1 to 3	→ 135
▶ Diagnostics	→ 140
Actual diagnostics	→ 140
Previous diagnostics	→ 141
Operating time from restart	→ 142
Operating time	→ 142
▶ Diagnostic list	→ 143
▶ Event logbook	→ 146
▶ Device information	→ 149
▶ Min/max values	→ 152
▶ Heartbeat	→ 154
▶ Simulation	→ 155


3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the local display. Specific parameters for the operating tools are included at the appropriate points in the menu structure.

 Expert		
Direct access		→  10
Locking status		→  11
Access status display		→  11
Access status tooling		→  12
Enter access code		→  13
▶ System		→  13
▶ Sensor		→  35
▶ Output		→  74
▶ Communication		→  106
▶ Application		→  135
▶ Diagnostics		→  140

Direct access

Navigation

 Expert → Direct access

Prerequisite

There is a local display with operating elements.

Description


Input of the access code to enable direct access to the desired parameter via the local display. For this reason, each parameter is assigned a parameter number that appears in the navigation view on the right in the header of the selected parameter.

User entry


0 to 65 535

Additional information*User entry*

The direct access code consists of a 4-digit number and the channel number, which identifies the channel of a process variable: e.g. 0914-1

-  The leading zeros in the direct access code do not have to be entered.
Example: Input of "914" instead of "0914"
- If no channel number is entered, channel 1 is jumped to automatically.
Example: Enter 0914 → **Assign process variable** parameter
- If a different channel is jumped to: Enter the direct access code with the corresponding channel number.
Example: Enter 0914-3 → **Assign process variable** parameter

Locking status

Navigation Expert → Locking status**Description**



Displays the active write protection.

User interface

- Hardware locked
- Temporarily locked


Additional information*Display*

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.

-  If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the **Locking status** parameter (→  11).

"Hardware locked" option (priority 1)


The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters (e.g. via local display or operating tool).

-  Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

"Temporarily locked" option (priority 2)

Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc.). Once the internal processing has been completed, the parameters can be changed once again.








Access status display

Navigation Expert → Access stat.disp**Prerequisite**








A local display is provided.

Description

Displays the access authorization to the parameters via the local display.

User interface	<ul style="list-style-type: none"> ▪ Operator ▪ Maintenance
Factory setting	Operator
Additional information	<p><i>Description</i></p> <p>If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.</p> <p> Access authorization can be modified via the Enter access code parameter (→  13).</p> <p> For information on the Enter access code parameter, see the "Disabling write protection via access code" section of the Operating Instructions for the device</p> <p> If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the Locking status parameter (→  11).</p> <p><i>Display</i></p> <p> Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.</p>

Access status tooling

Navigation	  Expert → Access stat.tool
Description	Displays the access authorization to the parameters via the operating tool.
User interface	<ul style="list-style-type: none"> ▪ Operator ▪ Maintenance
Factory setting	Maintenance
Additional information	<p><i>Description</i></p> <p> Access authorization can be modified via the Enter access code parameter (→  13).</p> <p> If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the Locking status parameter (→  11).</p> <p><i>Display</i></p> <p> Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.</p>

Enter access code

Navigation	Expert → Ent. access code
Description	Use this function to enter the user-specific release code to remove parameter write protection.
User entry	0 to 9999

3.1 "System" submenu














Navigation Expert → System

▶ System	
▶ Display	→ 13
▶ Administration	→ 26
▶ Diagnostic handling	→ 29

3.1.1 "Display" submenu



Navigation Expert → System → Display

▶ Display	
Display language	→ 14
Format display	→ 15
Value 1 display	→ 16
0% bargraph value 1	→ 17
100% bargraph value 1	→ 18
Decimal places 1	→ 18
Value 2 display	→ 18
Decimal places 2	→ 19
Value 3 display	→ 19

0% bargraph value 3	→  20
100% bargraph value 3	→  20
Decimal places 3	→  21
Value 4 display	→  21
Decimal places 4	→  22
Display interval	→  22
Display damping	→  23
Header	→  23
Header text	→  24
Separator	→  24
Contrast display	→  24
Backlight	→  25
Access status display	→  25

Display language

Navigation

  Expert → System → Display → Display language

Prerequisite

A local display is provided.

Description

Use this function to select the configured language on the local display.

Selection

- English
- Deutsch *
- Français *
- Español *
- Italiano *
- Nederlands *
- Portuguesa *
- Polski *
- русский язык (Russian) *
- Svenska *
- Türkçe *
- 中文 (Chinese) *
- 日本語 (Japanese) *

* Visibility depends on order options or device settings

- 한국어 (Korean) *
- العربية (Arabic) *
- Bahasa Indonesia *
- ภาษาไทย (Thai) *
- tiếng Việt (Vietnamese) *
- čeština (Czech) *

Factory setting English (alternatively, the ordered language is preset in the device)

Format display

Navigation  Expert → System → Display → Format display

Prerequisite A local display is provided.

Description Use this function to select how the measured value is shown on the local display.





Selection

- 1 value, max. size
- 1 bargraph + 1 value
- 2 values
- 1 value large + 2 values
- 4 values

Factory setting 1 value, max. size

Additional information *Description*

The display format (size, bar graph etc.) and number of measured values displayed simultaneously (1 to 4) can be configured. This setting only applies to normal operation.

-  ▪ The **Value 1 display** parameter (→  16) to **Value 4 display** parameter (→  21) are used to specify which measured values are shown on the local display and in what order.
- If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured via the **Display interval** parameter (→  22).


Possible measured values shown on the local display:

"1 value, max. size" option




A0016529

* Visibility depends on order options or device settings


"1 bargraph + 1 value" option

A0016530


"2 values" option

A0016531

3

"1 value large + 2 values" option

A0016532

"4 values" option

A0016533

Value 1 display**Navigation**

Expert → System → Display → Value 1 display

Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values to be shown on the local display.

Selection

- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity

- Conductivity *
- Corrected conductivity *
- Temperature *
- Electronic temperature
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Current output 1 *
- None

Factory setting

Volume flow

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation.



The **Format display** parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how.

Selection

The unit of the displayed measured value is taken from the **System units** submenu (→ 42).

0% bargraph value 1**Navigation**

Expert → System → Display → 0% bargraph 1

Prerequisite

A local display is provided.

Description

Use this function to enter the 0% bar graph value to be shown on the display for the measured value 1.

User entry

Signed floating-point number

Factory setting

Country-specific:

- 0 l/h
- 0 gal/min (us)








Additional information*Description*





The **Format display** parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph.



User entry






The unit of the displayed measured value is taken from the **System units** submenu (→ 42).

* Visibility depends on order options or device settings





100% bargraph value 1		
Navigation	 Expert → System → Display → 100% bargraph 1	
Prerequisite	A local display is provided.	
Description	Use this function to enter the 100% bar graph value to be shown on the display for the measured value 1.	
User entry	Signed floating-point number	
Factory setting	Depends on country and nominal diameter →  162	
Additional information	<p><i>Description</i></p> <p> The Format display parameter (→  15) is used to specify that the measured value is to be displayed as a bar graph.</p> <p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→  42).</p>	

Decimal places 1		
Navigation	 Expert → System → Display → Decimal places 1	
Prerequisite	A measured value is specified in the Value 1 display parameter (→  16).	
Description	Use this function to select the number of decimal places for measured value 1.	
Selection	<ul style="list-style-type: none"> ■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx 	
Factory setting	x.xx	
Additional information	<p><i>Description</i></p> <p> This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.</p>	




Value 2 display		
Navigation	 Expert → System → Display → Value 2 display	
Prerequisite	A local display is provided.	





Description	Use this function to select one of the measured values to be shown on the local display.
Selection	For the picklist, see the Value 1 display parameter (→  16)
Factory setting	None
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→  15) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Selection</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→  42).</p>

Decimal places 2








Navigation	  Expert → System → Display → Decimal places 2
Prerequisite	A measured value is specified in the Value 2 display parameter (→  18).
Description	Use this function to select the number of decimal places for measured value 2.
Selection	<ul style="list-style-type: none"> ■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx
Factory setting	x.xx
Additional information	<p><i>Description</i></p> <p> This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.</p>

Value 3 display




Navigation	  Expert → System → Display → Value 3 display
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values to be shown on the local display.
Selection	Picklist, see Value 1 display parameter (→  16)
Factory setting	None

Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→  15) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Selection</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→  42).</p>
-------------------------------	---



0% bargraph value 3

Navigation	  Expert → System → Display → 0% bargraph 3
Prerequisite	A selection has been made in the Value 3 display parameter (→  19).
Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 3.
User entry	Signed floating-point number
Factory setting	Country-specific: <ul style="list-style-type: none"> ▪ 0 l/h ▪ 0 gal/min (us)
Additional information	<p><i>Description</i></p> <p> The Format display parameter (→  15) is used to specify that the measured value is to be displayed as a bar graph.</p> <p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→  42).</p>



100% bargraph value 3

Navigation	  Expert → System → Display → 100% bargraph 3
Prerequisite	A selection was made in the Value 3 display parameter (→  19).
Description	Use this function to enter the 100% bar graph value to be shown on the display for the measured value 3.
User entry	Signed floating-point number
Factory setting	0



Additional information*Description*

 The **Format display** parameter (→  15) is used to specify that the measured value is to be displayed as a bar graph.

User entry

 The unit of the displayed measured value is taken from the **System units** submenu (→  42).

Decimal places 3**Navigation**

  Expert → System → Display → Decimal places 3

Prerequisite

A measured value is specified in the **Value 3 display** parameter (→  19).

Description

Use this function to select the number of decimal places for measured value 3.


Selection

- x
- x.x
- x.xx
- x.xxx
- x.xxxx



Factory setting

x.xx

Additional information*Description*

 This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 4 display**Navigation**

  Expert → System → Display → Value 4 display

Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values to be shown on the local display.

Selection



Picklist, see **Value 1 display** parameter (→  16)

Factory setting



None


Additional information*Description*





If several measured values are displayed at once, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.

 The **Format display** parameter (→  15) is used to specify how many measured values are displayed simultaneously and how.







Selection

 The unit of the displayed measured value is taken from the **System units** submenu (→  42).

Decimal places 4 

Navigation	  Expert → System → Display → Decimal places 4
Prerequisite	A measured value is specified in the Value 4 display parameter (→  21).
Description	Use this function to select the number of decimal places for measured value 4.
Selection	<ul style="list-style-type: none"> ▪ x ▪ x.x ▪ x.xx ▪ x.xxx ▪ x.xxxx
Factory setting	x.xx
Additional information	<p><i>Description</i></p> <p> This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.</p>

Display interval


Navigation	  Expert → System → Display → Display interval
Prerequisite	A local display is provided.
Description	Use this function to enter the length of time the measured values are displayed if the values alternate on the display.
User entry	1 to 10 s
Factory setting	5 s
Additional information	<p><i>Description</i></p> <p>This type of alternating display only occurs automatically if the number of measured values defined exceeds the number of values the selected display format can display simultaneously.</p> <p> <ul style="list-style-type: none"> ▪ The Value 1 display parameter (→  16) to Value 4 display parameter (→  21) are used to specify which measured values are shown on the local display. ▪ The display format of the displayed measured values is specified using the Format display parameter (→  15). </p>

Display damping


Navigation	Expert → System → Display → Display damping
Prerequisite	A local display is provided.
Description	Use this function to enter the reaction time of the local display to fluctuations in the measured value caused by process conditions.
User entry	0.0 to 999.9 s
Factory setting	0.0 s
Additional information	<p><i>User entry</i></p> <p>A time constant is entered:</p> <ul style="list-style-type: none"> ▪ If a low time constant is entered, the display reacts particularly quickly to fluctuating measured variables. ▪ On the other hand, the display reacts more slowly if a high time constant is entered.

Header


Navigation	Expert → System → Display → Header
Prerequisite	A local display is provided.
Description	Use this function to select the contents of the header of the local display.
Selection	<ul style="list-style-type: none"> ▪ Device tag ▪ Free text
Factory setting	Device tag
Additional information	<p><i>Description</i></p> <p>The header text only appears during normal operation.</p>



A0013375


1 Position of the header text on the display

Selection

- Device tag
Is defined in the **Device tag** parameter (→ 149).
- Free text
Is defined in the **Header text** parameter (→ 24).

Header text 🔒

Navigation  Expert → System → Display → Header text


Prerequisite The **Free text** option is selected in the **Header** parameter (→  23).

Description Use this function to enter a customer-specific text for the header of the local display.

User entry Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting -----

Additional information *Description*
The header text only appears during normal operation.



A0013375

1 Position of the header text on the display

User entry

The number of characters displayed depends on the characters used.

Separator 🔒

Navigation  Expert → System → Display → Separator

Prerequisite A local display is provided.

Description Use this function to select the decimal separator.

Selection





- . (point)
- , (comma)

Factory setting . (point)



Contrast display

Navigation  Expert → System → Display → Contrast display









Prerequisite A local display is provided.

Description	Use this function to enter a value to adapt the display contrast to the ambient conditions (e.g. the lighting or viewing angle).
User entry	20 to 80 %
Factory setting	Depends on the display
Additional information	<p><i>Set the contrast via the push-buttons:</i></p> <ul style="list-style-type: none"> ▪ Brighter: Press and hold down the   keys simultaneously. ▪ Darker: Press and hold down the   keys simultaneously.


Backlight

Navigation	  Expert → System → Display → Backlight
Prerequisite	Order code for "Display; operation", option E "SD03 4-line, illum.; touch control + data backup function"
Description	Use this function to switch the backlight of the local display on and off.
Selection	<ul style="list-style-type: none"> ▪ Disable ▪ Enable
Factory setting	Enable

Access status display





Navigation	  Expert → System → Display → Access stat.disp
Prerequisite	A local display is provided.
Description	Displays the access authorization to the parameters via the local display.
User interface	<ul style="list-style-type: none"> ▪ Operator ▪ Maintenance
Factory setting	Operator
Additional information	<p><i>Description</i></p> <p>If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.</p> <ul style="list-style-type: none">  Access authorization can be modified via the Enter access code parameter (→  13).  For information on the Enter access code parameter, see the "Disabling write protection via access code" section of the Operating Instructions for the device  If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the Locking status parameter (→  11).

Display



 Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

3.1.2 "Administration" submenu



Navigation  Expert → System → Administration

▶ Administration		
▶ Define access code		→  26
Device reset		→  28
Activate SW option		→  28
Software option overview		→  29


"Define access code" wizard

 The **Define access code** wizard is only available if operating using the local display. If you are operating using the operating tool, the **Define access code** parameter (→  27) is directly in the **Administration** submenu. The **Confirm access code** parameter is not available if you are operating using the operating tool.

Navigation  Expert → System → Administration → Def. access code

▶ Define access code		
Define access code		→  26
Confirm access code		→  27

Define access code**Navigation**

 Expert → System → Administration → Def. access code → Def. access code

Description

Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the local display.



User entry



0 to 9 999


Factory setting

0

Additional information*Description*

The write protection affects all parameters in the document marked with the  symbol. On the local display, the  symbol in front of a parameter indicates that the parameter is write-protected.

 Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter (→  13).

 If you lose the access code, please contact your Endress+Hauser Sales Center.


User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

Confirm access code**Navigation**

 Expert → System → Administration → Def. access code → Confirm code

Description

Enter the defined release code a second time to confirm the release code.

User entry

0 to 9999

Factory setting

0

Additional parameters in the "Administration" submenu**Define access code****Navigation**

 Expert → System → Administration → Def. access code

Description





Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the operating tool.

User entry




0 to 9999

Factory setting



0


Additional information	<p><i>Description</i></p> <p>The write protection affects all parameters in the document marked with the  symbol.</p> <p> Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the Enter access code parameter (→  13).</p> <p> If you lose the access code, please contact your Endress+Hauser Sales Center.</p> <p><i>User entry</i></p> <p>A message is displayed if the access code is not in the input range.</p> <p><i>Factory setting</i></p> <p>If the factory setting is not changed or 0 is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "Maintenance" role.</p>
-------------------------------	--

Device reset


Navigation	  Expert → System → Administration → Device reset
Description	Use this function to choose whether to reset the device configuration - either entirely or in part - to a defined state.
Selection	<ul style="list-style-type: none"> ■ Cancel ■ To delivery settings ■ Restart device
Factory setting	Cancel
Additional information	<p><i>"Cancel" option</i></p> <p>No action is executed and the user exits the parameter.</p> <p><i>"To delivery settings" option</i></p> <p>Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.</p> <p> This option is not visible if no customer-specific settings have been ordered.</p> <p><i>"Restart device" option</i></p> <p>The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.</p>

Activate SW option

Navigation	  Expert → System → Administration → Activate SW opt.
Description	Use this function to enter an activation code to enable an additional, ordered software option.



User entry	Max. 10-digit string consisting of numbers.
Factory setting	0
Additional information	<p><i>User entry</i></p> <p> Endress+Hauser provides the corresponding activation code for the software option with the order.</p> <p>NOTICE! This activation code varies depending on the measuring device and the software option. If an incorrect or invalid code is entered, this can result in the loss of software options that are already been activated. After commissioning the measuring device: in this parameter only enter activation codes which Endress+Hauser has provided (e.g. when a new software option was ordered). If an incorrect or invalid activation code is entered, enter the activation code from the parameter protocol again and contact your Endress+Hauser sales organization, quoting the serial number of your device.</p> <p><i>Example for a software option</i></p> <p>Order code for "Application package", option EB "Heartbeat Verification + Monitoring"</p>

Software option overview

Navigation	 Expert → System → Administration → SW option overv.
Description	Displays all the software options that are enabled in the device.
User interface	<ul style="list-style-type: none"> ■ Electrode cleaning circuit ■ Heartbeat Verification ■ Heartbeat Monitoring
Additional information	<p><i>Description</i></p> <p>Displays all the options that are available if ordered by the customer.</p> <p><i>"Electrode cleaning circuit" option</i></p> <p>Order code for "Application package", option EC "ECC electrode cleaning"</p> <p><i>"Heartbeat Verification" option and "Heartbeat Monitoring" option</i></p> <p>Order code for "Application package", option EB "Heartbeat Verification + Monitoring"</p>

3.1.3 "Diagnostic handling" submenu

Navigation  Expert → System → Diagn. handling

▶ Diagnostic handling	
Alarm delay	→  30
▶ Diagnostic behavior	→  30

Alarm delay**Navigation**

Expert → System → Diagn. handling → Alarm delay

Description

Use this function to enter the time interval until the device generates a diagnostic message.

The diagnostic message is reset without a time delay.

User entry

0 to 60 s

Factory setting

0 s

Additional information*Description*

This setting affects the following diagnostic messages:

- 190 Special event 1
- 832 Electronic temperature too high
- 833 Electronic temperature too low
- 834 Process temperature too high
- 835 Process temperature too low
- 862 Partly filled pipe
- 990 Special event 4

"Diagnostic behavior" submenu

For a list of all the diagnostic events, see the Operating Instructions for the device.


Modifying the diagnostic behavior of a diagnostic event. Each diagnostic event is assigned a certain diagnostic behavior at the factory. The user can change this assignment for certain diagnostics events.









The following options are available in the **Assign behavior of diagnostic no. xxx** parameters:

- **Off** option
The diagnostic event is ignored; it is neither entered into the Event logbook, nor is a diagnostic message generated.
- **Alarm** option
The device continues to measure. The signal outputs assume the defined alarm condition. A diagnostic message is generated.
- **Warning** option
The device continues to measure. A diagnostic message is generated.
- **Logbook entry only** option
The device continues to measure. The diagnostic message is entered in the **Event logbook** submenu (→ 146) (**Event list** submenu (→ 148)) only and is not displayed in alternation with the measured value display.

Navigation





Expert → System → Diagn. handling → Diagn. behavior



Assign behavior of diagnostic no. 442	→  31
Assign behavior of diagnostic no. 443	→  32
Assign behavior of diagnostic no. 531	→  32
Assign behavior of diagnostic no. 832	→  33
Assign behavior of diagnostic no. 833	→  33
Assign behavior of diagnostic no. 834	→  33
Assign behavior of diagnostic no. 835	→  34
Assign behavior of diagnostic no. 862	→  34
Assign behavior of diagnostic no. 937	→  34
Assign behavior of diagnostic no. 302	→  35



Assign behavior of diagnostic no. 441 (Current output 1)





Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 441
Description	Use this function to change the diagnostic behavior of the diagnostic message 441 Current output 1 .
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Alarm ▪ Warning ▪ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available for selection: →  30





Assign behavior of diagnostic no. 442 (Frequency output)







Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 442
Prerequisite	The measuring device has a pulse/frequency/switch output.
Description	Use this function to change the diagnostic behavior of the diagnostic message 442 Frequency output .

Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available for selection: →  30

Assign behavior of diagnostic no. 443 (Pulse output)

Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 443
Prerequisite	The measuring device has a pulse/frequency/switch output.
Description	Use this function to change the diagnostic behavior of the diagnostic message 443 Pulse output .
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available for selection: →  30

Assign behavior of diagnostic no. 531 (Empty pipe detection)

Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 531
Description	Use this function to change the diagnostic behavior of the diagnostic message 531 Empty pipe detection .
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available, see →  30

Assign behavior of diagnostic no. 832 (Electronic temperature too high)


Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 832
Description	Use this function to change the diagnostic behavior of the diagnostic message 832 Electronic temperature too high .
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Alarm ▪ Warning ▪ Logbook entry only
Factory setting	Warning
Additional information	For a detailed description of the options available, see → 30

Assign behavior of diagnostic no. 833 (Electronic temperature too low)


Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 833
Description	Use this function to change the diagnostic behavior of the diagnostic message 833 Electronic temperature too low .
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Alarm ▪ Warning ▪ Logbook entry only
Factory setting	Warning
Additional information	For a detailed description of the options available, see → 30

Assign behavior of diagnostic no. 834 (Process temperature too high)


Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 834
Description	Use this function to change the diagnostic behavior of the diagnostic message 834 Process temperature too high .
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Alarm ▪ Warning ▪ Logbook entry only
Factory setting	Warning
Additional information	For a detailed description of the options available, see → 30

Assign behavior of diagnostic no. 835 (Process temperature too low)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 835
Description	Use this function to change the diagnostic behavior of the diagnostic message 835 Process temperature too low .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	For a detailed description of the options available, see → 30

Assign behavior of diagnostic no. 862 (Empty pipe)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 862
Description	Use this function to change the diagnostic behavior of the diagnostic message 862 Empty pipe .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	For a detailed description of the options available, see → 30

Assign behavior of diagnostic no. 937 (EMC interference)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 937
Description	Use this function to change the diagnostic behavior of the diagnostic message 937 EMC interference .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	For a detailed description of the options available for selection: → 30

Assign behavior of diagnostic no. 302 (Device verification active)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 302
Description	Use this function to change the diagnostic behavior of the diagnostic message 302 Device verification active .
Selection	<ul style="list-style-type: none"> ▪ Alarm ▪ Warning
Factory setting	Warning
Additional information	For a detailed description of the options available, see → 30

3.2 "Sensor" submenu

Navigation Expert → Sensor

▶ Sensor	
▶ Measured values	→ 35
▶ System units	→ 42
▶ Process parameters	→ 53
▶ External compensation	→ 65
▶ Sensor adjustment	→ 67
▶ Calibration	→ 72







3.2.1 "Measured values" submenu

Navigation Expert → Sensor → Measured val.




▶ Measured values	
▶ Process variables	→ 36
▶ Totalizer	→ 38
▶ Output values	→ 40

"Process variables" submenu




Navigation  Expert → Sensor → Measured val. → Process variab.

▶ Process variables	
Volume flow	→  36
Mass flow	→  36
Conductivity	→  37
Corrected volume flow	→  37
Temperature	→  37
Corrected conductivity	→  38





Volume flow

Navigation	 Expert → Sensor → Measured val. → Process variab. → Volume flow
Description	Displays the volume flow currently measured.
User interface	Signed floating-point number
Additional information	<p><i>Dependency</i></p> <p> The unit is taken from the Volume flow unit parameter (→  43)</p>




Mass flow

Navigation	 Expert → Sensor → Measured val. → Process variab. → Mass flow
Description	Displays the mass flow currently calculated.
User interface	Signed floating-point number
Additional information	<p><i>Dependency</i></p> <p> The unit is taken from the Mass flow unit parameter (→  46)</p>




Conductivity

Navigation	 Expert → Sensor → Measured val. → Process variab. → Conductivity
Prerequisite	In the Conductivity measurement parameter (→  57), the On option is selected.
Description	Displays the conductivity currently measured.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Conductivity unit parameter (→  44)




Corrected volume flow

Navigation	 Expert → Sensor → Measured val. → Process variab. → Correct.vol.flow
Description	Displays the corrected volume flow currently measured.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Corrected volume flow unit parameter (→  48)


Temperature



Navigation	 Expert → Sensor → Measured val. → Process variab. → Temperature
Prerequisite	For the following order code: "Sensor Option", option CI "Fluid temperature probe"
Description	Displays the temperature currently calculated.
User interface	Positive floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  45)

Corrected conductivity

Navigation	 Expert → Sensor → Measured val. → Process variab. → CorrConductivity
Prerequisite	One of the following conditions is satisfied: <ul style="list-style-type: none"> ▪ Order code for "Sensor Option", option CI "Fluid temperature probe" or ▪ The temperature is read into the flowmeter from an external device.
Description	Displays the conductivity currently corrected.
User interface	Positive floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Conductivity unit parameter (→  44)



"Totalizer" submenu






Navigation  Expert → Sensor → Measured val. → Totalizer

▶ Totalizer	
Totalizer value 1 to 3	→  38
Totalizer overflow 1 to 3	→  39






Totalizer value 1 to 3



Navigation	 Expert → Sensor → Measured val. → Totalizer → Totalizer val. 1 to 3
Prerequisite	One of the following options is selected in the Assign process variable parameter (→  136) of the Totalizer 1 to 3 submenu: <ul style="list-style-type: none"> ▪ Volume flow ▪ Mass flow ▪ Corrected volume flow
Description	Displays the current totalizer reading.
User interface	Signed floating-point number

Additional information	<p><i>Description</i></p> <p>As it is only possible to display a maximum of 7 digits, the current counter value is the sum of the totalizer value and the overflow value from the Totalizer overflow 1 to 3 parameter if the display range is exceeded.</p> <p> In the event of an error, the totalizer adopts the mode defined in the Failure mode parameter (→  139).</p> <p><i>Display</i></p> <p>The value of the process variable totalized since measuring began can be positive or negative. This depends on the settings in the Totalizer operation mode parameter (→  137).</p> <p> The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→  136).</p> <p><i>Example</i></p> <p>Calculation of the current totalizer reading when the value exceeds the 7-digit display range:</p> <ul style="list-style-type: none"> ▪ Value in the Totalizer value 1 parameter: 196 845.7 m³ ▪ Value in the Totalizer overflow 1 parameter: $1 \cdot 10^6$ (1 overflow) = 1 000 000 [m³] ▪ Current totalizer reading: 1 196 845.7 m³
-------------------------------	---

Totalizer overflow 1 to 3


Navigation	  Expert → Sensor → Measured val. → Totalizer → Tot. overflow 1 to 3
Prerequisite	<p>One of the following options is selected in the Assign process variable parameter (→  136) of the Totalizer 1 to 3 submenu:</p> <ul style="list-style-type: none"> ▪ Volume flow ▪ Mass flow ▪ Corrected volume flow
Description	Displays the current totalizer overflow.
User interface	Integer with sign
Additional information	<p><i>Description</i></p> <p>If the current reading has more than 7 digits, which is the maximum value range that can be displayed, the value above this range is given as an overflow. The current totalizer value is therefore the sum of the overflow value and the totalizer value from the Totalizer value 1 to 3 parameter</p> <p><i>Display</i></p> <p> The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→  136).</p>






Example

Calculation of the current totalizer reading when the value exceeds the 7-digit display range:

- Value in the **Totalizer value 1** parameter: 196 845.7 m³
- Value in the **Totalizer overflow 1** parameter: $2 \cdot 10^6$ (2 overflows) = 2 000 000 [m³]
- Current totalizer reading: 2 196 845.7 m³

"Output values" submenu

Navigation   Expert → Sensor → Measured val. → Output values

▶ Output values	
Output current 1	→  40
Measured current 1	→  40
Pulse output 1	→  41
Output frequency 1	→  41
Switch status 1	→  42



Output current 1

Navigation   Expert → Sensor → Measured val. → Output values → Output curr. 1

Description Displays the current value currently calculated for the current output.

User interface 0 to 22.5 mA

Measured current 1


Navigation   Expert → Sensor → Measured val. → Output values → Measur. curr. 1

Description Use this function to display the actual measured value of the output current.

User interface 0 to 30 mA

Pulse output 1

Navigation	🔍📄 Expert → Sensor → Measured val. → Output values → Pulse output 1
Prerequisite	In the Operating mode parameter (→ 📄 88), the Pulse option is selected.
Description	Displays the pulse frequency currently output.
User interface	Positive floating-point number
Additional information	<p><i>Description</i></p> <ul style="list-style-type: none"> ▪ The pulse output is an open collector output. ▪ This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented. ▪ The Value per pulse parameter (→ 📄 90) and Pulse width parameter (→ 📄 90) can be used to define the value (i.e. the measured value amount that corresponds to a pulse) and the duration of the pulse.



A0025816-EN

0 Non-conductive
 1 Conductive
 NC NC contact (normally closed)
 NO NO contact (normally open)




The output behavior can be reversed via the **Invert output signal** parameter (→ 📄 105) i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (→ 📄 92)) can be configured.

Output frequency 1












Navigation	🔍📄 Expert → Sensor → Measured val. → Output values → Output freq. 1
Prerequisite	In the Operating mode parameter (→ 📄 88), the Frequency option is selected.
Description	Displays the actual value of the output frequency which is currently measured.
User interface	0.0 to 12 500.0 Hz

Switch status 1

Navigation	  Expert → Sensor → Measured val. → Output values → Switch status 1
Prerequisite	The Switch option is selected in the Operating mode parameter (→  88).
Description	Displays the current switch status of the status output.
User interface	<ul style="list-style-type: none"> ▪ Open ▪ Closed
Additional information	<p><i>User interface</i></p> <ul style="list-style-type: none"> ▪ Open The switch output is not conductive. ▪ Closed The switch output is conductive.

3.2.2 "System units" submenu

Navigation   Expert → Sensor → System units

▶ System units	
Volume flow unit	→  43
Volume unit	→  44
Conductivity unit	→  44
Temperature unit	→  45
Mass flow unit	→  46
Mass unit	→  46
Density unit	→  47
Corrected volume flow unit	→  48
Corrected volume unit	→  49
Date/time format	→  49
▶ User-specific units	→  50

**Volume flow unit****Navigation**

Expert → Sensor → System units → Volume flow unit

Description

Use this function to select the unit for the volume flow.

Selection*SI units*

- cm³/s
- cm³/min
- cm³/h
- cm³/d
- dm³/s
- dm³/min
- dm³/h
- dm³/d
- m³/s
- m³/min
- m³/h
- m³/d
- ml/s
- ml/min
- ml/h
- ml/d
- l/s
- l/min
- l/h
- l/d
- hl/s
- hl/min
- hl/h
- hl/d
- Ml/s
- Ml/min
- Ml/h
- Ml/d

US units

- af/s
- af/min
- af/h
- af/d
- ft³/s
- ft³/min
- ft³/h
- ft³/d
- fl oz/s (us)
- fl oz/min (us)
- fl oz/h (us)
- fl oz/d (us)
- gal/s (us)
- gal/min (us)
- gal/h (us)
- gal/d (us)
- kgal/s (us)
- kgal/min (us)
- kgal/h (us)
- kgal/d (us)
- Mgal/s (us)
- Mgal/min (us)
- Mgal/h (us)
- Mgal/d (us)
- bbl/s (us;liq.)
- bbl/min (us;liq.)
- bbl/h (us;liq.)
- bbl/d (us;liq.)
- bbl/s (us;beer)
- bbl/min (us;beer)
- bbl/h (us;beer)
- bbl/d (us;beer)
- bbl/s (us;oil)
- bbl/min (us;oil)
- bbl/h (us;oil)
- bbl/d (us;oil)
- bbl/s (us;tank)
- bbl/min (us;tank)
- bbl/h (us;tank)
- bbl/d (us;tank)

Imperial units

- gal/s (imp)
- gal/min (imp)
- gal/h (imp)
- gal/d (imp)
- Mgal/s (imp)
- Mgal/min (imp)
- Mgal/h (imp)
- Mgal/d (imp)
- bbl/s (imp;beer)
- bbl/min (imp;beer)
- bbl/h (imp;beer)
- bbl/d (imp;beer)
- bbl/s (imp;oil)
- bbl/min (imp;oil)
- bbl/h (imp;oil)
- bbl/d (imp;oil)






Custom-specific units

- User vol./s
- User vol./min
- User vol./h
- User vol./d

Factory setting

Country-specific:

- l/h
- gal/min (us)

Additional information	<p><i>Result</i></p> <p>The selected unit applies for: Volume flow parameter (→  36)</p> <p><i>Selection</i></p> <p> For an explanation of the abbreviated units: →  167</p> <p><i>Customer-specific units</i></p> <p> The unit for the customer-specific volume is specified in the User volume text parameter (→  50).</p>
-------------------------------	--

Volume unit

Navigation   Expert → Sensor → System units → Volume unit

Description Use this function to select the unit for the volume.



Selection	<p><i>SI units</i></p> <ul style="list-style-type: none"> ▪ cm³ ▪ dm³ ▪ m³ ▪ ml ▪ l ▪ hl ▪ Ml Mega 	<p><i>US units</i></p> <ul style="list-style-type: none"> ▪ af ▪ ft³ ▪ fl oz (us) ▪ gal (us) ▪ kgal (us) ▪ Mgal (us) ▪ bbl (us;oil) ▪ bbl (us;liq.) ▪ bbl (us;beer) ▪ bbl (us;tank) 	<p><i>Imperial units</i></p> <ul style="list-style-type: none"> ▪ gal (imp) ▪ Mgal (imp) ▪ bbl (imp;beer) ▪ bbl (imp;oil)
------------------	--	--	---

Custom-specific units
User vol.



Factory setting Country-specific:

- m³
- gal (us)



Additional information *Selection*

 For an explanation of the abbreviated units: →  167

Customer-specific units

 The unit for the customer-specific volume is specified in the **User volume text** parameter (→  50).

Conductivity unit

Navigation   Expert → Sensor → System units → Conductiv. unit

Prerequisite In the **Conductivity measurement** parameter (→  57), the **On** option is selected.

Description Use this function to select the unit for the conductivity.

Selection



SI units

- nS/cm
- μ S/cm
- μ S/m
- μ S/mm
- mS/m
- mS/cm
- S/cm
- S/m
- kS/m
- MS/m


Factory setting μ S/cm

Additional information *Result*



The selected unit applies for:

- **Conductivity** parameter (→  37)
- **Corrected conductivity** parameter (→  38)

Selection

 For an explanation of the abbreviated units: →  167

Temperature unit

Navigation   Expert → Sensor → System units → Temperature unit

Description Use this function to select the unit for the temperature.

Selection







<i>SI units</i>	<i>US units</i>
■ °C	■ °F
■ K	■ °R

Factory setting Country-specific:



- °C
- °F

Additional information *Result*

The selected unit applies for:

- **Temperature** parameter (→  37)
- **Maximum value** parameter (→  153)
- **Minimum value** parameter (→  153)
- **External temperature** parameter (→  66)
- **Maximum value** parameter (→  154)
- **Minimum value** parameter (→  154)

Selection

 For an explanation of the abbreviated units: →  167

Mass flow unit


Navigation Expert → Sensor → System units → Mass flow unit

Description Use this function to select the unit for the mass flow.

Selection

<p><i>SI units</i></p> <ul style="list-style-type: none"> ▪ g/s ▪ g/min ▪ g/h ▪ g/d ▪ kg/s ▪ kg/min ▪ kg/h ▪ kg/d ▪ t/s ▪ t/min ▪ t/h ▪ t/d 	<p><i>US units</i></p> <ul style="list-style-type: none"> ▪ oz/s ▪ oz/min ▪ oz/h ▪ oz/d ▪ lb/s ▪ lb/min ▪ lb/h ▪ lb/d ▪ STon/s ▪ STon/min ▪ STon/h ▪ STon/d
<p><i>Custom-specific units</i></p> <ul style="list-style-type: none"> ▪ User mass/s ▪ User mass/min ▪ User mass/h ▪ User mass/d 	

Factory setting Country-specific:

- kg/h
- lb/min

Additional information *Result*

The selected unit applies for:
Mass flow parameter (→ 36)

Selection

For an explanation of the abbreviated units: → 167





Customer-specific units

The unit for the customer-specific mass is specified in the **User mass text** parameter (→ 51).





Mass unit


Navigation Expert → Sensor → System units → Mass unit

Description Use this function to select the unit for the mass.

Selection	<i>SI units</i> <ul style="list-style-type: none"> ▪ g ▪ kg ▪ t <i>Custom-specific units</i> User mass	<i>US units</i> <ul style="list-style-type: none"> ▪ oz ▪ lb ▪ STon
Factory setting	Country-specific: <ul style="list-style-type: none"> ▪ kg ▪ lb 	
Additional information	<i>Selection</i>  For an explanation of the abbreviated units: →  167 <i>Customer-specific units</i>  The unit for the customer-specific mass is specified in the User mass text parameter (→  51).	

Density unit


Navigation	  Expert → Sensor → System units → Density unit		
Description	Use this function to select the unit for the density.		
Selection	<i>SI units</i> <ul style="list-style-type: none"> ▪ g/cm³ ▪ g/m³ ▪ kg/dm³ ▪ kg/l ▪ kg/m³ ▪ SD4°C ▪ SD15°C ▪ SD20°C ▪ SG4°C ▪ SG15°C ▪ SG20°C 	<i>US units</i> <ul style="list-style-type: none"> ▪ lb/ft³ ▪ lb/gal (us) ▪ lb/bbl (us;liq.) ▪ lb/bbl (us;beer) ▪ lb/bbl (us;oil) ▪ lb/bbl (us;tank) 	<i>Imperial units</i> <ul style="list-style-type: none"> ▪ lb/gal (imp) ▪ lb/bbl (imp;beer) ▪ lb/bbl (imp;oil)
Factory setting	Country-specific: <ul style="list-style-type: none"> ▪ kg/l ▪ lb/ft³ 		
Additional information	<i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> ▪ External density parameter (→  66) ▪ Fixed density parameter (→  66) 		

Selection

- SD = specific density
The specific density is the ratio of the density of the fluid to the density of water at a water temperature of +4 °C (+39 °F), +15 °C (+59 °F), +20 °C (+68 °F).
- SG = specific gravity
The specific gravity is the ratio of the density of the fluid to the density of water at a water temperature of +4 °C (+39 °F), +15 °C (+59 °F), +20 °C (+68 °F).



For an explanation of the abbreviated units: → 167

Corrected volume flow unit**Navigation**

Expert → Sensor → System units → Cor.volflow unit

Description

Use this function to select the unit for the corrected volume flow.

Selection*SI units*

- NI/s
- NI/min
- NI/h
- NI/d
- Nm³/s
- Nm³/min
- Nm³/h
- Nm³/d
- Sm³/s
- Sm³/min
- Sm³/h
- Sm³/d

US units

- Sft³/s
- Sft³/min
- Sft³/h
- Sft³/d
- Sgal/s (us)
- Sgal/min (us)
- Sgal/h (us)
- Sgal/d (us)
- Sbbbl/s (us;liq.)
- Sbbbl/min (us;liq.)
- Sbbbl/h (us;liq.)
- Sbbbl/d (us;liq.)
- Sgal/s (imp)
- Sgal/min (imp)
- Sgal/h (imp)
- Sgal/d (imp)

Custom-specific units

- UserCrVol./s
- UserCrVol./min
- UserCrVol./h
- UserCrVol./d

Factory setting

Country-specific:

- NI/h
- Sft³/h

Additional information*Result*


The selected unit applies for:

Corrected volume flow parameter (→ 37)

Selection

For an explanation of the abbreviated units: → 167

Customer-specific units

 The unit for the customer-specific corrected volume is defined in the **User corrected volume text** parameter (→  52).

Corrected volume unit**Navigation**

 Expert → Sensor → System units → Corr. vol. unit

Description

Use this function to select the unit for the corrected volume.

Selection*SI units*

- NI
- Nm³
- Sm³

US units

- Sft³
- Sgal (us)
- Sbbl (us;liq.)

Imperial units

Sgal (imp)

Custom-specific units


UserCrVol.

Factory setting

Country-specific:

- Nm³
- Sft³

Additional information*Selection*

 For an explanation of the abbreviated units: →  167

Customer-specific units

 The unit for the customer-specific corrected volume is defined in the **User corrected volume text** parameter (→  52).

Date/time format**Navigation**

 Expert → Sensor → System units → Date/time format

Description

Use this function to select the desired time format for calibration history.



Selection

- dd.mm.yy hh:mm
- dd.mm.yy hh:mm am/pm
- mm/dd/yy hh:mm
- mm/dd/yy hh:mm am/pm

Factory setting










dd.mm.yy hh:mm

Additional information*Selection*


 For an explanation of the abbreviated units: →  167

"User-specific units" submenu

Navigation  Expert → Sensor → System units → User-spec. units

▶ User-specific units	
User volume text	→  50
User volume offset	→  51
User volume factor	→  51
User mass text	→  51
User mass offset	→  52
User mass factor	→  52
User corrected volume text	→  52
User corrected volume offset	→  53
User corrected volume factor	→  53

User volume text**Navigation**

 Expert → Sensor → System units → User-spec. units → Volume text

Description

Use this function to enter a text for the user-specific unit of volume and volume flow. The corresponding time units (s, min, h, d) for volume flow are generated automatically.

User entry

Max. 10 characters such as letters, numbers or special characters (@, %, /)

Factory setting

User vol.

Additional information


Result
















The defined unit is shown as an option in the choose list of the following parameters:

- **Volume flow unit** parameter (→  43)
- **Volume unit** parameter (→  44)


Example

If the text GLAS is entered, the choose list of the **Volume flow unit** parameter (→  43) shows the following options:


- GLAS/s
- GLAS/min
- GLAS/h
- GLAS/d



User volume offset 	
Navigation	  Expert → Sensor → System units → User-spec. units → Volume offset
Description	Use this function to enter the offset for adapting the user-specific volume unit and volume flow unit (without time).
User entry	Signed floating-point number
Factory setting	0
Additional information	<p><i>Description</i></p> <p> Value in user-specific unit = (factor × value in base unit) + offset</p>
User volume factor 	
Navigation	  Expert → Sensor → System units → User-spec. units → Volume factor
Description	Use this function to enter a quantity factor (without time) for the user-specific volume and volume flow unit.
User entry	Signed floating-point number
Factory setting	1.0
User mass text 	
Navigation	  Expert → Sensor → System units → User-spec. units → Mass text
Description	Use this function to enter a text for the user-specific unit of mass and mass flow. The corresponding time units (s, min, h, d) for mass flow are generated automatically.
User entry	Max. 10 characters such as letters, numbers or special characters (@, %, /)
Factory setting	User mass
Additional information	<p><i>Result</i></p> <p> The defined unit is shown as an option in the choose list of the following parameters:</p> <ul style="list-style-type: none"> ▪ Mass flow unit parameter (→  46) ▪ Mass unit parameter (→  46)

Example

If the text GLAS is entered, the following options are displayed in the picklist for the **Mass flow unit** parameter (→  46):

- GLAS/s
- GLAS/min
- GLAS/h
- GLAS/d

User mass offset **Navigation**

  Expert → Sensor → System units → User-spec. units → Mass offset

Description

Use this function to enter the offset for adapting the user-specific mass unit and mass flow unit (without time).

User entry


Signed floating-point number


Factory setting



0

Additional information

Description

 Value in user-specific unit = (factor × value in base unit) + offset

User mass factor **Navigation**

  Expert → Sensor → System units → User-spec. units → Mass factor

Description

Use this function to enter a quantity factor (without time) for the user-specific mass and mass flow unit.

User entry

Signed floating-point number

Factory setting

1.0

User corrected volume text **Navigation**

  Expert → Sensor → System units → User-spec. units → Corr. vol. text

Description

Use this function to enter a text for the user-specific unit of the corrected volume and corrected volume flow. The corresponding time units (s, min, h, d) for mass flow are generated automatically.


User entry



Max. 10 characters such as letters, numbers or special characters (@, %, /)

Factory setting


UserCrVol.

Additional information *Result*


 The defined unit is shown as an option in the choose list of the following parameters:



- **Corrected volume flow unit** parameter (→  48)
- **Corrected volume unit** parameter (→  49)

Example


If the text GLAS is entered, the choose list of the **Corrected volume flow unit** parameter (→  48) shows the following options:

- GLAS/s
- GLAS/min
- GLAS/h
- GLAS/d

User corrected volume offset 


Navigation   Expert → Sensor → System units → User-spec. units → Corr vol. offset



Description Use this function to enter the offset for adapting the user-specific corrected volume unit and corrected volume flow unit (without time).

 Value in user-specific unit = (factor × value in base unit) + offset

User entry Signed floating-point number

Factory setting 0

User corrected volume factor 

Navigation   Expert → Sensor → System units → User-spec. units → Cor.vol. factor


Description Use this function to enter a quantity factor (without time) for the user-specific corrected volume unit and corrected volume flow unit.









User entry Signed floating-point number

Factory setting 1.0

3.2.3 "Process parameters" submenu


Navigation   Expert → Sensor → Process param.



Flow damping	→  55
Flow override	→  56
Conductivity damping	→  56
Temperature damping	→  57
Conductivity measurement	→  57
▶ Low flow cut off	→  57
▶ Empty pipe detection	→  61
▶ Electrode cleaning circuit	→  63

Filter options

Navigation

  Expert → Sensor → Process param. → Filter options

Description

Use this function to select a filter option.

Selection

- Standard CIP off
- Standard CIP on
- Dynamic CIP off
- Dynamic CIP on
- Binomial filter

Factory setting

Standard CIP off

Additional information

Description

The user can choose from a range of filter combinations which can optimize the measurement result depending on the application. Each change in the filter setting affects the output signal of the measuring device. The response time of the output signal increases as the filter depth increases.

Selection

- **Standard**
 - Strong flow damping with a short output signal response time.
 - Some time is needed before a stable output signal can be generated.
 - Not suitable for pulsating flow as the average flow can be different here.
- **Dynamic**
 - Average flow damping with a delayed output signal response time.
 - The average flow is displayed correctly over a measuring interval determined over a long period.
- **Binominal**
 - Weak flow damping with a short output signal response time.
 - The average flow is displayed correctly over a measuring interval determined over a long period.
- **CIP**
 - This filter is also available for the **Standard** and **Dynamic** filter options.
 - If the CIP filter has detected a change in the medium (abrupt increase in the noise level, e.g. quickly changing medium conductivity values during CIP cleaning), flow damping is greatly increased and the raw value (before flow damping) is limited by the mean value (delimiter). This eliminates extremely high measured errors (up to several 100 m/s).
 - If the CIP filter is enabled, the response time of the entire measuring system increases and the output signal is delayed accordingly.

Examples

Possible applications for the filters

Application	Standard	Standard CIP	Dynamic	Dynamic CIP	Binomial
Pulsating flow (flow is negative intermittently)	---	---	++	--	++
Flow changes frequently (flow is dynamic)	-	--	++	-	++
Clear signal, quick control loop (< 1 s)	--	--	+ ¹⁾		++
Poor signal, slow control loop (response time of a few seconds)	++	-	--	---	---
Permanently bad signal	++	--	-	---	-
Short and severe signal distortion after a while		++		++	
Promag 50/53 replacement: Promag 100 system damping = 0.5 * Promag 50/53					+++
Promag 10 replacement: Promag 100 system damping = Promag 10 + 2			+++		
For a stable flow signal (no other requirements)	+++				

1) Flow damping value < 6

Flow damping



Navigation

Expert → Sensor → Process param. → Flow damping


Description

Use this function to enter flow damping. Reduction of the variability of the flow measured value (in relation to interference). For this purpose, the depth of the flow filter is adjusted: when the filter setting increases, the reaction time of the device also increases.





User entry 0 to 15

Factory setting 7



Additional information *User entry*

- Value = 0: no damping
- Value > 0: damping is increased
-  ▪ 0 means weak damping and 15 intense damping.
- A damping value of 0 is not recommended as the level of noise interference on the measuring signal is then so high that it would be virtually impossible to take a measurement.
- Damping depends on the measuring period and the selected filter type.
- Increasing or decreasing the damping depends on the application.

Result

-  The damping affects the following variables of the device:
 - Outputs →  74
 - Low flow cut off →  57
 - Totalizer →  135

Flow override

Navigation   Expert → Sensor → Process param. → Flow override

Description Use this function to select whether to interrupt the evaluation of measured values. This is useful for the cleaning processes of a pipeline, for example.

Selection

- Off
- On


Factory setting Off

Additional information *Result*



-  This setting affects all the functions and outputs of the measuring device.

Description

Flow override is active

- The diagnostic message diagnostic message  **C453 Flow override** is displayed.
- Output values
 - Output: Value at zero flow
 - Temperature: proceeding output
 - Totalizers 1-3: Stop being totalized



Conductivity damping


Navigation   Expert → Sensor → Process param. → Conduct. damping




Prerequisite In the **Conductivity measurement** parameter (→  57), the **On** option is selected.

Description	Use this function to enter the time constant for conductivity damping.
User entry	0 to 999.9 s
Factory setting	0 s



Temperature damping 

Navigation	  Expert → Sensor → Process param. → Temp. damping
Prerequisite	For the following order code: "Sensor Option", option CI "Fluid temperature probe"
Description	Use this function to enter the time constant for temperature damping.
User entry	0 to 999.9 s
Factory setting	0 s



Conductivity measurement 



Navigation	  Expert → Sensor → Process param. → Conduct. measur.
Description	Use this function to enable and disable conductivity measurement.
Selection	<ul style="list-style-type: none"> ■ Off ■ On
Factory setting	Off
Additional information	<p><i>Description</i></p> <p> For conductivity measurement to work, the medium must have a minimum conductivity of 5 µS/cm.</p>

"Low flow cut off" submenu



Navigation   Expert → Sensor → Process param. → Low flow cut off

▶ **Low flow cut off**








Assign process variable	→  58
On value low flow cutoff	→  58

Off value low flow cutoff	→  59
Pressure shock suppression	→  59

Assign process variable


Navigation	  Expert → Sensor → Process param. → Low flow cut off → Assign variable
Description	Use this function to select the process variable for low flow cutoff detection.
Selection	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Mass flow ■ Corrected volume flow
Factory setting	Volume flow

On value low flow cutoff

Navigation	  Expert → Sensor → Process param. → Low flow cut off → On value
Prerequisite	One of the following options is selected in the Assign process variable parameter (→  58): <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow
Description	Use this function to enter a switch-on value for low flow cut off. Low flow cut off is activated if the value entered is not equal to 0 →  59.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter →  163
Additional information	<p><i>Dependency</i></p> <p> The unit depends on the process variable selected in the Assign process variable parameter (→  58).</p>

Off value low flow cutoff


Navigation	Expert → Sensor → Process param. → Low flow cut off → Off value
Prerequisite	One of the following options is selected in the Assign process variable parameter (→ 58): <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow
Description	Use this function to enter a switch-off value for low flow cut off. The off value is entered as a positive hysteresis from the on value → 58.
User entry	0 to 100.0 %
Factory setting	50 %
Additional information	<i>Example</i>



A0012887

- Q* Flow
t Time
H Hysteresis
A Low flow cut off active
1 Low flow cut off is activated
2 Low flow cut off is deactivated
3 On value entered
4 Off value entered

Pressure shock suppression


Navigation	Expert → Sensor → Process param. → Low flow cut off → Pres. shock sup.
Prerequisite	One of the following options is selected in the Assign process variable parameter (→ 58): <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow
Description	Use this function to enter the time interval for signal suppression (= active pressure shock suppression).
User entry	0 to 100 s
Factory setting	0 s

Additional information*Description***Pressure shock suppression is enabled**


- Prerequisite:
 - Flow rate < on-value of low flow cut off
- Output values
 - Current output: outputs the current corresponding to zero flow.
 - Flow displayed: 0
 - Totalizer: the totalizers are pegged at the last correct value

Pressure shock suppression is disabled

- Prerequisite: the time interval set in this function has elapsed.
- If the flow also exceeds the switch-off value for low flow cut off, the device starts processing the current flow value again and displays it.

Example


When closing a valve, momentarily strong fluid movements may occur in the pipeline, which are registered by the measuring system. These totalized flow values lead to a false totalizer status, particularly during batching processes.











A0012888

- Q Flow
- t Time
- A Drip
- B Pressure shock
- C Pressure shock suppression active as specified by the time entered
- D Pressure shock suppression inactive
- 1 Valve closes
- 2 Flow falls below the on-value of the low flow cut off: pressure shock suppression is activated
- 3 The time entered has elapsed: pressure shock suppression is deactivated
- 4 The actual flow value is now displayed and output
- 5 On value for low flow cut off
- 6 Off value for low flow cut off


"Empty pipe detection" submenu


Navigation  Expert → Sensor → Process param. → Empty pipe det.



▶ **Empty pipe detection**

Empty pipe detection	→  61
Switch point empty pipe detection	→  61
Response time empty pipe detection	→  62
New adjustment	→  62
Progress	→  62
Empty pipe adjust value	→  63
Full pipe adjust value	→  63
Measured value EPD	→  63

Empty pipe detection 

Navigation	 Expert → Sensor → Process param. → Empty pipe det. → Empty pipe det.
Description	Use this function to switch empty pipe detection on and off.
Selection	<ul style="list-style-type: none"> ■ Off ■ On
Factory setting	Off

Switch point empty pipe detection 

Navigation	 Expert → Sensor → Process param. → Empty pipe det. → Switch point EPD
Prerequisite	The On option is selected in the Empty pipe detection parameter (→  61).
Description	Use this function to enter the percentage threshold value of the resistance in relation to the adjustment values.
User entry	0 to 100 %
Factory setting	10 %

Response time empty pipe detection


Navigation	Expert → Sensor → Process param. → Empty pipe det. → Response time
Prerequisite	In the Empty pipe detection parameter (→ 61), the On option is selected.
Description	Enter the minimum length of time (debouncing time) the signal must be present for the diagnostic message △S862 Empty pipe to be triggered if the measuring pipe is empty or partially full.
User entry	0 to 100 s
Factory setting	1 s

New adjustment


Navigation	Expert → Sensor → Process param. → Empty pipe det. → New adjustment
Prerequisite	The On option is selected in the Empty pipe detection parameter (→ 61).
Description	For selecting whether to perform an empty pipe or full pipe adjustment.
Selection	<ul style="list-style-type: none"> ▪ Cancel ▪ Empty pipe adjust ▪ Full pipe adjust
Factory setting	Cancel

Progress

Navigation	Expert → Sensor → Process param. → Empty pipe det. → Progress
Prerequisite	The On option is selected in the Empty pipe detection parameter (→ 61).
Description	Use this function to view the progress.
User interface	<ul style="list-style-type: none"> ▪ Ok ▪ Busy ▪ Not ok

Empty pipe adjust value

Navigation	Expert → Sensor → Process param. → Empty pipe det. → Empty pipe value
Prerequisite	<ul style="list-style-type: none"> ▪ In the Empty pipe detection parameter (→ 61), the On option is selected. ▪ Adjustment value > full pipe value.
Description	Displays the adjustment value when the measuring pipe is empty.
User interface	Positive floating-point number

Full pipe adjust value

Navigation	Expert → Sensor → Process param. → Empty pipe det. → Full pipe value
Prerequisite	<ul style="list-style-type: none"> ▪ In the Empty pipe detection parameter (→ 61), the On option is selected. ▪ Adjustment value < empty pipe value.
Description	Displays the adjustment value when the measuring pipe is full.
User interface	Positive floating-point number

Measured value EPD

Navigation	Expert → Sensor → Process param. → Empty pipe det. → Meas. value EPD
Prerequisite	In the Empty pipe detection parameter (→ 61), the On option is selected.
Description	Displays the current measured value.
User interface	Positive floating-point number

"Electrode cleaning circuit" submenu

Navigation Expert → Sensor → Process param. → ECC

▶ Electrode cleaning circuit	
Electrode cleaning circuit	→ 64
ECC duration	→ 64
ECC recovery time	→ 64

ECC cleaning cycle	→ 65
ECC Polarity	→ 65

Electrode cleaning circuit


Navigation	Expert → Sensor → Process param. → ECC → ECC
Prerequisite	For the following order code: "Application package", option EC "ECC electrode cleaning"
Description	Use this function to enable and disable cyclic electrode cleaning.
Selection	<ul style="list-style-type: none"> ■ Off ■ On
Factory setting	Off

ECC duration


Navigation	Expert → Sensor → Process param. → ECC → ECC duration
Prerequisite	For the following order code: "Application package", option EC "ECC electrode cleaning"
Description	Use this function to enter the duration of electrode cleaning in seconds.
User entry	0.01 to 30 s
Factory setting	2 s

ECC recovery time


Navigation	Expert → Sensor → Process param. → ECC → ECC recov. time
Prerequisite	For the following order code: "Application package", option EC "ECC electrode cleaning"
Description	Use this function to enter the recovery time after electrode cleaning to prevent signal output interference. The current output values are frozen in the meanwhile.
User entry	Positive floating-point number
Factory setting	60 s

ECC cleaning cycle

Navigation	Expert → Sensor → Process param. → ECC → ECC clean. cycle
Prerequisite	For the following order code: "Application package", option EC "ECC electrode cleaning"
Description	Use this function to enter the pause duration until the next electrode cleaning.
User entry	0.5 to 168 h
Factory setting	0.5 h


ECC Polarity



Navigation	Expert → Sensor → Process param. → ECC → ECC Polarity
Prerequisite	For the following order code: "Application package", option EC "ECC electrode cleaning"
Description	Displays the polarity of the electrode cleaning circuit.
User interface	<ul style="list-style-type: none"> ■ Positive ■ Negative
Factory setting	Depends on the electrode material: <ul style="list-style-type: none"> ■ Platinum: Negative option ■ Tantalum, Alloy C22, stainless steel: Positive option

3.2.4 "External compensation" submenu






Navigation Expert → Sensor → External comp.

► External compensation	
External value	→ 66
External temperature	→ 66
External density	→ 66
Fixed density	→ 66
Reference density	→ 67






External value



Navigation	  Expert → Sensor → External comp. → External value
Description	Use this function to select the process variable which is taken from an external device.
Selection	<ul style="list-style-type: none"> ■ Off ■ Density ■ Temperature
Factory setting	Off



External temperature



Navigation	  Expert → Sensor → External comp. → External temp.
Prerequisite	In the External value parameter (→  66), the Temperature option is selected.
Description	Displays the temperature read in from the external device.
User interface	Floating point number with sign
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  45)

External density





Navigation	  Expert → Sensor → External comp. → External density
Prerequisite	In the External value parameter (→  66), the Density option is selected.
Description	Displays the density read in from the external device.
User interface	Positive floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Density unit parameter (→  47)

Fixed density


Navigation	  Expert → Sensor → External comp. → Fixed density
Description	Use this function to enter a fixed value for the density.

User entry	Positive floating-point number
Factory setting	Country-specific: <ul style="list-style-type: none"> ■ 1 000 kg/l ■ 1 000 lb/ft³
Additional information	<i>Dependency</i>  The unit is taken from the Density unit parameter (→  47)





Reference density


Navigation	  Expert → Sensor → External comp. → Ref.density
Description	Use this function to enter a fixed value for the reference density.
User entry	Positive floating-point number
Factory setting	Country-specific: <ul style="list-style-type: none"> ■ 1 kg/l ■ 1 lb/ft³
Additional information	<i>Dependency</i>  The unit is taken from the Density unit parameter (→  47)

3.2.5 "Sensor adjustment" submenu

Navigation   Expert → Sensor → Sensor adjustm.

▶ Sensor adjustment

Installation direction	→  68
Integration time	→  68
Measuring period	→  68
▶ Process variable adjustment	→  68

Installation direction
**Navigation**

Expert → Sensor → Sensor adjustm. → Install. direct.

Description

Use this function to change the sign of the medium flow direction.

Selection

- Flow in arrow direction
- Flow against arrow direction

Factory setting

Flow in arrow direction

Additional information*Description*

Before changing the sign: ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor nameplate.

Integration time
**Navigation**

Expert → Sensor → Sensor adjustm. → Integration time

Description

Display the duration of an integration cycle.

User interface

1 to 65 ms

Measuring period
**Navigation**

Expert → Sensor → Sensor adjustm. → Measuring period

Description

Display the time of a full measuring period.

User interface

50 to 1 000 ms

"Process variable adjustment" submenu
Navigation Expert → Sensor → Sensor adjustm. → Variable adjust

▶ Process variable adjustment	
Volume flow offset	→ 69
Volume flow factor	→ 69
Mass flow offset	→ 70

Mass flow factor	→ 70
Conductivity offset	→ 70
Conductivity factor	→ 71
Corrected volume flow offset	→ 71
Corrected volume flow factor	→ 71
Temperature offset	→ 72
Temperature factor	→ 72




Volume flow offset

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow offset
Description	Use this function to enter the zero point shift for the volume flow trim. The volume flow unit on which the shift is based is m ³ /s.
User entry	Signed floating-point number
Factory setting	0 m ³ /s
Additional information	<p><i>Description</i></p> <p> Corrected value = (factor × value) + offset</p>




Volume flow factor

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow factor
Description	Use this function to enter a quantity factor (without time) for the volume flow. This multiplication factor is applied over the volume flow range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<p><i>Description</i></p> <p> Corrected value = (factor × value) + offset</p>





Mass flow offset 














Navigation	  Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow offset
Description	Use this function to enter the zero point shift for the mass flow trim. The mass flow unit on which the shift is based is kg/s.
User entry	Signed floating-point number
Factory setting	0 kg/s
Additional information	<i>Description</i>  Corrected value = (factor × value) + offset



Mass flow factor 



Navigation	  Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow factor
Description	Use this function to enter a quantity factor (without time) for the mass flow. This multiplication factor is applied over the mass flow range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<i>Description</i>  Corrected value = (factor × value) + offset

Conductivity offset 

Navigation	  Expert → Sensor → Sensor adjustm. → Variable adjust → Conduct. offset
Prerequisite	In the Conductivity measurement parameter (→  57), the On option is selected.
Description	Use this function to enter the zero point shift for the conductivity trim. The conductivity unit on which the shift is based is S/m
User entry	Signed floating-point number
Factory setting	0 S/m
Additional information	<i>Description</i>  Corrected value = (factor × value) + offset



Conductivity factor 	
Navigation	  Expert → Sensor → Sensor adjustm. → Variable adjust → Conduct. factor
Prerequisite	In the Conductivity measurement parameter (→  57), the On option is selected.
Description	Use this function to enter a quantity factor for the conductivity. This multiplication factor is applied over the conductivity range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<p><i>Description</i></p> <p> Corrected value = (factor × value) + offset</p>
Corrected volume flow offset 	
Navigation	  Expert → Sensor → Sensor adjustm. → Variable adjust → Corr. vol offset
Description	Use this function to enter the zero point shift for the corrected volume flow trim. The corrected volume flow unit on which the shift is based is 1 Nm ³ /s.
User entry	Signed floating-point number
Factory setting	0 Nm ³ /s
Additional information	<p><i>Description</i></p> <p> Corrected value = (factor × value) + offset</p>
Corrected volume flow factor 	
Navigation	  Expert → Sensor → Sensor adjustm. → Variable adjust → Corr. vol factor
Description	Use this function to enter a quantity factor (without time) for the corrected volume flow. This multiplication factor is applied over the corrected volume flow range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<p><i>Description</i></p> <p> Corrected value = (factor × value) + offset</p>



Temperature offset	
Navigation	 Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. offset
Prerequisite	For the following order code: "Sensor Option", option CI "Fluid temperature probe"
Description	Use this function to enter the zero point shift for the temperature trim. The temperature unit on which the shift is based is 1 K.
User entry	Signed floating-point number
Factory setting	0 K
Additional information	<i>Description</i>  Corrected value = (factor × value) + offset

Temperature factor	
Navigation	 Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. factor
Prerequisite	For the following order code: "Sensor Option", option CI "Fluid temperature probe"
Description	Use this function to enter a quantity factor (without time) for the temperature. This multiplication factor is applied over the temperature range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<i>Description</i>  Corrected value = (factor × value) + offset




3.2.6 "Calibration" submenu

Navigation  Expert → Sensor → Calibration



▶ Calibration	
Nominal diameter	→  73
Calibration factor	→  73

Zero point	→  73
Conductivity calibration factor	→  74



Nominal diameter

Navigation	  Expert → Sensor → Calibration → Nominal diameter
Description	Displays the nominal diameter of the sensor.
User interface	DN _{xx} / x"
Factory setting	Depends on the size of the sensor
Additional information	<p><i>Description</i></p> <p> The value is also specified on the sensor nameplate.</p>

Calibration factor

Navigation	  Expert → Sensor → Calibration → Cal. factor
Description	Displays the current calibration factor for the sensor.
User interface	Positive floating-point number
Factory setting	Depends on nominal diameter and calibration.

Zero point

Navigation	  Expert → Sensor → Calibration → Zero point
Description	This function shows the zero point correction value for the sensor.
User interface	Signed floating-point number
Factory setting	Depends on nominal diameter and calibration

Conductivity calibration factor


Navigation	Expert → Sensor → Calibration → Cond. cal. fact.
Prerequisite	In the Conductivity measurement parameter (→ 57), the On option is selected.
Description	Displays the calibration factor for the conductivity measurement.
User interface	0 to 10 000

3.3 "Output" submenu

Navigation Expert → Output

▶ Output	
▶ Current output 1	→ 74
▶ Pulse/frequency/switch output 1	→ 86

3.3.1 "Current output 1" submenu

Navigation Expert → Output → Curr.output 1

▶ Current output 1	
Assign current output	→ 75
Current span	→ 75
Fixed current	→ 76
0/4 mA value	→ 77
20 mA value	→ 78
Measuring mode	→ 79
Damping output	→ 83
Response time	→ 84
Failure mode	→ 85
Failure current	→ 86

Output current 1	→ 86
Measured current 1	→ 86

Assign current output

Navigation   Expert → Output → Curr.output 1 → Assign curr.

Description Use this function to select a process variable for the current output.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity
- Conductivity *
- Corrected conductivity *
- Temperature *
- Electronic temperature

Factory setting Volume flow

Current span

Navigation   Expert → Output → Curr.output 1 → Current span

Description Use this function to select the current range for the process value output and the upper and lower level for signal on alarm.


Selection

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- 0...20 mA
- Fixed current

Factory setting Country-specific:


- 4...20 mA NAMUR
- 4...20 mA US

Additional information *Description*

-  In the event of a device alarm, the current output adopts the value specified in the **Failure mode** parameter (→ 85).
- If the measured value is outside the measuring range, the diagnostic message **△S441 Current output 1** is displayed.
- The measuring range is specified via the **0/4 mA value** parameter (→ 77) and **20 mA value** parameter (→ 78).


* Visibility depends on order options or device settings

"Fixed current" option

The current value is set via the **Fixed current** parameter (→  76).

Example

Shows the relationship between the current span for the output of the process variable and the lower and upper alarm levels:





A0013316


- I* Current
- 1* Current span for process value
- 2* Lower level for signal on alarm
- 3* Upper level for signal on alarm

Selection


Selection	1	2	3
4...20 mA NAMUR	3.8 to 20.5 mA	< 3.6 mA	> 21.95 mA
4...20 mA US	3.9 to 20.8 mA US	< 3.6 mA	> 21.95 mA
4...20 mA	4 to 20.5 mA	< 3.6 mA	> 21.95 mA
0...20 mA	0 to 20.5 mA	< 0 mA	> 21.95 mA

 If the flow exceeds or falls below the upper or lower signal on alarm level, the diagnostic message  **S441 Current output 1** is displayed.

Fixed current**Navigation**

  Expert → Output → Curr.output 1 → Fixed current

Prerequisite

In the **Current span** parameter (→  75), the **Fixed current** option is selected.

Description

Use this function to enter a constant current value for the current output.

User entry

0 to 22.5 mA

Factory setting

22.5 mA

Additional information*Example*

This setting can be used for HART multidrop, for example.

0/4 mA value**Navigation**

Expert → Output → Curr.output 1 → 0/4 mA value

Prerequisite

One of the following options is selected in the **Current span** parameter (→ 75):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- 0...20 mA

Description

Use this function to enter a value for the 0/4 mA current.

User entry

Signed floating-point number

Factory setting

Country-specific:

- 0 l/h
- 0 gal/min (us)

Additional information*Description*

Positive and negative values are permitted depending on the process variable assigned in the **Assign current output** parameter (→ 75). In addition, the value can be greater than or smaller than the value assigned for the 20 mA current in the **20 mA value** parameter (→ 78).

Dependency

The unit depends on the process variable selected in the **Assign current output** parameter (→ 75).

Current output behavior

The current output behaves differently depending on the settings configured in the following parameters:

- Current span (→ 75)
- Measuring mode (→ 79)
- Failure mode (→ 85)


Configuration examples

Some examples of parameter settings and their effect on the current output are given in the following section.

Configuration example A

Measuring mode with **Forward flow** option

- **0/4 mA value** parameter (→ 77) = not equal to zero flow (e.g. -250 m³/h)
- **20 mA value** parameter (→ 78) = not equal to zero flow (e.g. +750 m³/h)
- Calculated current value = 8 mA at zero flow




A0013757

Q Flow
I Current
1 Measuring range is exceeded or undershot

The operational range of the measuring device is defined by the values entered for the **0/4 mA value** parameter (→ [☰ 77](#)) and **20 mA value** parameter (→ [☰ 78](#)). If the effective flow exceeds or falls below this operational range, the diagnostic message **△S441 Current output 1** is displayed.

Configuration example B

Measuring mode with **Forward/Reverse flow** option



- I* Current
Q Flow
 1 Value assigned to the 0/4 mA current
 2 Forward flow
 3 Reverse flow

The current output signal is independent of the direction of flow (absolute amount of the measured variable). The values for the **0/4 mA value** parameter (→ [☰ 77](#)) and **20 mA value** parameter (→ [☰ 78](#)) must have the same sign. The value for the **20 mA value** parameter (→ [☰ 78](#)) (e.g. reverse flow) corresponds to the mirrored value for the **20 mA value** parameter (→ [☰ 78](#)) (e.g. forward flow).

Configuration example C

Measuring mode with **Reverse flow compensation** option

If flow is characterized by severe fluctuations (e.g. when using reciprocating pumps), flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 s → [☰ 79](#).

20 mA value



Navigation

[☰☰](#) Expert → Output → Curr.output 1 → 20 mA value

Prerequisite

One of the following options is selected in the **Current span** parameter (→ [☰ 75](#)):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- 0...20 mA

Description

Use this function to enter a value for the 20 mA current.

User entry

Signed floating-point number


Factory setting

Depends on country and nominal diameter → [☰ 162](#)

Additional information

Description

Positive and negative values are permitted depending on the process variable assigned in the **Assign current output** parameter (→ [☰ 75](#)). In addition, the value can be greater




than or smaller than the value assigned for the 0/4 mA current in the **0/4 mA value** parameter (→  77).

Dependency



 The unit depends on the process variable selected in the **Assign current output** parameter (→  75).

Example

- Value assigned to 0/4 mA = -250 m³/h
- Value assigned to 20 mA = +750 m³/h
- Calculated current value = 8 mA (at zero flow)



If the **Forward/Reverse flow** option is selected in the **Measuring mode** parameter (→  79), different signs cannot be entered for the values of the **0/4 mA value** parameter (→  77) and **20 mA value** parameter (→  78). The diagnostic message **△S441 Current output 1** is displayed.

Configuration examples

 Observe the configuration examples for the **0/4 mA value** parameter (→  77).

Measuring mode


Navigation

  Expert → Output → Curr.output 1 → Measuring mode

Prerequisite

One of the following options is selected in the **Assign current output** parameter (→  75):

- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity
- Conductivity *
- Corrected conductivity *
- Temperature *
- Electronic temperature

One of the following options is selected in the **Current span** parameter (→  75):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- 0...20 mA

Description

Use this function to select the measuring mode for the current output.

Selection

- Forward flow
- Forward/Reverse flow
- Reverse flow compensation

Factory setting

Forward flow

* Visibility depends on order options or device settings


Additional information*Description*


 The process variable that is assigned to the current output via the **Assign current output** parameter (→  75) is displayed below the parameter.

"Forward flow" option





The current output signal is proportional to the process variable assigned. The measuring range is defined by the values that are assigned to the 0/4 mA and 20 mA current value.

The flow components outside the scaled measuring range are taken into account for signal output as follows:

- Both values are defined such that they are not equal to zero flow e.g.:
 - 0/4 mA current value = $-5 \text{ m}^3/\text{h}$
 - 20 mA current value = $10 \text{ m}^3/\text{h}$
- If the effective flow exceeds or falls below this measuring range, the diagnostic message  **S441 Current output 1** is displayed.


"Forward/Reverse flow" option

- I* Current
Q Flow
 1 Value assigned to the 0/4 mA current
 2 Forward flow
 3 Reverse flow

- The current output signal is independent of the direction of flow (absolute amount of the measured variable). The values for the **0/4 mA value** parameter (→  77) and **20 mA value** parameter (→  78) must have the same sign.
- The value for the **20 mA value** parameter (→  78) (e.g. reverse flow) corresponds to the mirrored value for the **20 mA value** parameter (→  78) (e.g. forward flow).

"Reverse flow compensation" option


If flow is characterized by severe fluctuations (e.g. when using reciprocating pumps), flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 s.

If buffering cannot be processed within approx. 60 s, the diagnostic message  **S441 Current output 1** is displayed.

Under certain plant conditions, flow values can aggregate in the buffer, for example in the case of prolonged and unwanted fluid reverse flow. However, this buffer is reset in all relevant programming adjustments which affect the current output.

*Examples of how the current output behaves***Example 1**

Defined measuring range: lower range value and upper range value with the **same** sign




A0028084

4 Measuring range

- I* Current
- Q* Flow
- 1 Lower range value (value assigned to 0/4 mA current)
- 2 Upper range value (value assigned to 20 mA current)

With the following flow response:




A0028091

5 Flow response

- Q* Flow
- t* Time

With **Forward flow** option

The current output signal is proportional to the process variable assigned. The flow components outside the scaled measuring range are not taken into account for signal output.




A0028092

- I* Current
- t* Time

With **Forward/Reverse flow** option

The current output signal is independent of the direction of flow.




A0028093

- I* Current
- t* Time

With **Reverse flow compensation** option

Flow components outside the span are buffered, balanced and output after a maximum delay of 60 s.




A0028094

I Current
 t Time
 S Flow components saved
 A Balancing of saved flow components

Example 2

Defined measuring range: lower range value and upper range value with **different** signs




A0028095

6 Measuring range

I Current
 Q Flow
 1 Lower range value (value assigned to 0/4 mA current)
 2 Upper range value (value assigned to 20 mA current)

With flow a (–) outside, b (–) inside the measuring range




A0028096

Q Flow
 t Time
 1 Lower range value (value assigned to 0/4 mA current)
 2 Upper range value (value assigned to 20 mA current)

With **Forward flow** option

- a (–): The flow components outside the scaled measuring range cannot be taken into account for signal output.
The diagnostic message $\triangle S441$ Current output 1 is displayed.
- b (–): The current output signal is proportional to the process variable assigned.



A0028100


I Current
 t Time

With **Forward/Reverse flow** option

This option is not possible in this case as the values for the **0/4 mA value** parameter (→ ☰ 77) and **20 mA value** parameter (→ ☰ 78) have different signs.

With **Reverse flow compensation** option

Flow components outside the span are buffered, balanced and output after a maximum delay of 60 s.



A0028101

I Current
 t Time
 S Flow components saved
 A Balancing of saved flow components

Damping output



Navigation

☰☰ Expert → Output → Curr.output 1 → Damping out.

Prerequisite

One of the following options is selected in the **Assign current output** parameter (→ ☰ 75):

- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity
- Conductivity*
- Corrected conductivity*
- Temperature*
- Electronic temperature

One of the following options is selected in the **Current span** parameter (→ ☰ 75):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- 0...20 mA

Description

Use this function to enter the reaction time of the current output signal to fluctuations in the measured value caused by process conditions.

* Visibility depends on order options or device settings

User entry 0.0 to 999.9 s


Factory setting 1.0 s


Additional information *User entry*

Use this function to enter a time constant:


- If a low time constant is entered, the current output reacts particularly quickly to fluctuating measured variables.
- On the other hand, the current output reacts more slowly if a high time constant is entered.

Response time

Navigation  Expert → Output → Curr.output 1 → Response time

Prerequisite One of the following options is selected in the **Assign current output** parameter (→  75):

- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity
- Conductivity^{*}
- Corrected conductivity^{*}
- Temperature^{*}
- Electronic temperature



One of the following options is selected in the **Current span** parameter (→  75):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- 0...20 mA

Description Displays the response time. This specifies how quickly the current output reaches the measured value change of 63 % of 100 % of the measured value change.

User interface Positive floating-point number

Additional information *Description*

-  The response time is made up of the time specified for the following dampings:
- Current output damping →  83
and
 - Depending on the measured variable assigned to the output.
Flow damping

* Visibility depends on order options or device settings

**Failure mode****Navigation**

Expert → Output → Curr.output 1 → Failure mode

Prerequisite

One of the following options is selected in the **Assign current output** parameter (→ 75):

- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity
- Conductivity*
- Corrected conductivity*
- Temperature*
- Electronic temperature

One of the following options is selected in the **Current span** parameter (→ 75):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- 0...20 mA

Description

Use this function to select the value of the current output in the event of a device alarm.

Selection

- Min.
- Max.
- Last valid value
- Actual value
- Defined value

Factory setting

Max.

Additional information*Description*

This setting does not affect the failsafe mode of other outputs and totalizers. This is specified in separate parameters.

"Min." option

The current output adopts the value of the lower level for signal on alarm.

The signal on alarm level is defined via the **Current span** parameter (→ 75).

"Max." option

The current output adopts the value of the upper level for signal on alarm.

The signal on alarm level is defined via the **Current span** parameter (→ 75).

"Last valid value" option

The current output adopts the last measured value that was valid before the device alarm occurred.



"Actual value" option


The current output adopts the measured value on the basis of the current flow measurement; the device alarm is ignored.




* Visibility depends on order options or device settings

"Defined value" option



The current output adopts a defined measured value.

 The measured value is defined via the **Failure current** parameter (→  86).



Failure current 

Navigation	  Expert → Output → Curr.output 1 → Failure current
Prerequisite	In the Failure mode parameter (→  85), the Defined value option is selected.
Description	Use this function to enter a fixed value that the current output adopts in the event of a device alarm.
User entry	0 to 22.5 mA
Factory setting	22.5 mA

Output current 1


Navigation	  Expert → Output → Curr.output 1 → Output curr. 1
Description	Displays the current value currently calculated for the current output.
User interface	0 to 22.5 mA

Measured current 1






Navigation	  Expert → Output → Curr.output 1 → Measur. curr. 1
Description	Use this function to display the actual measured value of the output current.
User interface	0 to 30 mA

3.3.2 "Pulse/frequency/switch output" submenu

Navigation   Expert → Output → PFS output



Assign pulse output	→ 89
Value per pulse	→ 90
Pulse width	→ 90
Measuring mode	→ 91
Failure mode	→ 92
Pulse output 1	→ 93
Assign frequency output	→ 93
Minimum frequency value	→ 94
Maximum frequency value	→ 94
Measuring value at minimum frequency	→ 95
Measuring value at maximum frequency	→ 95
Measuring mode	→ 96
Damping output	→ 97
Response time	→ 97
Failure mode	→ 98
Failure frequency	→ 99
Output frequency 1	→ 99
Switch output function	→ 99
Assign diagnostic behavior	→ 100
Assign limit	→ 101
Switch-on value	→ 102
Switch-off value	→ 103
Assign flow direction check	→ 103
Assign status	→ 104

Switch-on delay	→  104
Switch-off delay	→  104
Failure mode	→  105
Switch status 1	→  105
Invert output signal	→  105

Operating mode

Navigation

  Expert → Output → PFS output 1 → Operating mode

Description

Use this function to select the operating mode of the output as a pulse, frequency or switch output.

Selection

- Pulse
- Frequency
- Switch

Factory setting

Pulse

Additional information


"Pulse" option

Quantity-dependent pulse with configurable pulse width


- Whenever a specific mass, volume or corrected volume is reached (pulse value), a pulse is output, the duration of which was set previously (pulse width).
- The pulses are never shorter than the set duration.

Example

- Flow rate approx. 100 g/s
- Pulse value 0.1 g
- Pulse width 0.05 ms
- Pulse rate 1 000 Impuls/s



A0026883

 7 Quantity-proportional pulse (pulse value) with pulse width to be configured

B Pulse width entered

P Pauses between the individual pulses


"Frequency" option

Flow-proportional frequency output with 1:1 on/off ratio

An output frequency is output that is proportional to the value of a process variable, such as mass flow, volume flow, corrected volume flow, flow velocity, conductivity, corrected conductivity, temperature or electronic temperature.

Example

- Flow rate approx. 100 g/s
- Max. frequency 10 kHz
- Flow rate at max. frequency 1 000 g/s
- Output frequency approx. 1 000 Hz



A0026886


8 Flow-proportional frequency output

"Switch" option

Contact for displaying a condition (e.g. alarm or warning if a limit value is reached)

Example

Alarm response without alarm




A0026884

9 No alarm, high level

Example

Alarm response in case of alarm



A0026885

10 Alarm, low level

Assign pulse output



Navigation

Expert → Output → PFS output 1 → Assign pulse

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 88).



Description



Use this function to select the process variable for the pulse output.

Selection	<ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Volume flow ■ Corrected volume flow
------------------	--

Factory setting	Off
------------------------	-----


Value per pulse

Navigation	  Expert → Output → PFS output 1 → Value per pulse
-------------------	--

Prerequisite	<p>The Pulse option is selected in the Operating mode parameter (→  88), and one of the following options is selected in the Assign pulse output parameter (→  89):</p> <ul style="list-style-type: none"> ■ Mass flow ■ Volume flow ■ Corrected volume flow
---------------------	--

Description	Use this function to enter the value for the measured value that a pulse is equivalent to.
--------------------	--



User entry	Signed floating-point number
-------------------	------------------------------

Factory setting	Depends on country and nominal diameter →  163
------------------------	---

Additional information	<p><i>User entry</i></p> <p>Weighting of the pulse output with a quantity.</p> <p>The lower the pulse value, the</p> <ul style="list-style-type: none"> ■ better the resolution. ■ the higher the frequency of the pulse response.
-------------------------------	--

Pulse width

Navigation	  Expert → Output → PFS output 1 → Pulse width
-------------------	--

Prerequisite	<p>In the Operating mode parameter (→  88), the Pulse option is selected and one of the following options is selected in the Assign pulse output parameter (→  89):</p> <ul style="list-style-type: none"> ■ Mass flow ■ Volume flow ■ Corrected volume flow
---------------------	--


Description	Use this function to enter the duration of the output pulse.
--------------------	--

User entry	0.05 to 2 000 ms
-------------------	------------------

Factory setting	100 ms
------------------------	--------

Additional information*Description*

- Define how long a pulse is (duration).
- The maximum pulse rate is defined by $f_{\max} = 1 / (2 \times \text{pulse width})$.
- The interval between two pulses lasts at least as long as the set pulse width.
- The maximum flow is defined by $Q_{\max} = f_{\max} \times \text{pulse value}$.
- If the flow exceeds these limit values, the measuring device displays the diagnostic message **△S443 Pulse output 1 to 2**.



A0026882

B Pulse width entered
P Intervals between the individual pulses

Example

- Pulse value: 0.1 g
- Pulse width: 0.1 ms
- $f_{\max}: 1 / (2 \times 0.1 \text{ ms}) = 5 \text{ kHz}$
- $Q_{\max}: 5 \text{ kHz} \times 0.1 \text{ g} = 0.5 \text{ kg/s}$



The pulse width is not relevant for **Automatic pulse** option.

Measuring mode**Navigation**

Expert → Output → PFS output 1 → Measuring mode

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 88), and one of the following options is selected in the **Assign pulse output** parameter (→ 89):

- Mass flow
- Volume flow
- Corrected volume flow

Description





Use this function to select the measuring mode for the pulse output.

Selection





- Forward flow
- Forward/Reverse flow
- Reverse flow
- Reverse flow compensation

Factory setting





Forward flow


Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Forward flow Positive flow is output, negative flow is not output. ▪ Forward/Reverse flow Positive and negative flow are output (absolute value), but a distinction is not made between positive and negative flow. ▪ Reverse flow Negative flow is output, positive flow is not output. ▪ Reverse flow compensation The flow components outside the span are buffered, balanced and output after a maximum delay of 60 s. <p> For a detailed description of the options available, see the Measuring mode parameter (→  79)</p> <p><i>Examples</i></p> <p> For a detailed description of the configuration examples, see the Measuring mode parameter (→  79)</p>
-------------------------------	---

Failure mode


Navigation	  Expert → Output → PFS output 1 → Failure mode
Prerequisite	The Pulse option is selected in the Operating mode parameter (→  88) and one of the following options is selected in the Assign pulse output parameter (→  89): <ul style="list-style-type: none"> ▪ Mass flow ▪ Volume flow ▪ Corrected volume flow
Description	Use this function to select the failure mode of the pulse output in the event of a device alarm.
Selection	<ul style="list-style-type: none"> ▪ Actual value ▪ No pulses
Factory setting	No pulses
Additional information	<p><i>Description</i></p> <p>The dictates of safety render it advisable to ensure that the pulse output shows a predefined behavior in the event of a device alarm.</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Actual value In the event of a device alarm, the pulse output continues on the basis of the current flow measurement. The fault is ignored. ▪ No pulses In the event of a device alarm, the pulse output is "switched off". <p>NOTICE! A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The Actual value option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.</p>

Pulse output 1

Navigation	 Expert → Output → PFS output 1 → Pulse output 1
Prerequisite	In the Operating mode parameter (→  88), the Pulse option is selected.
Description	Displays the pulse frequency currently output.
User interface	Positive floating-point number
Additional information	<p><i>Description</i></p> <ul style="list-style-type: none"> ■ The pulse output is an open collector output. ■ This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented. ■ The Value per pulse parameter (→  90) and Pulse width parameter (→  90) can be used to define the value (i.e. the measured value amount that corresponds to a pulse) and the duration of the pulse.





0 Non-conductive
 1 Conductive
 NC NC contact (normally closed)
 NO NO contact (normally open)

The output behavior can be reversed via the **Invert output signal** parameter (→  105) i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (→  92)) can be configured.



Assign frequency output



Navigation	 Expert → Output → PFS output 1 → Assign freq.
Prerequisite	In the Operating mode parameter (→  88), the Frequency option is selected.
Description	Use this function to select the process variable for the frequency output.

Selection	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity[*] ■ Conductivity[*] ■ Corrected conductivity[*] ■ Temperature[*] ■ Electronic temperature
------------------	--

Factory setting	Off
------------------------	-----

Minimum frequency value

Navigation	  Expert → Output → PFS output 1 → Min. freq. value
-------------------	---



Prerequisite	<p>The Frequency option is selected in the Operating mode parameter (→  88) and one of the following options is selected in the Assign frequency output parameter (→  93):</p> <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity[*] ■ Conductivity[*] ■ Corrected conductivity[*] ■ Temperature[*] ■ Electronic temperature
---------------------	---



Description	Use this function to enter the start value frequency.
--------------------	---

User entry	0.0 to 10 000.0 Hz
-------------------	--------------------

Factory setting	0.0 Hz
------------------------	--------

Maximum frequency value







Navigation	  Expert → Output → PFS output 1 → Max. freq. value
-------------------	---

Prerequisite	<p>The Frequency option is selected in the Operating mode parameter (→  88) and one of the following options is selected in the Assign frequency output parameter (→  93):</p> <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity[*] ■ Conductivity[*] ■ Corrected conductivity[*] ■ Temperature[*] ■ Electronic temperature
---------------------	---





* Visibility depends on order options or device settings

Description	Use this function to enter the end value frequency.
User entry	0.0 to 10 000.0 Hz
Factory setting	10 000.0 Hz



Measuring value at minimum frequency

Navigation	  Expert → Output → PFS output 1 → Val. at min.freq
Prerequisite	The Frequency option is selected in the Operating mode parameter (→  88) and one of the following options is selected in the Assign frequency output parameter (→  93): <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity ■ Conductivity * ■ Corrected conductivity * ■ Temperature * ■ Electronic temperature
Description	Use this function to enter the measured value for the start value frequency.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter
Additional information	<i>Dependency</i>  The entry depends on the process variable selected in the Assign frequency output parameter (→  93).








Measuring value at maximum frequency

Navigation	  Expert → Output → PFS output 1 → Val. at max.freq
Prerequisite	The Frequency option is selected in the Operating mode parameter (→  88) and one of the following options is selected in the Assign frequency output parameter (→  93): <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity ■ Conductivity * ■ Corrected conductivity * ■ Temperature * ■ Electronic temperature
Description	Use this function to enter the measured value for the end value frequency.

* Visibility depends on order options or device settings

User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter
Additional information	<p><i>Description</i></p> <p>Use this function to enter the maximum measured value at the maximum frequency. The selected process variable is output as a proportional frequency.</p> <p><i>Dependency</i></p> <p> The entry depends on the process variable selected in the Assign frequency output parameter (→  93).</p>

Measuring mode

Navigation	 Expert → Output → PFS output 1 → Measuring mode
Prerequisite	<p>The Frequency option is selected in the Operating mode parameter (→  88) and one of the following options is selected in the Assign frequency output parameter (→  93):</p> <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity ■ Conductivity[*] ■ Corrected conductivity[*] ■ Temperature[*] ■ Electronic temperature
Description	Use this function to select the measuring mode for the frequency output.
Selection	<ul style="list-style-type: none"> ■ Forward flow ■ Forward/Reverse flow ■ Reverse flow compensation
Factory setting	Forward flow
Additional information	<p><i>Selection</i></p> <p> For a detailed description of the options available, see the Measuring mode parameter (→  79)</p> <p><i>Examples</i></p> <p> For a detailed description of the configuration examples, see the Measuring mode parameter (→  79)</p>

* Visibility depends on order options or device settings








Damping output


Navigation	Expert → Output → PFS output 1 → Damping out.
Prerequisite	The Frequency option is selected in the Operating mode parameter (→ 88) and one of the following options is selected in the Assign frequency output parameter (→ 93): <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity ■ Conductivity * ■ Corrected conductivity * ■ Temperature * ■ Electronic temperature
Description	Use this function to enter the reaction time of the output signal to fluctuations in the measured value.
User entry	0 to 999.9 s
Factory setting	0.0 s
Additional information	<i>Description</i> Use this function to enter a time constant (PT1 element) for frequency output damping. The frequency output is subject to separate damping that is independent of all preceding time constants.

Response time

Navigation	Expert → Output → PFS output 1 → Response time
Prerequisite	The Frequency option is selected in the Operating mode parameter (→ 88) and one of the following options is selected in the Assign frequency output parameter (→ 93): <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity ■ Conductivity * ■ Corrected conductivity * ■ Temperature * ■ Electronic temperature
Description	Displays the response time. This specifies how quickly the pulse/frequency/switch output reaches the measured value change of 63 % of 100 % of the measured value change.
User interface	Positive floating-point number

* Visibility depends on order options or device settings

Additional information	<p><i>Description</i></p> <p> The response time is made up of the time specified for the following dampings:</p> <ul style="list-style-type: none"> ▪ Damping of pulse/frequency/switch output →  83 and ▪ Depending on the measured variable assigned to the output. Flow damping
Failure mode	
Navigation	 Expert → Output → PFS output 1 → Failure mode
Prerequisite	<p>The Frequency option is selected in the Operating mode parameter (→  88) and one of the following options is selected in the Assign frequency output parameter (→  93):</p> <ul style="list-style-type: none"> ▪ Volume flow ▪ Mass flow ▪ Corrected volume flow ▪ Flow velocity ▪ Conductivity* ▪ Corrected conductivity* ▪ Temperature* ▪ Electronic temperature
Description	Use this function to select the failure mode of the frequency output in the event of a device alarm.
Selection	<ul style="list-style-type: none"> ▪ Actual value ▪ Defined value ▪ 0 Hz
Factory setting	0 Hz
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Actual value In the event of a device alarm, the frequency output continues on the basis of the current flow measurement. The device alarm is ignored. ▪ Defined value In the event of a device alarm, the frequency output continues on the basis of a predefined value. The Failure frequency (→  99) replaces the current measured value, making it possible to bypass the device alarm. The actual measurement is switched off for the duration of the device alarm. ▪ 0 Hz In the event of a device alarm, the frequency output is "switched off". <p>NOTICE! A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The Actual value option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.</p>

* Visibility depends on order options or device settings

Failure frequency


Navigation	Expert → Output → PFS output 1 → Failure freq.
Prerequisite	The Frequency option is selected in the Operating mode parameter (→ 88) and one of the following options is selected in the Assign frequency output parameter (→ 93): <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity ■ Conductivity * ■ Corrected conductivity * ■ Temperature * ■ Electronic temperature
Description	Use this function to enter the value for the frequency output in the event of a device alarm in order to bypass the alarm.
User entry	0.0 to 12 500.0 Hz
Factory setting	0.0 Hz

Output frequency 1

Navigation	Expert → Output → PFS output 1 → Output freq. 1
Prerequisite	In the Operating mode parameter (→ 88), the Frequency option is selected.
Description	Displays the actual value of the output frequency which is currently measured.
User interface	0.0 to 12 500.0 Hz






Switch output function


Navigation	Expert → Output → PFS output 1 → Switch out funct
Prerequisite	In the Operating mode parameter (→ 88) the Switch option is selected.
Description	Use this function to select a function for the switch output.
Selection	<ul style="list-style-type: none"> ■ Off ■ On ■ Diagnostic behavior ■ Limit ■ Flow direction check ■ Status

* Visibility depends on order options or device settings

Factory setting	Off
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Off The switch output is permanently switched off (open, non-conductive). ■ On The switch output is permanently switched on (closed, conductive). ■ Diagnostic behavior Indicates if the diagnostic event is present or not. Is used to output diagnostic information and to react to it appropriately at the system level. ■ Limit Indicates if a specified limit value has been reached for the process variable. Is used to output diagnostic information relating to the process and to react to it appropriately at the system level. ■ Flow direction check Indicates the flow direction (forward or reverse flow). ■ Status Indicates the device status depending on whether empty pipe detection or low flow cut off is selected.

Assign diagnostic behavior

Navigation	  Expert → Output → PFS output 1 → Assign diag. beh
Prerequisite	<ul style="list-style-type: none"> ■ The Switch option is selected in the Operating mode parameter (→  88). ■ The Diagnostic behavior option is selected in the Switch output function parameter (→  99).
Description	Use this function to select the diagnostic event category that is displayed for the switch output.
Selection	<ul style="list-style-type: none"> ■ Alarm ■ Alarm or warning ■ Warning
Factory setting	Alarm
Additional information	<p><i>Description</i></p> <p> If no diagnostic event is pending, the switch output is closed and conductive.</p> <p><i>Options</i></p> <ul style="list-style-type: none"> ■ Alarm The switch output signals only diagnostic events in the alarm category. ■ Alarm or warning The switch output signals diagnostic events in the alarm and warning category. ■ Warning The switch output signals only diagnostic events in the warning category.

Assign limit
**Navigation**

Expert → Output → PFS output 1 → Assign limit

Prerequisite

- In the **Operating mode** parameter (→ 88), the **Switch** option is selected.
- In the **Switch output function** parameter (→ 99), the **Limit** option is selected.

Description

Use this function to select a process variable for the limit function.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity
- Conductivity*
- Corrected conductivity*
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Temperature*
- Electronic temperature


Factory setting

Volume flow

Additional information*Description*

Behavior of status output when Switch-on value > Switch-off value:

- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive




A0026891

- 1 Switch-on value
- 2 Switch-off value
- 3 Conductive
- 4 Non-conductive
- A Process variable
- B Status output

Behavior of status output when Switch-on value < Switch-off value:

- Process variable < Switch-on value: transistor is conductive
- Process variable > Switch-off value: transistor is non-conductive

* Visibility depends on order options or device settings




A0026892

- 1 Switch-off value
- 2 Switch-on value
- 3 Conductive
- 4 Non-conductive
- A Process variable
- B Status output

Behavior of status output when Switch-on value = Switch-off value:

- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive



A0026893

- 1 Switch-on value = Switch-off value
- 2 Conductive
- 3 Non-conductive
- A Process variable
- B Status output

Switch-on value



Navigation

Expert → Output → PFS output 1 → Switch-on value

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 88).
- The **Limit** option is selected in the **Switch output function** parameter (→ 99).

Description




Use this function to enter the measured value for the switch-on point.

User entry








Signed floating-point number

Factory setting





- Country-specific:
- 0 l/h
 - 0 gal/min (us)

Additional information	<p><i>Description</i></p> <p>Use this function to enter the limit value for the switch-on value (process variable > switch-on value = closed, conductive).</p> <p> When using a hysteresis: Switch-on value > Switch-off value.</p> <p><i>Dependency</i></p> <p> The unit depends on the process variable selected in the Assign limit parameter (→  101).</p>
-------------------------------	--

Switch-off value

Navigation	  Expert → Output → PFS output 1 → Switch-off value
Prerequisite	<ul style="list-style-type: none"> ▪ The Switch option is selected in the Operating mode parameter (→  88). ▪ The Limit option is selected in the Switch output function parameter (→  99).
Description	Use this function to enter the measured value for the switch-off point.
User entry	Signed floating-point number
Factory setting	Country-specific: <ul style="list-style-type: none"> ▪ 0 l/h ▪ 0 gal/min (us)
Additional information	<p><i>Description</i></p> <p>Use this function to enter the limit value for the switch-off value (process variable < switch-off value = open, non-conductive).</p> <p> When using a hysteresis: Switch-on value > Switch-off value.</p> <p><i>Dependency</i></p> <p> The unit depends on the process variable selected in the Assign limit parameter (→  101).</p>

Assign flow direction check



Navigation	  Expert → Output → PFS output 1 → Assign dir.check
Prerequisite	<ul style="list-style-type: none"> ▪ The Switch option is selected in the Operating mode parameter (→  88). ▪ The Flow direction check option is selected in the Switch output function parameter (→  99).
Description	Use this function to select a process variable for monitoring the flow direction.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Volume flow ▪ Mass flow ▪ Corrected volume flow

Factory setting Volume flow

Assign status

Navigation   Expert → Output → PFS output 1 → Assign status

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→  88).
- The **Status** option is selected in the **Switch output function** parameter (→  99).

Description Use this function to select a device status for the switch output.

Selection



- Empty pipe detection
- Low flow cut off

Factory setting Empty pipe detection



Additional information *Options*

If empty pipe detection or low flow cut off are enabled, the output is conductive. Otherwise, the switch output is non-conductive.

Switch-on delay

Navigation   Expert → Output → PFS output 1 → Switch-on delay

Prerequisite



- The **Switch** option is selected in the **Operating mode** parameter (→  88).
- The **Limit** option is selected in the **Switch output function** parameter (→  99).

Description Use this function to enter a delay time for switching on the switch output.



User entry 0.0 to 100.0 s

Factory setting 0.0 s

Switch-off delay

Navigation   Expert → Output → PFS output 1 → Switch-off delay

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→  88).
- The **Limit** option is selected in the **Switch output function** parameter (→  99).

Description Use this function to enter a delay time for switching off the switch output.

User entry 0.0 to 100.0 s

Factory setting 0.0 s

Failure mode


Navigation	Expert → Output → PFS output 1 → Failure mode
Description	Use this function to select a failsafe mode for the switch output in the event of a device alarm.
Selection	<ul style="list-style-type: none"> ▪ Actual status ▪ Open ▪ Closed
Factory setting	Open
Additional information	<p><i>Options</i></p> <ul style="list-style-type: none"> ▪ Actual status In the event of a device alarm, faults are ignored and the current behavior of the input value is output by the switch output. The Actual status option behaves in the same way as the current input value. ▪ Open In the event of a device alarm, the switch output's transistor is set to non-conductive. ▪ Closed In the event of a device alarm, the switch output's transistor is set to conductive.

Switch status 1

Navigation	Expert → Output → PFS output 1 → Switch status 1
Prerequisite	The Switch option is selected in the Operating mode parameter (→ 88).
Description	Displays the current switch status of the status output.
User interface	<ul style="list-style-type: none"> ▪ Open ▪ Closed
Additional information	<p><i>User interface</i></p> <ul style="list-style-type: none"> ▪ Open The switch output is not conductive. ▪ Closed The switch output is conductive.


Invert output signal


Navigation	Expert → Output → PFS output 1 → Invert outp.sig.
Description	Use this function to select whether to invert the output signal.
Selection	<ul style="list-style-type: none"> ▪ No ▪ Yes

Factory setting No


Additional information *Selection*

No option (passive - negative)



A0026693


Yes option (passive - positive)





A0026692


3.4 "Communication" submenu

Navigation   Expert → Communication













3.4.1 "HART input" submenu

Navigation   Expert → Communication → HART input




"Configuration" submenu

Navigation  Expert → Communication → HART input → Configuration

► Configuration		
Capture mode	→ 	107
Device ID	→ 	108
Device type	→ 	108
Manufacturer ID	→ 	108
Burst command	→ 	109
Slot number	→ 	109
Timeout	→ 	110
Failure mode	→ 	110
Failure value	→ 	111

Capture mode



Navigation  Expert → Communication → HART input → Configuration → Capture mode

Description Use this function to select the capture mode via burst or master communication.

- Selection**
- Off
 - Burst network
 - Master network





Factory setting Off

Additional information *"Burst network" option*
The device records data transmitted via burst in the network.





"Master network" option

In this case, the device must be located in a HART network in which a HART master (control) queries the measured values of the up to 64 network participants. The device reacts only to the responses of a specific device in the network. Device ID, device type, manufacturer ID and the HART commands used by the master must be defined.




Device ID 


Navigation	  Expert → Communication → HART input → Configuration → Device ID
Prerequisite	The Master network option is selected in the Capture mode parameter (→  107).
Description	Use this function to enter the device ID of the HART slave device whose data are to be recorded.
User entry	6-digit value: <ul style="list-style-type: none"> ▪ Via local operation: enter as hexadecimal or decimal number ▪ Via operating tool: enter as decimal number
Factory setting	0
Additional information	 In addition to the device ID and manufacturer ID, the device type is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Device type 


Navigation	  Expert → Communication → HART input → Configuration → Device type
Prerequisite	The Master network option is selected in the Capture mode parameter (→  107).
Description	Use this function to enter the device type of the HART slave device whose data are to be recorded.
User entry	4-digit hexadecimal number
Factory setting	0x1138
Additional information	 In addition to the device ID and manufacturer ID, the device type is part of the unique ID. Each HART device is uniquely identified by the unique device ID.


Manufacturer ID 

Navigation	  Expert → Communication → HART input → Configuration → Manufacturer ID
Prerequisite	The Master network option is selected in the Capture mode parameter (→  107).
Description	Use this function to enter the manufacturer ID of the HART slave device whose data are to be recorded.
User entry	2-digit value: <ul style="list-style-type: none"> ▪ Via local operation: enter as hexadecimal or decimal number ▪ Via operating tool: enter as decimal number
Factory setting	0

Additional information  In addition to the device ID and manufacturer ID, the device type is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Burst command 

Navigation   Expert → Communication → HART input → Configuration → Burst command

Prerequisite The **Burst network** option or the **Master network** option are selected in the **Capture mode** parameter (→  107).



Description Use this function to select the burst command to be recorded.


- Selection**
- Command 1
 - Command 3
 - Command 9
 - Command 33

Factory setting Command 1

- Additional information** *Selection*
- Command 1
Use this function to capture the primary variable.
 - Command 3
Use this function to capture the dynamic HART variables and the current.
 - Command 9
Use this function to capture the dynamic HART variables including the associated status.
 - Command 33
Use this function to capture the dynamic HART variables including the associated unit.

Slot number 

Navigation   Expert → Communication → HART input → Configuration → Slot number

Prerequisite The **Burst network** option or the **Master network** option is selected in the **Capture mode** parameter (→  107).

Description Use this function to enter the position of the process variable to be recorded in the burst command.

User entry 1 to 4

Factory setting 1

Additional information *User entry*

Slot	Command			
	1	3	9	33
1	PV	PV	HART variable (slot 1)	HART variable (slot 1)
2	–	SV	HART variable (slot 2)	HART variable (slot 2)

Slot	Command			
	1	3	9	33
3	-	TV	HART variable (slot 3)	HART variable (slot 3)
4	-	QV	HART variable (slot 4)	HART variable (slot 4)

Timeout
**Navigation**

Expert → Communication → HART input → Configuration → Timeout

Prerequisite

In the **Capture mode** parameter (→ 107), the **Burst network** option or **Master network** option is selected.

Description

Use this function to enter the maximum permitted interval between two HART frames.

User entry

1 to 120 s

Factory setting

5 s

Additional information

Description



If the interval is exceeded, the measuring device displays the diagnostic message **F410 Data transfer**.

Failure mode
**Navigation**

Expert → Communication → HART input → Configuration → Failure mode

Prerequisite

In the **Capture mode** parameter (→ 107), the **Burst network** option or **Master network** option is selected.

Description

Use this function to select the device behavior if no data are recorded within the maximum permitted interval.

Selection

- Alarm
- Last valid value
- Defined value

Factory setting

Alarm

Additional information

Options


- Alarm
An error message is set.
- Last valid value
The last valid measured value is used.
- Defined value
A user-defined measured value is used: (**Failure value** parameter (→ 111)).

Failure value


Navigation	Expert → Communication → HART input → Configuration → Failure value
Prerequisite	The following conditions are met: <ul style="list-style-type: none"> ▪ In the Capture mode parameter (→ 107), the Burst network option or Master network option is selected. ▪ In the Failure mode parameter (→ 110), the Defined value option is selected.
Description	Use this function to enter the measured value to be used if no data are recorded within the maximum permitted interval.
User entry	Signed floating-point number
Factory setting	0

"Input" submenu

Navigation Expert → Communication → HART input → Input



Value

Navigation	Expert → Communication → HART input → Input → Value
Description	Displays the value of the device variable recorded by the HART input.
User interface	Signed floating-point number


Status





Navigation	Expert → Communication → HART input → Input → Status
Description	Displays the value of the device variable recorded by the HART input in accordance with the HART specification.

User interface


- Manual/Fixed
- Good
- Poor accuracy
- Bad





3.4.2 "HART output" submenu

Navigation  Expert → Communication → HART output


▶ HART output		
▶ Configuration		→  112
▶ Burst configuration		→  114
▶ Information		→  120
▶ Output		→  123

"Configuration" submenu

Navigation  Expert → Communication → HART output → Configuration

▶ Configuration		
HART short tag		→  112
Device tag		→  113
HART address		→  113
No. of preambles		→  113

HART short tag**Navigation**

 Expert → Communication → HART output → Configuration → HART short tag

Description










Use this function to enter a brief description for the measuring point. This can be edited and displayed via HART protocol or using the local display.

User entry


Max. 8 characters: A-Z, 0-9 and certain special characters (e.g. punctuation marks, @, %).















Factory setting

PROMAG


Device tag		
Navigation	  Expert → Communication → HART output → Configuration → Device tag	
Description	Use this function to enter the name for the measuring point.	
User entry	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).	
Factory setting	Promag	
HART address		
Navigation	  Expert → Communication → HART output → Configuration → HART address	
Description	Use this function to enter the address via which the data exchange takes place via HART protocol.	
User entry	0 to 63	
Factory setting	0	
No. of preambles		
Navigation	  Expert → Communication → HART output → Configuration → No. of preambles	
Description	Use this function to enter the number of preambles in the HART protocol.	
User entry	2 to 20	
Factory setting	5	
Additional information	<p><i>User entry</i></p> <p>As every modem component can "swallow" a byte, 2-byte preambles at least must be defined.</p>	

"Burst configuration" submenu

Navigation  Expert → Communication → HART output → Burst config.
→ Burst config. 1 to 3

▶ Burst configuration	
▶ Burst configuration 1 to 3	
Burst mode 1 to 3	→  114
Burst command 1 to 3	→  115
Burst variable 0	→  116
Burst variable 1	→  116
Burst variable 2	→  117
Burst variable 3	→  117
Burst variable 4	→  117
Burst variable 5	→  117
Burst variable 6	→  118
Burst variable 7	→  118
Burst trigger mode	→  118
Burst trigger level	→  119
Min. update period	→  119
Max. update period	→  120

Burst mode 1 to 3**Navigation**

 Expert → Communication → HART output → Burst config. → Burst config. 1 to 3
→ Burst mode 1 to 3

Description

Use this function to select whether to activate the HART burst mode for burst message X.

Selection

- Off
- On

Factory setting

Off

Additional information	<i>Options</i> <ul style="list-style-type: none"> ■ Off The measuring device transmits data only when requested by the HART master. ■ On The measuring device transmits data regularly without being requested.
-------------------------------	---

Burst command 1 to 3


Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst command 1 to 3
-------------------	--

Description	Use this function to select the HART command that is sent to the HART master.
--------------------	---

Selection	<ul style="list-style-type: none"> ■ Command 1 ■ Command 2 ■ Command 3 ■ Command 9 ■ Command 33 ■ Command 48
------------------	--

Factory setting	Command 2
------------------------	-----------



Additional information	<i>Selection</i> <ul style="list-style-type: none"> ■ Command 1 Read out the primary variable. ■ Command 2 Read out the current and the main measured value as a percentage. ■ Command 3 Read out the dynamic HART variables and the current. ■ Command 9 Read out the dynamic HART variables including the related status. ■ Command 33 Read out the dynamic HART variables including the related unit. ■ Command 48 Read out the complete device diagnostics. <p><i>"Command 33" option</i></p> <p>The HART device variables are defined via Command 107.</p> <p>The following measured variables (HART device variables) can be read out:</p> <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity ■ Conductivity * ■ Corrected conductivity * ■ Electronic temperature ■ Density ■ Temperature * ■ HART input ■ Totalizer 1...3 ■ Percent Of Range
-------------------------------	--

* Visibility depends on order options or device settings


- Measured current
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)

Commands


 Information about the defined details of the command: HART specifications

 The measured variables (HART device variables) are assigned to the dynamic variables in the **Output** submenu (→  74).

Burst variable 0

Navigation	 Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst variable 0
Description	For HART command 9 and 33: select the HART device variable or the process variable.
Selection	<ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity ■ Conductivity* ■ Corrected conductivity* ■ Electronic temperature ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Density ■ Temperature* ■ HART input ■ Percent Of Range ■ Measured current ■ Primary variable (PV) ■ Secondary variable (SV) ■ Tertiary variable (TV) ■ Quaternary variable (QV) ■ Not used
Factory setting	Volume flow

Burst variable 1



Navigation	 Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst variable 1
Description	For HART command 9 and 33: select the HART device variable or the process variable.

* Visibility depends on order options or device settings

Selection See the **Burst variable 0** parameter (→  116).

Factory setting Not used

Burst variable 2

Navigation   Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst variable 2

Description For HART command 9 and 33: select the HART device variable or the process variable.

Selection See the **Burst variable 0** parameter (→  116).

Factory setting Not used

Burst variable 3



Navigation   Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst variable 3

Description For HART command 9 and 33: select the HART device variable or the process variable.

Selection See the **Burst variable 0** parameter (→  116).

Factory setting Not used

Burst variable 4

Navigation   Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst variable 4

Description For HART command 33: select the HART device variable or the process variable.

Selection See the **Burst variable 0** parameter (→  116).

Factory setting Not used

Burst variable 5

Navigation   Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst variable 5

Description For HART command 33: select the HART device variable or the process variable.

Selection See the **Burst variable 0** parameter (→  116).

Factory setting Not used

Burst variable 6


Navigation   Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst variable 6

Description For HART command 33: select the HART device variable or the process variable.

Selection See the **Burst variable 0** parameter (→  116).

Factory setting Not used

Burst variable 7

Navigation   Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst variable 7

Description For HART command 33: select the HART device variable or the process variable.

Selection See the **Burst variable 0** parameter (→  116).

Factory setting Not used

Burst trigger mode





Navigation   Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Trigger mode

Description Use this function to select the event that triggers burst message X.




Selection

- Continuous
- Window
- Rising
- Falling
- On change



Factory setting Continuous

Additional information	<p><i>Options</i></p> <ul style="list-style-type: none"> ■ Continuous The message is sent continuously, at least at intervals corresponding to the time frame specified in the Burst min period parameter (→  119). ■ Window The message is sent if the specified measured value has changed by the value in the Burst trigger level parameter (→  119). ■ Rising The message is sent if the specified measured value exceeds the value in the Burst trigger level parameter (→  119). ■ Falling The message is sent if the specified measured value drops below the value in the Burst trigger level parameter (→  119). ■ On change The message is sent if a measured value changes in the burst message.
-------------------------------	---



Burst trigger level

Navigation	  Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Trigger level
Description	For entering the burst trigger value.
User entry	Positive floating-point number
Additional information	<p><i>Description</i></p> <p>Together with the option selected in the Burst trigger mode parameter (→  118) the burst trigger value determines the time of burst message X.</p>



Min. update period











Navigation	  Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Min. upd. per.
Description	Use this function to enter the minimum time span between two burst commands of burst message X.
User entry	Positive integer
Factory setting	1 000 ms

Max. update period



Navigation	  Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Max. upd. per.
Description	Use this function to enter the maximum time span between two burst commands of burst message X.
User entry	Positive integer
Factory setting	2 000 ms


"Information" submenu

Navigation   Expert → Communication → HART output → Information



► Information	
Device revision	→  120
Device ID	→  121
Device type	→  121
Manufacturer ID	→  121
HART revision	→  122
HART descriptor	→  122
HART message	→  122
Hardware revision	→  122
Software revision	→  123
HART date code	→  123

Device revision



Navigation	  Expert → Communication → HART output → Information → Device revision
Description	Use this function to view the device revision with which the device is registered with the HART Communication Foundation.

User interface	2-digit hexadecimal number
Factory setting	2
Additional information	<p><i>Description</i></p> <p> The device revision is needed to assign the appropriate device description file (DD) to the device.</p>


Device ID

Navigation	 Expert → Communication → HART output → Information → Device ID
Description	Use this function to view the device ID for identifying the measuring device in a HART network.
User interface	6-digit hexadecimal number
Additional information	<p><i>Description</i></p> <p> In addition to the device type and manufacturer ID, the device ID is part of the unique ID. Each HART device is uniquely identified by the unique device ID.</p>

Device type


Navigation	 Expert → Communication → HART output → Information → Device type
Description	Displays the device type with which the measuring device is registered with the HART Communication Foundation.
User interface	2-digit hexadecimal number
Factory setting	0x3A (for Promag 100)
Additional information	<p><i>Description</i></p> <p> The device type is specified by the manufacturer. It is needed to assign the appropriate device description file (DD) to the device.</p>

Manufacturer ID

Navigation	 Expert → Communication → HART output → Information → Manufacturer ID
Description	Use this function to view the manufacturer ID with which the measuring device is registered with the HART Communication Foundation.
User interface	2-digit hexadecimal number

Factory setting 0x11 (for Endress+Hauser)

HART revision

Navigation  Expert → Communication → HART output → Information → HART revision


Description Use this function to display the HART protocol revision of the measuring device.

User interface 5 to 7

Factory setting 7

HART descriptor



Navigation  Expert → Communication → HART output → Information → HART descriptor

Description Use this function to enter a description for the measuring point. This can be edited and displayed via HART protocol or using the local display.

User entry Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting Promag 100

HART message




Navigation  Expert → Communication → HART output → Information → HART message

Description Use this function to enter a HART message which is sent via the HART protocol when requested by the master.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting Promag 100

Hardware revision


Navigation  Expert → Communication → HART output → Information → Hardware rev.

Description Displays the hardware revision of the measuring device.

User interface 0 to 255


Factory setting 1

Software revision

Navigation	 Expert → Communication → HART output → Information → Software rev.
Description	Displays the software revision of the measuring device.
User interface	0 to 255
Factory setting	2

HART date code











Navigation	 Expert → Communication → HART output → Information → HART date code
Description	Use this function to enter the date information for individual use.
User entry	Date entry format: yyyy-mm-dd
Factory setting	2009-07-20
Additional information	<i>Example</i> Device installation date


"Output" submenu

Navigation  Expert → Communication → HART output → Output





► **Output**

Assign PV	→  124
Primary variable (PV)	→  124
Assign SV	→  124
Secondary variable (SV)	→  125
Assign TV	→  125
Tertiary variable (TV)	→  126
Assign QV	→  126
Quaternary variable (QV)	→  126


Assign PV 

Navigation	 Expert → Communication → HART output → Output → Assign PV
Description	Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).
Selection	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity ■ Conductivity* ■ Corrected conductivity* ■ Temperature* ■ Electronic temperature

Primary variable (PV)

Navigation	 Expert → Communication → HART output → Output → Primary var (PV)
Description	Displays the current measured value of the primary dynamic variable (PV).
User interface	Signed floating-point number
Additional information	<p><i>User interface</i></p> <p>The measured value displayed depends on the process variable selected in the Assign PV parameter (→  124).</p> <p><i>Dependency</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→  42).</p>





Assign SV 

Navigation	 Expert → Communication → HART output → Output → Assign SV
Description	Use this function to select a measured variable (HART device variable) for the secondary dynamic variable (SV).
Selection	<ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity ■ Conductivity* ■ Corrected conductivity*

* Visibility depends on order options or device settings


- Temperature *
- Electronic temperature
- Totalizer 1
- Totalizer 2
- Totalizer 3

Secondary variable (SV)

Navigation	 Expert → Communication → HART output → Output → Second.var(SV)
Description	Displays the current measured value of the secondary dynamic variable (SV).
User interface	Signed floating-point number
Additional information	<p><i>User interface</i></p> <p>The measured value displayed depends on the process variable selected in the Assign SV parameter (→  124).</p> <p><i>Dependency</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→  42).</p>





Assign TV



Navigation	 Expert → Communication → HART output → Output → Assign TV
Description	Use this function to select a measured variable (HART device variable) for the tertiary (third) dynamic variable (TV).
Selection	<ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity ■ Conductivity * ■ Corrected conductivity * ■ Temperature * ■ Electronic temperature ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3


* Visibility depends on order options or device settings

Tertiary variable (TV)



Navigation	 Expert → Communication → HART output → Output → Tertiary var(TV)
Description	Displays the current measured value of the tertiary dynamic variable (TV).
User interface	Signed floating-point number
Additional information	<p><i>User interface</i></p> <p>The measured value displayed depends on the process variable selected in the Assign TV parameter (→  125).</p> <p><i>Dependency</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→  42).</p>

Assign QV





Navigation	 Expert → Communication → HART output → Output → Assign QV
Description	Use this function to select a measured variable (HART device variable) for the quaternary (fourth) dynamic variable (QV).
Selection	<ul style="list-style-type: none"> ▪ Volume flow ▪ Mass flow ▪ Corrected volume flow ▪ Flow velocity ▪ Conductivity[*] ▪ Corrected conductivity[*] ▪ Temperature[*] ▪ Electronic temperature ▪ Totalizer 1 ▪ Totalizer 2 ▪ Totalizer 3

Quaternary variable (QV)



Navigation	 Expert → Communication → HART output → Output → Quaterna.var(QV)
Description	Displays the current measured value of the quaternary dynamic variable (QV).
User interface	Signed floating-point number
Additional information	<p><i>User interface</i></p> <p>The measured value displayed depends on the process variable selected in the Assign QV parameter (→  126).</p>







* Visibility depends on order options or device settings

Dependency



 The unit of the displayed measured value is taken from the **System units** submenu (→  42).

3.4.3 "Web server" submenu

Navigation   Expert → Communication → Web server

► Web server	
Web server language	→  127
MAC address	→  128
IP address	→  128
Subnet mask	→  128
Default gateway	→  129
Web server functionality	→  129

Web server language**Navigation**

  Expert → Communication → Web server → Webserv.language

Description

Use this function to select the web server language setting.

Selection


- English
- Deutsch *
- Français *
- Español *
- Italiano *
- Nederlands *
- Portuguesa *
- Polski *
- русский язык (Russian) *
- Svenska *
- Türkçe *
- 中文 (Chinese) *
- 日本語 (Japanese) *
- 한국어 (Korean) *
- العربية (Arabic) *
- Bahasa Indonesia *

* Visibility depends on order options or device settings

- ภาษาไทย (Thai) *
- tiếng Việt (Vietnamese) *
- čeština (Czech) *

Factory setting English

MAC address

Navigation  Expert → Communication → Web server → MAC Address


Description Displays the MAC ¹⁾ address of the measuring device.

User interface Unique 12-digit character string comprising letters and numbers

Factory setting Each measuring device is given an individual address.

Additional information *Example*
For the display format
00:07:05:10:01:5F

IP address


Navigation  Expert → Communication → Web server → IP address

Description Displays the IP address of the Web server of the measuring device.

User interface 4 octet: 0 to 255 (in the particular octet)

Factory setting 192.168.1.212

Subnet mask

Navigation  Expert → Communication → Web server → Subnet mask

Description Displays the subnet mask.

User interface 4 octet: 0 to 255 (in the particular octet)

Factory setting 255.255.255.0

* Visibility depends on order options or device settings

1) Media Access Control

Default gateway




Navigation	Expert → Communication → Web server → Default gateway
Description	Displays the default gateway.
User interface	4 octet: 0 to 255 (in the particular octet)
Factory setting	0.0.0.0


Web server functionality




Navigation	Expert → Communication → Web server → Webserver funct.
Description	Use this function to switch the Web server on and off.
Selection	<ul style="list-style-type: none"> ■ Off ■ On
Factory setting	On
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Off <ul style="list-style-type: none"> – The Web server is completely disabled. – Port 80 is blocked. ■ On <ul style="list-style-type: none"> – The complete Web server functionality is available. – JavaScript is used. – The password is transmitted as an encrypted password. – Any change to the password is also transmitted in encrypted format.












3.4.4 "Diagnostic configuration" submenu


 For a list of all the diagnostic events, see the Operating Instructions for the device.





 Assign a category to the particular diagnostic event:


- **Failure (F)** option
A device error has occurred. The measured value is no longer valid.
- **Function check (C)** option
The device is in service mode (e.g. during a simulation).
- **Out of specification (S)** option
The device is being operated:
 - Outside its technical specification limits (e.g. outside the process temperature range)
 - Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)
- **Maintenance required (M)** option
Maintenance is required. The measured value is still valid.
- **No effect (N)** option
Has no effect on the condensed status.





Navigation  Expert → Communication → Diag. config.


► Diagnostic configuration	
Event category 004	→  131
Event category 441	→  131
Event category 442	→  131
Event category 443	→  132
Event category 531	→  132
Event category 832	→  132
Event category 833	→  133
Event category 834	→  133
Event category 835	→  134
Event category 862	→  134
Event category 937	→  134



Event category 004 (Sensor)


Navigation	  Expert → Communication → Diag. config. → Event category 004
Description	Use this function to select the category assigned to diagnostic message 004 Sensor .
Selection	<ul style="list-style-type: none"> ■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ No effect (N)
Factory setting	Out of specification (S)
Additional information	 For a detailed description of the options available for selection: →  130


Event category 441 (Current output 1)


Navigation	  Expert → Communication → Diag. config. → Event category 441
Description	Use this function to select the category assigned to diagnostic message 441 Current output 1 .
Selection	<ul style="list-style-type: none"> ■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ No effect (N)
Factory setting	Out of specification (S)
Additional information	 For a detailed description of the options available for selection: →  130

Event category 442 (Frequency output)


Navigation	  Expert → Communication → Diag. config. → Event category 442
Prerequisite	The pulse/frequency/switch output is available.
Description	Use this function to select the category assigned to diagnostic message 442 Frequency output .
Selection	<ul style="list-style-type: none"> ■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ No effect (N)

Factory setting Out of specification (S)

Additional information  For a detailed description of the options available for selection: →  130

Event category 443 (Pulse output)

Navigation   Expert → Communication → Diag. config. → Event category 443

Prerequisite The pulse/frequency/switch output is available.

Description Use this function to select the category assigned to diagnostic message **443 Pulse output**.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional information  For a detailed description of the options available for selection: →  130

Event category 531 (Empty pipe detection)

Navigation   Expert → Communication → Diag. config. → Event category 531

Description Use this function to select the category assigned to diagnostic message **531 Empty pipe detection**.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional information  For a detailed description of the options available for selection: →  130



Event category 832 (Electronic temperature too high)

Navigation   Expert → Communication → Diag. config. → Event category 832

Description Use this function to select the category assigned to diagnostic message **832 Electronic temperature too high**.

- Selection**
- Failure (F)
 - Function check (C)
 - Out of specification (S)
 - Maintenance required (M)
 - No effect (N)

Factory setting Out of specification (S)

Additional information  For a detailed description of the options available for selection: →  130

Event category 833 (Electronic temperature too low)

Navigation   Expert → Communication → Diag. config. → Event category 833


Description Use this function to select the category assigned to diagnostic message **833 Electronic temperature too low**.

- Selection**
- Failure (F)
 - Function check (C)
 - Out of specification (S)
 - Maintenance required (M)
 - No effect (N)

Factory setting Out of specification (S)

Additional information  For a detailed description of the options available for selection: →  130


Event category 834 (Process temperature too high)

Navigation   Expert → Communication → Diag. config. → Event category 834

Description Use this function to select a category for the diagnostic message **834 Process temperature too high**.

- Selection**
- Failure (F)
 - Function check (C)
 - Out of specification (S)
 - Maintenance required (M)
 - No effect (N)

Factory setting Out of specification (S)

Additional information  For a detailed description of the options available for selection: →  130

Event category 835 (Process temperature too low)



Navigation	Expert → Communication → Diag. config. → Event category 835
Description	Use this function to select a category for the diagnostic message 835 Process temperature too low .
Selection	<ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ No effect (N)
Factory setting	Out of specification (S)
Additional information	For a detailed description of the options available for selection: → 130

Event category 862 (Empty pipe)



Navigation	Expert → Communication → Diag. config. → Event category 862
Description	Use this function to select the category assigned to diagnostic message 862 Empty pipe .
Selection	<ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ No effect (N)
Factory setting	Out of specification (S)
Additional information	For a detailed description of the options available for selection: → 130

Event category 937 (EMC interference)




Navigation	Expert → Communication → Diag. config. → Event category 937
Description	Use this function to select the category assigned to diagnostic message 937 EMC interference .
Selection	<ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ No effect (N)
Factory setting	Out of specification (S)

Additional information

For a detailed description of the options available for selection: → 130

3.5 "Application" submenu

Navigation Expert → Application

Reset all totalizers

Navigation

Expert → Application → Reset all tot.

DescriptionUse this function to reset all totalizers to the value **0** and restart the totaling process. This deletes all the flow values previously totalized.**Selection**

- Cancel
- Reset + totalize


Factory setting




Cancel

Additional information*Selection*

- Cancel
No action is executed and the user exits the parameter.
- Reset + totalize
All totalizers are reset to 0 and the totaling process is restarted.

3.5.1 "Totalizer 1 to 3" submenu

Navigation Expert → Application → Totalizer 1 to 3

Control Totalizer 1 to 3	→  138
Preset value 1 to 3	→  139
Failure mode	→  139

Assign process variable

Navigation

  Expert → Application → Totalizer 1 to 3 → Assign variable

Description

Use this function to select a process variable for the Totalizer 1 to 3.

Selection


- Off
- Volume flow
- Mass flow
- Corrected volume flow

Factory setting


Volume flow

Additional information

Description



 If the option selected is changed, the device resets the totalizer to 0.

Selection


If the **Off** option is selected, only **Assign process variable** parameter (→  136) is still displayed in the **Totalizer 1 to 3** submenu. All other parameters in the submenu are hidden.

Unit totalizer

Navigation

  Expert → Application → Totalizer 1 to 3 → Unit totalizer

Prerequisite

One of the following options is selected in the **Assign process variable** parameter (→  136) of the **Totalizer 1 to 3** submenu:

- Volume flow
- Mass flow
- Corrected volume flow

Description

Use this function to select the unit for the process variable of totalizer 1-3.

Selection

SI units

- g
- kg
- t

US units

- oz
- lb
- STon

Custom-specific units

User mass

or

SI units

- cm³
- dm³
- m³
- ml
- l
- hl
- Ml Mega

US units

- af
- ft³
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;oil)
- bbl (us;tank)

Imperial units

- gal (imp)
- Mgal (imp)
- bbl (imp;beer)
- bbl (imp;oil)

Custom-specific units

User vol.

or

SI units

- NI
- Nm³
- Sm³

US units

- Sft³
- Sgal (us)
- Sbbl (us;liq.)

Imperial units

Sgal (imp)

Custom-specific units

UserCrVol.

Factory setting

Country-specific:

- l
- gal (us)

Additional information

Description



The unit is selected separately for each totalizer. The unit is independent of the option selected in the **System units** submenu (→ 42).

Selection

The selection depends on the process variable selected in the **Assign process variable** parameter (→ 136).

Totalizer operation mode



Navigation

Expert → Application → Totalizer 1 to 3 → Operation mode

Prerequisite

One of the following options is selected in the **Assign process variable** parameter (→ 136) of the **Totalizer 1 to 3** submenu:

- Volume flow
- Mass flow
- Corrected volume flow

Description

Use this function to select how the totalizer summates the flow.

Selection

- Net flow total
- Forward flow total
- Reverse flow total


Factory setting Net flow total

Additional information *Selection*

- Net flow total
Positive and negative flow values are totalized and balanced against one another. Net flow is registered in the flow direction.
- Forward flow total
Only the flow in the forward flow direction is totalized.
- Reverse flow total
Only the flow against the forward flow direction is totalized (= reverse flow total).

Control Totalizer 1 to 3

Navigation  Expert → Application → Totalizer 1 to 3 → Control Tot. 1 to 3

Prerequisite One of the following options is selected in the **Assign process variable** parameter (→  136) of the **Totalizer 1 to 3** submenu:

- Volume flow
- Mass flow
- Corrected volume flow



Description Use this function to select the control of totalizer value 1-3.

Selection





- Totalize
- Reset + hold
- Preset + hold
- Reset + totalize
- Preset + totalize

Factory setting Totalize

Additional information *Selection*




- Totalize
The totalizer is started or continues totalizing with the current counter reading.
- Reset + hold
The totaling process is stopped and the totalizer is reset to 0.
- Preset + hold
The totaling process is stopped and the totalizer is set to its defined start value from the **Preset value** parameter (→  139).
- Reset + totalize
The totalizer is reset to 0 and the totaling process is restarted.
- Preset + totalize
The totalizer is set to the defined start value in the **Preset value** parameter (→  139) and the totaling process is restarted.

Preset value 1 to 3

Navigation	 Expert → Application → Totalizer 1 to 3 → Preset value 1 to 3
Prerequisite	One of the following options is selected in the Assign process variable parameter (→  136) of the Totalizer 1 to 3 submenu: <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow
Description	Use this function to enter a start value for totalizer 1-3.
User entry	Signed floating-point number
Factory setting	0 1
Additional information	<p><i>User entry</i></p> <p> The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→  136).</p> <p><i>Example</i></p> <p>This configuration is suitable for applications such as iterative filling processes with a fixed batch quantity.</p>

Failure mode













Navigation	 Expert → Application → Totalizer 1 to 3 → Failure mode
Prerequisite	One of the following options is selected in the Assign process variable parameter (→  136) of the Totalizer 1 to 3 submenu: <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow
Description	Use this function to select how a totalizer behaves in the event of a device alarm.
Selection	<ul style="list-style-type: none"> ■ Stop ■ Actual value ■ Last valid value
Factory setting	Stop
Additional information	<p><i>Description</i></p> <p> This setting does not affect the failsafe mode of other totalizers and the outputs. This is specified in separate parameters.</p>

Selection

- Stop
Totalizing is stopped when a device alarm occurs.
- Actual value
The totalizer continues to count based on the current measured value; the device alarm is ignored.
- Last valid value
The totalizer continues to count based on the last valid measured value before the device alarm occurred.

3.6 "Diagnostics" submenu

Navigation  Expert → Diagnostics






▶ Diagnostics	
Actual diagnostics	→  140
Previous diagnostics	→  141
Operating time from restart	→  142
Operating time	→  142
▶ Diagnostic list	→  143
▶ Event logbook	→  146
▶ Device information	→  149
▶ Min/max values	→  152
▶ Heartbeat	→  154
▶ Simulation	→  155

Actual diagnostics




Navigation  Expert → Diagnostics → Actual diagnos.

Prerequisite A diagnostic event has occurred.






Description Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.

User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>User interface</i></p> <p> Additional pending diagnostic messages can be displayed in the Diagnostic list submenu (→  143).</p> <p> Information on what is causing the diagnostic message, and remedy measures, can be viewed by pressing the -button.</p> <p><i>Example</i></p> <p>For the display format: F271 Main electronic failure</p>




Timestamp

Navigation	 Expert → Diagnostics → Timestamp
Description	Displays the operating time when the current diagnostic message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>User interface</i></p> <p> The diagnostic message can be displayed via the Actual diagnostics parameter (→  140).</p> <p><i>Example</i></p> <p>For the display format: 24d12h13m00s</p>



Previous diagnostics

Navigation	  Expert → Diagnostics → Prev.diagnostics
Prerequisite	Two diagnostic events have already occurred.
Description	Displays the diagnostic message that occurred before the current message.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>User interface</i></p> <p> Information on what is causing the diagnostic message, and remedy measures, can be viewed by pressing the -button.</p> <p><i>Example</i></p> <p>For the display format: F271 Main electronic failure</p>



Timestamp

Navigation	 Expert → Diagnostics → Timestamp
Description	Displays the operating time when the last diagnostic message before the current message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>User interface</i></p> <p> The diagnostic message can be displayed via the Previous diagnostics parameter (→  141).</p> <p><i>Example</i></p> <p>For the display format: 24d12h13m00s</p>

Operating time from restart


Navigation	  Expert → Diagnostics → Time fr. restart
Description	Use this function to display the time the device has been in operation since the last device restart.
User interface	Days (d), hours (h), minutes (m) and seconds (s)

Operating time




Navigation	  Expert → Diagnostics → Operating time
Description	Use this function to display the length of time the device has been in operation.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>User interface</i></p> <p>The maximum number of days is 9999, which is equivalent to 27 years.</p>

3.6.1 "Diagnostic list" submenu




Navigation  Expert → Diagnostics → Diagnostic list






Diagnostics 1

Navigation	 Expert → Diagnostics → Diagnostic list → Diagnostics 1
Description	Use this function to display the current diagnostics message with the highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>Examples</i></p> <p>For the display format:</p> <ul style="list-style-type: none"> ■  F271 Main electronic failure ■  F276 I/O module failure




Timestamp

Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>User interface</i></p> <p> The diagnostic message can be displayed via the Diagnostics 1 parameter (→  143).</p> <p><i>Example</i></p> <p>For the display format: 24d12h13m00s</p>




Diagnostics 2

Navigation	 Expert → Diagnostics → Diagnostic list → Diagnostics 2
Description	Use this function to display the current diagnostics message with the second-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>Examples</i></p> <p>For the display format:</p> <ul style="list-style-type: none"> ■  F271 Main electronic failure ■  F276 I/O module failure




Timestamp

Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the second-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>User interface</i></p> <p> The diagnostic message can be displayed via the Diagnostics 2 parameter (→  144).</p> <p><i>Example</i></p> <p>For the display format: 24d12h13m00s</p>




Diagnostics 3

Navigation	 Expert → Diagnostics → Diagnostic list → Diagnostics 3
Description	Use this function to display the current diagnostics message with the third-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>Examples</i></p> <p>For the display format:</p> <ul style="list-style-type: none"> ■  F271 Main electronic failure ■  F276 I/O module failure




Timestamp

Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the third-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>User interface</i></p> <p> The diagnostic message can be displayed via the Diagnostics 3 parameter (→  144).</p> <p><i>Example</i></p> <p>For the display format: 24d12h13m00s</p>




Diagnostics 4

Navigation	 Expert → Diagnostics → Diagnostic list → Diagnostics 4
Description	Use this function to display the current diagnostics message with the fourth-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>Examples</i></p> <p>For the display format:</p> <ul style="list-style-type: none"> ■  F271 Main electronic failure ■  F276 I/O module failure




Timestamp

Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the fourth-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>User interface</i></p> <p> The diagnostic message can be displayed via the Diagnostics 4 parameter (→  145).</p> <p><i>Example</i></p> <p>For the display format: 24d12h13m00s</p>

Diagnostics 5


Navigation	 Expert → Diagnostics → Diagnostic list → Diagnostics 5
Description	Use this function to display the current diagnostics message with the fifth-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>Examples</i></p> <p>For the display format:</p> <ul style="list-style-type: none"> ■  F271 Main electronic failure ■  F276 I/O module failure

Timestamp

Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the fifth-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>User interface</i></p> <p> The diagnostic message can be displayed via the Diagnostics 5 parameter (→  146).</p> <p><i>Example</i></p> <p>For the display format: 24d12h13m00s</p>

3.6.2 "Event logbook" submenu

Navigation  Expert → Diagnostics → Event logbook



Filter options



Navigation	Expert → Diagnostics → Event logbook → Filter options
Description	Use this function to select the category whose event messages are displayed in the event list of the local display.
Selection	<ul style="list-style-type: none"> ▪ All ▪ Failure (F) ▪ Function check (C) ▪ Out of specification (S) ▪ Maintenance required (M) ▪ Information (I)
Factory setting	All
Additional information	<p><i>Description</i></p> <p> The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:</p> <ul style="list-style-type: none"> ▪ F = Failure ▪ C = Function Check ▪ S = Out of Specification ▪ M = Maintenance Required


Filter options


Navigation	Expert → Diagnostics → Event logbook → Filter options
Description	Use this function to select the category whose event messages are displayed in the event list of the operating tool.
Selection	<ul style="list-style-type: none"> ▪ All ▪ Failure (F) ▪ Function check (C) ▪ Out of specification (S) ▪ Maintenance required (M) ▪ Information (I)
Factory setting	All
Additional information	<p><i>Description</i></p> <p> The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:</p> <ul style="list-style-type: none"> ▪ F = Failure ▪ C = Function Check ▪ S = Out of Specification ▪ M = Maintenance Required


"Event list" submenu

Navigation  Expert → Diagnostics → Event logbook → Event list

**Event list****Navigation**

 Expert → Diagnostics → Event logbook → Event list

Description

Displays the history of event messages of the category selected in the **Filter options** parameter (→  147).

User interface



- For a "Category I" event message
Information event, short message, symbol for event recording and operating time when error occurred
- For a "Category F, C, S, M" event message (status signal)
Diagnostics code, short message, symbol for event recording and operating time when error occurred

Additional information*Description*

A maximum of 20 event messages are displayed in chronological order.




If the advanced HistoROM function is enabled in the device, the event list can contain up to 100 entries.

The following symbols indicate whether an event has occurred or has ended:

- : Occurrence of the event
- : End of the event

Examples

For the display format:

- I1091 Configuration modified
 24d12h13m00s
-  F271 Main electronic failure
 01d04h12min30s










HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

3.6.3 "Device information" submenu


Navigation  Expert → Diagnostics → Device info

▶ **Device information**

Device tag	→  149
Serial number	→  150
Firmware version	→  150
Device name	→  150
Order code	→  150
Extended order code 1	→  151
Extended order code 2	→  151
Extended order code 3	→  151
ENP version	→  152

Device tag

Navigation

 Expert → Diagnostics → Device info → Device tag

Description

Displays a unique name for the measuring point so it can be identified quickly within the plant. The name is displayed in the header.

User interface


Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

Promag 100

Additional information

User interface






 11 Header text


A0013375

The number of characters displayed depends on the characters used.


Serial number

Navigation	 Expert → Diagnostics → Device info → Serial number
Description	Displays the serial number of the measuring device.  The number can be found on the nameplate of the sensor and transmitter.
User interface	A maximum of 11-digit character string comprising letters and numbers.
Additional information	<i>Description</i>  Uses of the serial number <ul style="list-style-type: none"> ▪ To identify the measuring device quickly, e.g. when contacting Endress+Hauser. ▪ To obtain specific information on the measuring device using the Device Viewer: www.endress.com/deviceviewer

Firmware version


Navigation	 Expert → Diagnostics → Device info → Firmware version
Description	Displays the device firmware version installed.
User interface	Character string in the format xx.yy
Factory setting	01.01

Device name

Navigation	 Expert → Diagnostics → Device info → Device name
Description	Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.
User interface	Promag 100

Order code



Navigation	 Expert → Diagnostics → Device info → Order code
Description	Displays the device order code.
User interface	Character string composed of letters, numbers and certain punctuation marks (e.g. /).

Additional information*Description*

The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.

The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly readable from the order code.

**Uses of the order code**

- To order an identical spare device.
- To identify the device quickly and easily, e.g. when contacting Endress+Hauser.

Extended order code 1**Navigation**

Expert → Diagnostics → Device info → Ext. order cd. 1

Description

Displays the first part of the extended order code.

On account of length restrictions, the extended order code is split into a maximum of 3 parameters.

User interface

Character string

Additional information*Description*

The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.



The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

Extended order code 2**Navigation**

Expert → Diagnostics → Device info → Ext. order cd. 2

Description

For displaying the second part of the extended order code.

User interface

Character string

Additional information

For additional information, see **Extended order code 1** parameter (→ 151)

Extended order code 3**Navigation**


Expert → Diagnostics → Device info → Ext. order cd. 3

Description



For displaying the third part of the extended order code.

User interface

Character string

Additional information For additional information, see **Extended order code 1** parameter (→  151)

ENP version

Navigation   Expert → Diagnostics → Device info → ENP version

Description Displays the version of the electronic nameplate.

User interface Character string


Factory setting 2.02.00

Additional information *Description*



This electronic nameplate stores a data record for device identification that includes more data than the nameplates attached to the outside of the device.

3.6.4 "Min/max values" submenu

Navigation   Expert → Diagnostics → Min/max val.



Reset min/max values


Navigation   Expert → Diagnostics → Min/max val. → Reset min/max

Description Use this function to select measured variables whose minimum, maximum and average measured values are to be reset.



Selection Cancel

Factory setting Cancel




"Main electronic temperature" submenu

Navigation  Expert → Diagnostics → Min/max val. → Main elect.temp.




▶ Main electronic temperature

Minimum value	→  153
Maximum value	→  153

Minimum value


Navigation	 Expert → Diagnostics → Min/max val. → Main elect.temp. → Minimum value
Description	Displays the lowest previously measured temperature value of the main electronics module.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  45)




Maximum value

Navigation	 Expert → Diagnostics → Min/max val. → Main elect.temp. → Maximum value
Description	Displays the highest previously measured temperature value of the main electronics module.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  45)




"Temperature" submenu

Navigation  Expert → Diagnostics → Min/max val. → Temperature


**Minimum value**

Navigation	 Expert → Diagnostics → Min/max val. → Temperature → Minimum value
Prerequisite	For the following order code: "Sensor Option", option CI "Fluid temperature probe"
Description	Displays the lowest previously measured medium temperature value.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  45)

Maximum value

Navigation	 Expert → Diagnostics → Min/max val. → Temperature → Maximum value
Prerequisite	For the following order code: "Sensor Option", option CI "Fluid temperature probe"
Description	Displays the highest previously measured medium temperature value.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  45)

3.6.5 "Heartbeat" submenu

 For detailed information on the parameter descriptions of the **Heartbeat Verification** application package, see the Special Documentation for the device

Navigation  Expert → Diagnostics → Heartbeat














▶ Heartbeat

- ▶ Heartbeat base settings
- ▶ Performing verification
- ▶ Verification results
- ▶ Monitoring results

3.6.6 "Simulation" submenu

Navigation  Expert → Diagnostics → Simulation

▶ Simulation

- Assign simulation process variable →  156
- Value process variable →  156
- Simulation current output 1 →  157
- Value current output 1 →  157
- Frequency simulation 1 →  157
- Frequency value 1 →  158
- Pulse simulation 1 →  158
- Pulse value 1 →  159
- Switch output simulation 1 →  159
- Switch status 1 →  160
- Simulation device alarm →  160
- Diagnostic event category →  160
- Simulation diagnostic event →  161

Assign simulation process variable


Navigation	Expert → Diagnostics → Simulation → Assign proc.var.
Description	Use this function to select a process variable for the simulation process that is activated. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Conductivity[*] ■ Corrected conductivity[*] ■ Temperature[*]
Factory setting	Off
Additional information	<p><i>Description</i></p> <p> The simulation value of the process variable selected is defined in the Value process variable parameter (→ 156).</p>

Value process variable


Navigation	Expert → Diagnostics → Simulation → Value proc. var.
Prerequisite	One of the following options is selected in the Assign simulation process variable parameter (→ 156): <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Conductivity[*] ■ Corrected conductivity[*] ■ Temperature[*]
Description	Use this function to enter a simulation value for the selected process variable. Subsequent measured value processing and the signal output use this simulation value. In this way, users can verify whether the measuring device has been configured correctly.
User entry	Depends on the process variable selected
Factory setting	0
Additional information	<p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 42).</p>

* Visibility depends on order options or device settings

Simulation current output 1


Navigation	Expert → Diagnostics → Simulation → Sim.curr.out. 1
Description	Use this function to switch simulation of the current output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none"> ■ Off ■ On
Factory setting	Off
Additional information	<p><i>Description</i></p> <p> The desired simulation value is specified in the Value current output 1 parameter (→ 157).</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Off Current simulation is switched off. The device is in normal measuring mode or another process variable is being simulated. ■ On Current simulation is active.

Value current output 1




Navigation	Expert → Diagnostics → Simulation → Value curr.out 1
Prerequisite	In the Simulation current output 1 parameter, the On option is selected.
Description	Use this function to enter a current value for the simulation. In this way, users can verify the correct adjustment of the current output and the correct function of downstream switching units.
User entry	0 to 22.5 mA

Frequency simulation 1


Navigation	Expert → Diagnostics → Simulation → Frequency sim. 1
Prerequisite	In the Operating mode parameter (→ 88), the Frequency option is selected.
Description	Use this function to switch simulation of the frequency output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none"> ■ Off ■ On

Factory setting Off



Additional information *Description*


 The desired simulation value is defined in the **Frequency value** parameter (→  158).

Selection

- Off
Frequency simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Frequency simulation is active.

Frequency value 1

Navigation   Expert → Diagnostics → Simulation → Freq. value 1



Prerequisite In the **Frequency simulation** parameter (→  157), the **On** option is selected.


Description Use this function to enter a frequency value for the simulation. In this way, users can verify the correct adjustment of the frequency output and the correct function of downstream switching units.

User entry 0.0 to 12 500.0 Hz

Factory setting 0.0 Hz

Pulse simulation 1

Navigation   Expert → Diagnostics → Simulation → Pulse sim. 1

Prerequisite In the **Operating mode** parameter (→  88), the **Pulse** option is selected.



Description Use this function to switch simulation of the pulse output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection



- Off
- Fixed value
- Down-counting value

Factory setting Off



Additional information *Description*

 The desired simulation value is defined in the **Pulse value** parameter (→  159).


Selection

- Off
Pulse simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- Fixed value
Pulses are continuously output with the pulse width specified in the **Pulse width** parameter (→  90).
- Down-counting value
The pulses specified in the **Pulse value** parameter (→  159) are output.

Pulse value 1**Navigation**

  Expert → Diagnostics → Simulation → Pulse value 1

Prerequisite

In the **Pulse simulation** parameter (→  158), the **Down-counting value** option is selected.



Description

Use this function to enter a pulse value for the simulation. In this way, users can verify the correct adjustment of the pulse output and the correct function of downstream switching units.


User entry

0 to 65 535

Switch output simulation 1**Navigation**

  Expert → Diagnostics → Simulation → Switch sim. 1

Prerequisite

In the **Operating mode** parameter (→  88), the **Switch** option is selected.

Description

Use this function to switch simulation of the switch output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.


Selection

- Off
- On

Factory setting





Off




Additional information*Description*



The desired simulation value is defined in the **Switch status** parameter (→  160).

Selection

- Off
Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Switch simulation is active.


Switch status 1		
Navigation	  Expert → Diagnostics → Simulation → Switch status 1	
Prerequisite	In the Switch output simulation parameter (→  159), the On option is selected.	
Description	Use this function to select a switch value for the simulation. In this way, users can verify the correct adjustment of the switch output and the correct function of downstream switching units.	
Selection	<ul style="list-style-type: none"> ▪ Open ▪ Closed 	
Factory setting	Open	
Additional information	<i>Selection</i> <ul style="list-style-type: none"> ▪ Open Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated. ▪ Closed Switch simulation is active. 	

Simulation device alarm		
Navigation	  Expert → Diagnostics → Simulation → Sim. alarm	
Description	Use this function to switch the device alarm on and off.	
Selection	<ul style="list-style-type: none"> ▪ Off ▪ On 	
Factory setting	Off	
Additional information	<i>Description</i> The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.	

Diagnostic event category	
Navigation	 Expert → Diagnostics → Simulation → Event category
Description	Use this function to select the category of the diagnostic events that are displayed for the simulation in the Simulation diagnostic event parameter (→  161).
Selection	<ul style="list-style-type: none"> ▪ Sensor ▪ Electronics ▪ Configuration ▪ Process

Factory setting Process

Simulation diagnostic event

Navigation  Expert → Diagnostics → Simulation → Sim. diag. event



Description Use this function to select a diagnostic event for the simulation process that is activated.

Selection

- Off
- Diagnostic event picklist (depends on the category selected)

Factory setting Off

Additional information *Description*

 For the simulation, you can choose from the diagnostic events of the category selected in the **Diagnostic event category** parameter (→  160).

4 Country-specific factory settings

4.1 SI units

 Not valid for USA and Canada.

4.1.1 System units

Volume flow	l/h
Volume	m ³
Conductivity	μS/cm
Temperature	°C
Mass flow	kg/h
Mass	kg
Density	kg/l
Corrected volume flow	NI/h
Corrected volume	Nm ³

4.1.2 Full scale values

 The factory settings apply to the following parameters:

- 20 mA value (full scale value of the current output)
- 100% bar graph value 1

Nominal diameter [mm]	(v ~ 2.5 m/s) [dm ³ /min]
2	0.5
4	2
8	8
15	25
25	75
32	125
40	200
50	300
65	500
80	750
100	1200
125	1850
150	150 m ³ /h
200	300 m ³ /h
250	500 m ³ /h
300	750 m ³ /h
350	1000 m ³ /h
400	1200 m ³ /h
450	1500 m ³ /h

Nominal diameter [mm]	($v \sim 2.5$ m/s) [dm ³ /min]
500	2000 m ³ /h
600	2500 m ³ /h


4.1.3 Output current span

Current output 1	4 to 20 mA NAMUR
------------------	------------------

4.1.4 Pulse value

Nominal diameter [mm]	(~ 2 pulse/s) [dm ³]
2	0.005
4	0.025
8	0.1
15	0.2
25	0.5
32	1
40	1.5
50	2.5
65	5
80	5
100	10
125	15
150	0.03 m ³
200	0.05 m ³
250	0.05 m ³
300	0.1 m ³
350	0.1 m ³
400	0.15 m ³
450	0.25 m ³
500	0.25 m ³
600	0.3 m ³

4.1.5 On value low flow cut off

 The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [mm]	($v \sim 0.04$ m/s) [m ³ /h]
2	0.01
4	0.05
8	0.1
15	0.5
25	1

Nominal diameter [mm]	(v ~ 0.04 m/s) [m ³ /h]
32	2
40	3
50	5
65	8
80	12
100	20
125	30
150	2.5
200	5
250	7.5
300	10
350	15
400	20
450	25
500	30
600	40


4.2 US units

 Only valid for USA and Canada.

4.2.1 System units

Volume flow	gal/min (us)
Volume	gal (us)
Temperature	°F
Mass flow	lb/min
Mass	lb
Density	lb/ft ³
Corrected volume flow	Sft ³ /h
Corrected volume	Sft ³

4.2.2 Full scale values

 The factory settings apply to the following parameters:

- 20 mA value (full scale value of the current output)
- 100% bar graph value 1

Nominal diameter [in]	(v ~ 2.5 m/s) [gal/min]
1/12	0.1
1/8	0.5
3/8	2
1/2	6

Nominal diameter [in]	(v ~ 2.5 m/s) [gal/min]
1	18
1½	50
2	75
3	200
4	300
5	450
6	600
8	1200
10	1500
12	2400
14	3600
16	4800
18	6000
20	7500
24	10500


4.2.3 Output current span

Current output 1	4 to 20 mA US
------------------	---------------

4.2.4 Pulse value

Nominal diameter [in]	(~ 2 pulse/s) [gal]
1/12	0.001
1/8	0.005
3/8	0.02
½	0.1
1	0.2
1½	0.5
2	0.5
3	2
4	2
5	5
6	5
8	10
10	15
12	25
14	30
16	50
18	50
20	75
24	100

4.2.5 On value low flow cut off

 The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [in]	(v ~ 0.04 m/s) [gal/min]
1/12	0.002
1/8	0.008
3/8	0.025
1/2	0.15
1	0.25
1 1/2	0.75
2	1.25
3	2.5
4	4
5	7
6	12
8	15
10	30
12	45
14	60
16	60
18	90
20	120
24	180

5 Explanation of abbreviated units

5.1 SI units

Process variable	Units	Explanation
Density	g/cm ³ , g/m ³	Gram/volume unit
	kg/dm ³ , kg/l, kg/m ³	Kilogram/volume unit
	SD4°C, SD15°C, SD20°C	Specific density: The specific density is the ratio of the density of the fluid to the density of water at a water temperature of 4 °C (39 °F), 15 °C (59 °F), 20 °C (68 °F).
	SG4°C, SG15°C, SG20°C	Specific gravity: The specific gravity is the ratio of the density of the fluid to the density of water at a water temperature of 4 °C (39 °F), 15 °C (59 °F), 20 °C (68 °F).
Conductivity	µS/mm	Microsiemens/length unit
	nS/cm, µS/cm, mS/cm, S/cm	Nano- Micro- , Milli- , Siemens/length unit
	µS/m, mS/m, S/m, kS/m, MS/m	Micro- , Milli- , Siemens, Kilo-, Megasiemens/length unit
Mass	g, kg, t	Gram, kilogram, metric ton
Mass flow	g/s, g/min, g/h, g/d	Gram/time unit
	kg/s, kg/min, kg/h, kg/d	Kilogram/time unit
	t/s, t/min, t/h, t/d	Metric ton/time unit
Corrected volume	Nl, Nm ³ , Sm ³	Normal liter, normal cubic meter, standard cubic meter
Corrected volume flow	Nl/s, Nl/min, Nl/h, Nl/d	Normal liter/time unit
	Nm ³ /s, Nm ³ /min, Nm ³ /h, Nm ³ /d	Normal cubic meter/time unit
	Sm ³ /s, Sm ³ /min, Sm ³ /h, Sm ³ /d	Standard cubic meter/time unit
Temperature	°C , K	Celsius, Kelvin
Volume	cm ³ , dm ³ , m ³	Cubic centimeter, cubic decimeter, cubic meter
	ml, l, hl, Ml Mega	Milliliter, liter, hectoliter, megaliter
Volume flow	cm ³ /s, cm ³ /min, cm ³ /h, cm ³ /d	Cubic centimeter/time unit
	dm ³ /s, dm ³ /min, dm ³ /h, dm ³ /d	Cubic decimeter/time unit
	m ³ /s, m ³ /min, m ³ /h, m ³ /d	Cubic meter/time unit
	ml/s, ml/min, ml/h, ml/d	Milliliter/time unit
	l/s, l/min, l/h, l/d	Liter/time unit
	hl/s, hl/min, hl/h, hl/d	Hectoliter/time unit
	Ml/s, Ml/min, Ml/h, Ml/d	Megaliter/time unit
Time	s, m, h, d, y	Second, minute, hour, day, year

5.2 US units

Process variable	Units	Explanation
Density	lb/ft ³ , lb/gal (us)	Pound/cubic foot, pound/gallon
	lb/bbl (us;liq.), lb/bbl (us;beer), lb/bbl (us;oil), lb/bbl (us;tank)	Pound/volume unit
Mass	oz, lb, STon	Ounce, pound, standard ton
Mass flow	oz/s, oz/min, oz/h, oz/d	Ounce/time unit

Process variable	Units	Explanation
	lb/s, lb/min, lb/h, lb/d	Pound/time unit
	STon/s, STon/min, STon/h, STon/d	Standard ton/time unit
Corrected volume	Sft ³ , Sgal (us), Sbbbl (us;liq.)	Standard cubic foot, standard gallon, standard barrel
Corrected volume flow	Sft ³ /s, Sft ³ /min, Sft ³ /h, Sft ³ /d	Standard cubic foot/time unit
	Sgal/s (us), Sgal/min (us), Sgal/h (us), Sgal/d (us)	Standard gallon/time unit
	Sbbbl/s (us;liq.), Sbbbl/min (us;liq.), Sbbbl/h (us;liq.), Sbbbl/d (us;liq.)	Barrel/time unit (normal liquids)
Temperature	°F, °R	Fahrenheit, Rankine
Volume	af	Acre foot
	ft ³	Cubic foot
	fl oz (us), gal (us), kgal (us), Mgal (us)	Fluid ounce, gallon, kilogallon, million gallon
	bbbl (us;liq.), bbl (us;beer), bbl (us;oil), bbl (us;tank)	Barrel (normal liquids), barrel (beer), barrel (petrochemicals), barrel (filling tanks)
Volume flow	af/s, af/min, af/h, af/d	Acre foot/time unit
	ft ³ /s, ft ³ /min, ft ³ /h, ft ³ /d	Cubic foot/time unit
	fl oz/s (us), fl oz/min (us), fl oz/h (us), fl oz/d (us)	Fluid ounce/time unit
	gal/s (us), gal/min (us), gal/h (us), gal/d (us)	Gallon/time unit
	kgal/s (us), kgal/min (us), kgal/h (us), kgal/d (us)	Kilogallon/time unit
	Mgal/s (us), Mgal/min (us), Mgal/h (us), Mgal/d (us)	Million gallon/time unit
	bbbl/s (us;liq.), bbl/min (us;liq.), bbl/h (us;liq.), bbl/d (us;liq.)	Barrel/time unit (normal liquids) Normal liquids: 31.5 gal/bbl
	bbbl/s (us;beer), bbl/min (us;beer), bbl/h (us;beer), bbl/d (us;beer)	Barrel /time unit (beer) Beer: 31.0 gal/bbl
	bbbl/s (us;oil), bbl/min (us;oil), bbl/h (us;oil), bbl/d (us;oil)	Barrel/time unit (petrochemicals) Petrochemicals: 42.0 gal/bbl
	bbbl/s (us;tank), bbl/min (us;tank), bbl/h (us;tank), bbl/d (us;tank)	Barrel/time unit (filling tank) Filling tanks: 55.0 gal/bbl
Time	s, m, h, d, y	Second, minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

5.3 Imperial units

Process variable	Units	Explanation
Density	lb/gal (imp), lb/bbl (imp;beer), lb/bbl (imp;oil)	Pound/volume unit
Corrected volume	Sgal (imp)	Standard gallon
Corrected volume flow	Sgal/s (imp), Sgal/min (imp), Sgal/h (imp), Sgal/d (imp)	Standard gallon/time unit
Volume	gal (imp), Mgal (imp)	Gallon, mega gallon
	bbbl (imp;beer), bbl (imp;oil)	Barrel (beer), barrel (petrochemicals)

Process variable	Units	Explanation
Volume flow	gal/s (imp), gal/min (imp), gal/h (imp), gal/d (imp)	Gallon/time unit
	Mgal/s (imp), Mgal/min (imp), Mgal/h (imp), Mgal/d (imp)	Mega gallon/time unit
	bbbl/s (imp;beer), bbl/min (imp;beer), bbl/h (imp;beer), bbl/d (imp;beer)	Barrel /time unit (beer) Beer: 36.0 gal/bbl
	bbbl/s (imp;oil), bbl/min (imp;oil), bbl/h (imp;oil), bbl/d (imp;oil)	Barrel/time unit (petrochemicals) Petrochemicals: 34.97 gal/bbl
Time	s, m, h, d, y	Second, minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

Index

- 0 ... 9**
- 0/4 mA value (Parameter) 77
 - 0% bargraph value 1 (Parameter) 17
 - 0% bargraph value 3 (Parameter) 20
 - 20 mA value (Parameter) 78
 - 100% bargraph value 1 (Parameter) 18
 - 100% bargraph value 3 (Parameter) 20
- A**
- Access status display (Parameter) 11, 25
 - Access status tooling (Parameter) 12
 - Activate SW option (Parameter) 28
 - Actual diagnostics (Parameter) 140
 - Administration (Submenu) 26
 - Alarm delay (Parameter) 30
 - Application (Submenu) 135
 - Assign behavior of diagnostic no. 302 (Parameter) . . . 35
 - Assign behavior of diagnostic no. 441 (Parameter) . . . 31
 - Assign behavior of diagnostic no. 442 (Parameter) . . . 31
 - Assign behavior of diagnostic no. 443 (Parameter) . . . 32
 - Assign behavior of diagnostic no. 531 (Parameter) . . . 32
 - Assign behavior of diagnostic no. 832 (Parameter) . . . 33
 - Assign behavior of diagnostic no. 833 (Parameter) . . . 33
 - Assign behavior of diagnostic no. 834 (Parameter) . . . 33
 - Assign behavior of diagnostic no. 835 (Parameter) . . . 34
 - Assign behavior of diagnostic no. 862 (Parameter) . . . 34
 - Assign behavior of diagnostic no. 937 (Parameter) . . . 34
 - Assign current output (Parameter) 75
 - Assign diagnostic behavior (Parameter) 100
 - Assign flow direction check (Parameter) 103
 - Assign frequency output (Parameter) 93
 - Assign limit (Parameter) 101
 - Assign process variable (Parameter) 58, 136
 - Assign pulse output (Parameter) 89
 - Assign PV (Parameter) 124
 - Assign QV (Parameter) 126
 - Assign simulation process variable (Parameter) 156
 - Assign status (Parameter) 104
 - Assign SV (Parameter) 124
 - Assign TV (Parameter) 125
- B**
- Backlight (Parameter) 25
 - Burst command (Parameter) 109
 - Burst command 1 to 3 (Parameter) 115
 - Burst configuration 1 to 3 (Submenu) 114
 - Burst mode 1 to 3 (Parameter) 114
 - Burst trigger level (Parameter) 119
 - Burst trigger mode (Parameter) 118
 - Burst variable 0 (Parameter) 116
 - Burst variable 1 (Parameter) 116
 - Burst variable 2 (Parameter) 117
 - Burst variable 3 (Parameter) 117
 - Burst variable 4 (Parameter) 117
 - Burst variable 5 (Parameter) 117
 - Burst variable 6 (Parameter) 118
- Burst variable 7 (Parameter) 118**
- C**
- Calibration (Submenu) 72
 - Calibration factor (Parameter) 73
 - Capture mode (Parameter) 107
 - Communication (Submenu) 106
 - Conductivity (Parameter) 37
 - Conductivity calibration factor (Parameter) 74
 - Conductivity damping (Parameter) 56
 - Conductivity factor (Parameter) 71
 - Conductivity measurement (Parameter) 57
 - Conductivity offset (Parameter) 70
 - Conductivity unit (Parameter) 44
 - Configuration (Submenu) 107, 112
 - Confirm access code (Parameter) 27
 - Contrast display (Parameter) 24
 - Control Totalizer 1 to 3 (Parameter) 138
 - Corrected conductivity (Parameter) 38
 - Corrected volume flow (Parameter) 37
 - Corrected volume flow factor (Parameter) 71
 - Corrected volume flow offset (Parameter) 71
 - Corrected volume flow unit (Parameter) 48
 - Corrected volume unit (Parameter) 49
 - Current output 1 (Submenu) 74
 - Current span (Parameter) 75
- D**
- Damping output (Parameter) 83, 97
 - Date/time format (Parameter) 49
 - Decimal places 1 (Parameter) 18
 - Decimal places 2 (Parameter) 19
 - Decimal places 3 (Parameter) 21
 - Decimal places 4 (Parameter) 22
 - Default gateway (Parameter) 129
 - Define access code (Parameter) 26, 27
 - Define access code (Wizard) 26
 - Density unit (Parameter) 47
 - Device ID (Parameter) 108, 121
 - Device information (Submenu) 149
 - Device name (Parameter) 150
 - Device reset (Parameter) 28
 - Device revision (Parameter) 120
 - Device tag (Parameter) 113, 149
 - Device type (Parameter) 108, 121
 - Diagnostic behavior (Submenu) 30
 - Diagnostic configuration (Submenu) 130
 - Diagnostic event category (Parameter) 160
 - Diagnostic handling (Submenu) 29
 - Diagnostic list (Submenu) 143
 - Diagnostics (Submenu) 140
 - Diagnostics 1 (Parameter) 143
 - Diagnostics 2 (Parameter) 144
 - Diagnostics 3 (Parameter) 144
 - Diagnostics 4 (Parameter) 145
 - Diagnostics 5 (Parameter) 146

- Direct access
 - 0/4 mA value
 - Current output 1 77
 - 0% bargraph value 1 17
 - 0% bargraph value 3 20
 - 20 mA value
 - Current output 1 78
 - 100% bargraph value 1 18
 - 100% bargraph value 3 20
 - Access status display 11, 25
 - Access status tooling 12
 - Activate SW option 28
 - Actual diagnostics 140
 - Alarm delay 30
 - Assign behavior of diagnostic no. 302 35
 - Assign behavior of diagnostic no. 441 31
 - Assign behavior of diagnostic no. 442 31
 - Assign behavior of diagnostic no. 443 32
 - Assign behavior of diagnostic no. 531 32
 - Assign behavior of diagnostic no. 832 33
 - Assign behavior of diagnostic no. 833 33
 - Assign behavior of diagnostic no. 834 33
 - Assign behavior of diagnostic no. 835 34
 - Assign behavior of diagnostic no. 862 34
 - Assign behavior of diagnostic no. 937 34
 - Assign current output
 - Current output 1 75
 - Assign diagnostic behavior
 - Pulse/frequency/switch output 1 100
 - Assign flow direction check
 - Pulse/frequency/switch output 1 103
 - Assign frequency output
 - Pulse/frequency/switch output 1 93
 - Assign limit
 - Pulse/frequency/switch output 1 101
 - Assign process variable 58
 - Totalizer 1 to 3 136
 - Assign pulse output
 - Pulse/frequency/switch output 1 89
 - Assign PV 124
 - Assign QV 126
 - Assign simulation process variable 156
 - Assign status
 - Pulse/frequency/switch output 1 104
 - Assign SV 124
 - Assign TV 125
 - Backlight 25
 - Burst command 109
 - Burst command 1 to 3 115
 - Burst mode 1 to 3 114
 - Burst trigger level
 - Burst configuration 1 to 3 119
 - Burst trigger mode
 - Burst configuration 1 to 3 118
 - Burst variable 0
 - Burst configuration 1 to 3 116
 - Burst variable 1
 - Burst configuration 1 to 3 116
 - Burst variable 2
 - Burst configuration 1 to 3 117
 - Burst variable 3
 - Burst configuration 1 to 3 117
 - Burst variable 4
 - Burst configuration 1 to 3 117
 - Burst variable 5
 - Burst configuration 1 to 3 117
 - Burst variable 6
 - Burst configuration 1 to 3 118
 - Burst variable 7
 - Burst configuration 1 to 3 118
 - Calibration factor 73
 - Capture mode 107
 - Conductivity 37
 - Conductivity calibration factor 74
 - Conductivity damping 56
 - Conductivity factor 71
 - Conductivity measurement 57
 - Conductivity offset 70
 - Conductivity unit 44
 - Contrast display 24
 - Control Totalizer 1 to 3 138
 - Corrected conductivity 38
 - Corrected volume flow 37
 - Corrected volume flow factor 71
 - Corrected volume flow offset 71
 - Corrected volume flow unit 48
 - Corrected volume unit 49
 - Current span
 - Current output 1 75
 - Damping output
 - Current output 1 83
 - Pulse/frequency/switch output 1 97
 - Date/time format 49
 - Decimal places 1 18
 - Decimal places 2 19
 - Decimal places 3 21
 - Decimal places 4 22
 - Default gateway 129
 - Define access code 27
 - Density unit 47
 - Device ID 108, 121
 - Device name 150
 - Device reset 28
 - Device revision 120
 - Device tag 113, 149
 - Device type 108, 121
 - Diagnostic event category 160
 - Diagnostics 1 143
 - Diagnostics 2 144
 - Diagnostics 3 144
 - Diagnostics 4 145
 - Diagnostics 5 146
 - Direct access 10
 - Display damping 23
 - Display interval 22
 - Display language 14
 - ECC cleaning cycle 65

ECC duration	64
ECC Polarity	65
ECC recovery time	64
Electrode cleaning circuit	64
Empty pipe adjust value	63
Empty pipe detection	61
ENP version	152
Enter access code	13
Event category 004	131
Event category 441	131
Event category 442	131
Event category 443	132
Event category 531	132
Event category 832	132
Event category 833	133
Event category 834	133
Event category 835	134
Event category 862	134
Event category 937	134
Extended order code 1	151
Extended order code 2	151
Extended order code 3	151
External density	66
External temperature	66
External value	66
Failure current	
Current output 1	86
Failure frequency	
Pulse/frequency/switch output 1	99
Failure mode	110
Current output 1	85
Pulse/frequency/switch output 1	92, 98, 105
Totalizer 1 to 3	139
Failure value	111
Filter options	54, 147
Firmware version	150
Fixed current	
Current output 1	76
Fixed density	66
Flow damping	55
Flow override	56
Format display	15
Frequency simulation 1	157
Frequency value 1	158
Full pipe adjust value	63
Hardware revision	122
HART address	113
HART date code	123
HART descriptor	122
HART message	122
HART revision	122
HART short tag	112
Header	23
Header text	24
Installation direction	68
Integration time	68
Invert output signal	
Pulse/frequency/switch output 1	105
IP address	128
Locking status	11
MAC address	128
Manufacturer ID	108, 121
Mass flow	36
Mass flow factor	70
Mass flow offset	70
Mass flow unit	46
Mass unit	46
Max. update period	
Burst configuration 1 to 3	120
Maximum frequency value	
Pulse/frequency/switch output 1	94
Maximum value	153, 154
Measured current 1	40, 86
Measured value EPD	63
Measuring mode	
Current output 1	79
Pulse/frequency/switch output 1	91, 96
Measuring period	68
Measuring value at maximum frequency	
Pulse/frequency/switch output 1	95
Measuring value at minimum frequency	
Pulse/frequency/switch output 1	95
Min. update period	
Burst configuration 1 to 3	119
Minimum frequency value	
Pulse/frequency/switch output 1	94
Minimum value	153, 154
New adjustment	62
No. of preambles	113
Nominal diameter	73
Off value low flow cutoff	59
On value low flow cutoff	58
Operating mode	
Pulse/frequency/switch output 1	88
Operating time	142
Operating time from restart	142
Order code	150
Output current 1	40, 86
Output frequency 1	41, 99
Preset value 1 to 3	139
Pressure shock suppression	59
Previous diagnostics	141
Primary variable (PV)	124
Progress	62
Pulse output 1	41, 93
Pulse simulation 1	158
Pulse value 1	159
Pulse width	
Pulse/frequency/switch output 1	90
Quaternary variable (QV)	126
Reference density	67
Reset all totalizers	135
Reset min/max values	152
Response time	
Current output 1	84
Pulse/frequency/switch output 1	97
Response time empty pipe detection	62
Secondary variable (SV)	125

- Separator 24
 - Serial number 150
 - Simulation current output 1 157
 - Simulation device alarm 160
 - Simulation diagnostic event 161
 - Slot number 109
 - Software option overview 29
 - Software revision 123
 - Status 111
 - Subnet mask 128
 - Switch output function
 - Pulse/frequency/switch output 1 99
 - Switch output simulation 1 159
 - Switch point empty pipe detection 61
 - Switch status 1 42, 105, 160
 - Switch-off delay
 - Pulse/frequency/switch output 1 104
 - Switch-off value
 - Pulse/frequency/switch output 1 103
 - Switch-on delay
 - Pulse/frequency/switch output 1 104
 - Switch-on value
 - Pulse/frequency/switch output 1 102
 - Temperature 37
 - Temperature damping 57
 - Temperature factor 72
 - Temperature offset 72
 - Temperature unit 45
 - Tertiary variable (TV) 126
 - Timeout 110
 - Timestamp 141, 142, 143, 144, 145, 146
 - Totalizer operation mode
 - Totalizer 1 to 3 137
 - Totalizer overflow 1 to 3 39
 - Totalizer value 1 to 3 38
 - Unit totalizer
 - Totalizer 1 to 3 136
 - User corrected volume factor 53
 - User corrected volume offset 53
 - User corrected volume text 52
 - User mass factor 52
 - User mass offset 52
 - User mass text 51
 - User volume factor 51
 - User volume offset 51
 - User volume text 50
 - Value 111
 - Value 1 display 16
 - Value 2 display 18
 - Value 3 display 19
 - Value 4 display 21
 - Value current output 1 157
 - Value per pulse
 - Pulse/frequency/switch output 1 90
 - Value process variable 156
 - Volume flow 36
 - Volume flow factor 69
 - Volume flow offset 69
 - Volume flow unit 43
 - Volume unit 44
 - Web server functionality 129
 - Web server language 127
 - Zero point 73
 - Direct access (Parameter) 10
 - Display (Submenu) 13
 - Display damping (Parameter) 23
 - Display interval (Parameter) 22
 - Display language (Parameter) 14
 - Document
 - Explanation of the structure of a parameter description 6
 - Function 4
 - Structure 4
 - Symbols used 6
 - Target group 4
 - Using the document 4
 - Document function 4
- E**
- ECC cleaning cycle (Parameter) 65
 - ECC duration (Parameter) 64
 - ECC Polarity (Parameter) 65
 - ECC recovery time (Parameter) 64
 - Electrode cleaning circuit (Parameter) 64
 - Electrode cleaning circuit (Submenu) 63
 - Empty pipe adjust value (Parameter) 63
 - Empty pipe detection (Parameter) 61
 - Empty pipe detection (Submenu) 61
 - ENP version (Parameter) 152
 - Enter access code (Parameter) 13
 - Event category 004 (Parameter) 131
 - Event category 441 (Parameter) 131
 - Event category 442 (Parameter) 131
 - Event category 443 (Parameter) 132
 - Event category 531 (Parameter) 132
 - Event category 832 (Parameter) 132
 - Event category 833 (Parameter) 133
 - Event category 834 (Parameter) 133
 - Event category 835 (Parameter) 134
 - Event category 862 (Parameter) 134
 - Event category 937 (Parameter) 134
 - Event list (Submenu) 148
 - Event logbook (Submenu) 146
 - Extended order code 1 (Parameter) 151
 - Extended order code 2 (Parameter) 151
 - Extended order code 3 (Parameter) 151
 - External compensation (Submenu) 65
 - External density (Parameter) 66
 - External temperature (Parameter) 66
 - External value (Parameter) 66
- F**
- Factory settings 162
 - SI units 162
 - US units 164
 - Failure current (Parameter) 86
 - Failure frequency (Parameter) 99
 - Failure mode (Parameter) 85, 92, 98, 105, 110, 139

Failure value (Parameter)	111
Filter options (Parameter)	54, 147
Firmware version (Parameter)	150
Fixed current (Parameter)	76
Fixed density (Parameter)	66
Flow damping (Parameter)	55
Flow override (Parameter)	56
Format display (Parameter)	15
Frequency simulation 1 (Parameter)	157
Frequency value 1 (Parameter)	158
Full pipe adjust value (Parameter)	63
Function see Parameter	
H	
Hardware revision (Parameter)	122
HART address (Parameter)	113
HART date code (Parameter)	123
HART descriptor (Parameter)	122
HART input (Submenu)	106
HART message (Parameter)	122
HART output (Submenu)	112
HART revision (Parameter)	122
HART short tag (Parameter)	112
Header (Parameter)	23
Header text (Parameter)	24
Heartbeat (Submenu)	154
I	
Information (Submenu)	120
Input (Submenu)	111
Installation direction (Parameter)	68
Integration time (Parameter)	68
Invert output signal (Parameter)	105
IP address (Parameter)	128
L	
Locking status (Parameter)	11
Low flow cut off (Submenu)	57
M	
MAC address (Parameter)	128
Main electronic temperature (Submenu)	153
Manufacturer ID (Parameter)	108, 121
Mass flow (Parameter)	36
Mass flow factor (Parameter)	70
Mass flow offset (Parameter)	70
Mass flow unit (Parameter)	46
Mass unit (Parameter)	46
Max. update period (Parameter)	120
Maximum frequency value (Parameter)	94
Maximum value (Parameter)	153, 154
Measured current 1 (Parameter)	40, 86
Measured value EPD (Parameter)	63
Measured values (Submenu)	35
Measuring mode (Parameter)	79, 91, 96
Measuring period (Parameter)	68
Measuring value at maximum frequency (Parameter)	95
Measuring value at minimum frequency (Parameter)	95
Min. update period (Parameter)	119

Min/max values (Submenu)	152
Minimum frequency value (Parameter)	94
Minimum value (Parameter)	153, 154

N

New adjustment (Parameter)	62
No. of preambles (Parameter)	113
Nominal diameter (Parameter)	73

O

Off value low flow cutoff (Parameter)	59
On value low flow cutoff (Parameter)	58
Operating mode (Parameter)	88
Operating time (Parameter)	142
Operating time from restart (Parameter)	142
Order code (Parameter)	150
Output (Submenu)	74, 123
Output current 1 (Parameter)	40, 86
Output frequency 1 (Parameter)	41, 99
Output values (Submenu)	40

P

Parameter

Structure of a parameter description	6
Preset value 1 to 3 (Parameter)	139
Pressure shock suppression (Parameter)	59
Previous diagnostics (Parameter)	141
Primary variable (PV) (Parameter)	124
Process parameters (Submenu)	53
Process variable adjustment (Submenu)	68
Process variables (Submenu)	36
Progress (Parameter)	62
Pulse output 1 (Parameter)	41, 93
Pulse simulation 1 (Parameter)	158
Pulse value 1 (Parameter)	159
Pulse width (Parameter)	90
Pulse/frequency/switch output (Submenu)	86

Q

Quaternary variable (QV) (Parameter)	126
--	-----

R

Reference density (Parameter)	67
Reset all totalizers (Parameter)	135
Reset min/max values (Parameter)	152
Response time (Parameter)	84, 97
Response time empty pipe detection (Parameter)	62

S

Secondary variable (SV) (Parameter)	125
Sensor (Submenu)	35
Sensor adjustment (Submenu)	67
Separator (Parameter)	24
Serial number (Parameter)	150
Simulation (Submenu)	155
Simulation current output 1 (Parameter)	157
Simulation device alarm (Parameter)	160
Simulation diagnostic event (Parameter)	161
Slot number (Parameter)	109
Software option overview (Parameter)	29

- Software revision (Parameter) 123
 - Status (Parameter) 111
 - Submenu
 - Administration 26
 - Application 135
 - Burst configuration 1 to 3 114
 - Calibration 72
 - Communication 106
 - Configuration 107, 112
 - Current output 1 74
 - Device information 149
 - Diagnostic behavior 30
 - Diagnostic configuration 130
 - Diagnostic handling 29
 - Diagnostic list 143
 - Diagnostics 140
 - Display 13
 - Electrode cleaning circuit 63
 - Empty pipe detection 61
 - Event list 148
 - Event logbook 146
 - External compensation 65
 - HART input 106
 - HART output 112
 - Heartbeat 154
 - Information 120
 - Input 111
 - Low flow cut off 57
 - Main electronic temperature 153
 - Measured values 35
 - Min/max values 152
 - Output 74, 123
 - Output values 40
 - Process parameters 53
 - Process variable adjustment 68
 - Process variables 36
 - Pulse/frequency/switch output 86
 - Sensor 35
 - Sensor adjustment 67
 - Simulation 155
 - System 13
 - System units 42
 - Temperature 154
 - Totalizer 38
 - Totalizer 1 to 3 135
 - User-specific units 50
 - Web server 127
 - Subnet mask (Parameter) 128
 - Switch output function (Parameter) 99
 - Switch output simulation 1 (Parameter) 159
 - Switch point empty pipe detection (Parameter) 61
 - Switch status 1 (Parameter) 42, 105, 160
 - Switch-off delay (Parameter) 104
 - Switch-off value (Parameter) 103
 - Switch-on delay (Parameter) 104
 - Switch-on value (Parameter) 102
 - System (Submenu) 13
 - System units (Submenu) 42
- T**
- Target group 4
 - Temperature (Parameter) 37
 - Temperature (Submenu) 154
 - Temperature damping (Parameter) 57
 - Temperature factor (Parameter) 72
 - Temperature offset (Parameter) 72
 - Temperature unit (Parameter) 45
 - Tertiary variable (TV) (Parameter) 126
 - Timeout (Parameter) 110
 - Timestamp (Parameter) 141, 142, 143, 144, 145, 146
 - Totalizer (Submenu) 38
 - Totalizer 1 to 3 (Submenu) 135
 - Totalizer operation mode (Parameter) 137
 - Totalizer overflow 1 to 3 (Parameter) 39
 - Totalizer value 1 to 3 (Parameter) 38
- U**
- Unit totalizer (Parameter) 136
 - User corrected volume factor (Parameter) 53
 - User corrected volume offset (Parameter) 53
 - User corrected volume text (Parameter) 52
 - User mass factor (Parameter) 52
 - User mass offset (Parameter) 52
 - User mass text (Parameter) 51
 - User volume factor (Parameter) 51
 - User volume offset (Parameter) 51
 - User volume text (Parameter) 50
 - User-specific units (Submenu) 50
- V**
- Value (Parameter) 111
 - Value 1 display (Parameter) 16
 - Value 2 display (Parameter) 18
 - Value 3 display (Parameter) 19
 - Value 4 display (Parameter) 21
 - Value current output 1 (Parameter) 157
 - Value per pulse (Parameter) 90
 - Value process variable (Parameter) 156
 - Volume flow (Parameter) 36
 - Volume flow factor (Parameter) 69
 - Volume flow offset (Parameter) 69
 - Volume flow unit (Parameter) 43
 - Volume unit (Parameter) 44
- W**
- Web server (Submenu) 127
 - Web server functionality (Parameter) 129
 - Web server language (Parameter) 127
 - Wizard
 - Define access code 26
- Z**
- Zero point (Parameter) 73

www.addresses.endress.com
