

Description of Device Parameters

Proline Promag 200

HART

Electromagnetic flowmeter




Table of contents

1	Document information	4		
1.1	Document function	4		
1.2	Target group	4		
1.3	Using this document	4		
1.3.1	Information on the document structure	4		
1.3.2	Structure of a parameter description	6		
1.4	Symbols used	6		
1.4.1	Symbols for certain types of information	6		
1.4.2	Symbols in graphics	7		
2	Overview of the expert operating menu	8		
3	Description of device parameters ...	10		
3.1	"System" submenu	13		
3.1.1	"Display" submenu	13		
3.1.2	"Configuration backup display" submenu	26		
3.1.3	"Diagnostic handling" submenu	29		
3.1.4	"Administration" submenu	35		
3.2	"Sensor" submenu	40		
3.2.1	"Measured values" submenu	40		
3.2.2	"System units" submenu	45		
3.2.3	"Process parameters" submenu	53		
3.2.4	"Calculated values" submenu	61		
3.2.5	"Sensor adjustment" submenu	61		
3.2.6	"Calibration" submenu	64		
3.3	"Output" submenu	65		
3.3.1	"Current output 1" submenu	66		
3.3.2	"Pulse/frequency/switch output" submenu	78		
3.4	"Communication" submenu	89		
3.4.1	"HART output" submenu	89		
3.4.2	"Diagnostic configuration" submenu ..	103		
3.5	"Application" submenu	109		
3.5.1	"Totalizer 1 to 3" submenu	109		
3.6	"Diagnostics" submenu	113		
3.6.1	"Diagnostic list" submenu	116		
3.6.2	"Event logbook" submenu	120		
3.6.3	"Device information" submenu	122		
3.6.4	"Data logging" submenu	126		
3.6.5	"Min/max values" submenu	131		
3.6.6	"Heartbeat" submenu	135		
3.6.7	"Simulation" submenu	136		
4	Country-specific factory settings ..	142		
4.1	SI units	142		
4.1.1	System units	142		
4.1.2	Full scale values	142		
4.1.3	Output current span	142		
4.1.4	On value low flow cut off	142		
4.2	US units	143		
4.2.1	System units	143		
4.2.2	Full scale values	143		
4.2.3	Output current span	144		
4.2.4	On value low flow cut off	144		
5	Explanation of abbreviated units ..	145		
5.1	SI units	145		
5.2	US units	145		
5.3	Imperial units	146		
	Index	147		

1 Document information

1.1 Document function


The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the operating menu.


1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document



1.3.1 Information on the document structure


This document lists the submenus and their parameters according to the structure of the **Expert** menu (→  8).



A0022576-EN

 1 Sample graphic

 For the arrangement of the parameters according to the menu structure of the **Operation** menu, **Setup** menu, **Diagnostics** menu (→  113), along with short descriptions, see the Operating Instructions for the device.






A0022577-EN

2 Sample graphic

 For information about the operating philosophy, see the "Operating philosophy" chapter in the device's Operating Instructions








1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

Complete parameter name	Write-protected parameter = 
Navigation	 Navigation path to the parameter via the local display (direct access code)  Navigation path to the parameter via the operating tool The names of the menus, submenus and parameters are abbreviated to the form in which they appear on the display and in the operating tool.
Prerequisite	The parameter is only available under these specific conditions
Description	Description of the parameter function
Options	List of the individual options for the parameter <ul style="list-style-type: none"> ▪ Option 1 ▪ Option 2
User entry	Input range for the parameter
User interface	User interface value/data for the parameter
Factory setting	Default setting ex works
Additional information	Additional explanations (e.g. in examples): <ul style="list-style-type: none"> ▪ On individual options ▪ On display values/data ▪ On the input range ▪ On the factory setting ▪ On the parameter function

1.4 Symbols used

1.4.1 Symbols for certain types of information

Symbol	Meaning
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Operation via local display
	Operation via operating tool
	Write-protected parameter

1.4.2 Symbols in graphics

Symbol	Meaning	Symbol	Meaning
1, 2, 3 ...	Item numbers	A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections		

2 Overview of the expert operating menu

The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.

Expert		
Direct access (0106)		→ 10
Locking status (0004)		→ 11
Access status display (0091)		→ 11
Enter access code (0092)		→ 12
▶ System		→ 13
▶ Display		→ 13
▶ Configuration backup display		→ 26
▶ Diagnostic handling		→ 29
▶ Administration		→ 35
▶ Sensor		→ 40
▶ Measured values		→ 40
▶ System units		→ 45
▶ Process parameters		→ 53
▶ Calculated values		→ 61
▶ Sensor adjustment		→ 61
▶ Calibration		→ 64
▶ Output		→ 65
▶ Current output 1		→ 66
▶ Pulse/frequency/switch output		→ 78

▶ Communication	→ 89
▶ HART output	→ 89
▶ Diagnostic configuration	→ 103
▶ Application	→ 109
Reset all totalizers (2806)	→ 109
▶ Totalizer 1 to 3	→ 109
▶ Diagnostics	→ 113
Actual diagnostics (0691)	→ 114
Previous diagnostics (0690)	→ 115
Operating time from restart (0653)	→ 116
Operating time (0652)	→ 116
▶ Diagnostic list	→ 116
▶ Event logbook	→ 120
▶ Device information	→ 122
▶ Data logging	→ 126
▶ Min/max values	→ 131
▶ Heartbeat	→ 135
▶ Simulation	→ 136

3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the local display. Specific parameters for the operating tools are included at the appropriate points in the menu structure.

Expert	
Direct access (0106)	→ 10
Locking status (0004)	→ 11
Access status display (0091)	→ 11
Enter access code (0092)	→ 12
▶ System	→ 13
▶ Sensor	→ 40
▶ Output	→ 65
▶ Communication	→ 89
▶ Application	→ 109
▶ Diagnostics	→ 113

Direct access



Navigation

Expert → Direct access (0106)

Description

Input of the access code to enable direct access to the desired parameter via the local display. For this reason, each parameter is assigned a parameter number that appears on the right in the header of the selected parameter in the navigation view.

User entry

0 to 65 535





Additional information

User entry


The direct access code consists of a 4-digit number and the channel number, which identifies the channel of a process variable: e.g. 0914-1









- The leading zeros in the direct access code do not have to be entered.
Example: Input of "914" instead of "0914"
- If no channel number is entered, channel 1 is jumped to automatically.
Example: Input of 0914 → **Assign process variable** parameter
- If a different channel is jumped to: Enter the direct access code with the corresponding channel number.
Example: Input of 0914-3 → **Assign process variable** parameter

Locking status







Navigation	 Expert → Locking status (0004)
Description	Use this function to view the active write protection.
User interface	<ul style="list-style-type: none"> ▪ Hardware locked ▪ SIL locked ▪ Temporarily locked
Additional information	<p><i>User interface</i></p> <p>If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are selected.</p> <p> The -symbol appears in front of parameters that cannot be modified due to write protection.</p> <p><i>"Hardware locked" option (priority 1)</i></p> <p>The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters (e.g. via local display or operating tool).</p> <p> Information on disabling hardware write protection is provided in the "Write protection via the locking DIP switch" section of the Operations Instructions for the device.</p> <p><i>"SIL locked" option (priority 2)</i></p> <p>The SIL mode is enabled. This locks write access to the parameters (e.g. via local display or operating tool).</p> <p><i>"Temporarily locked" option (priority 3)</i></p> <p>Write access to the parameters is temporarily lock due to device-internal processing (e.g. data upload/download, reset). Once the internal processing has been completed, the parameters can be changed once again.</p>

Access status display


Navigation	 Expert → Access stat.disp (0091)
Prerequisite	A local display is provided.
Description	Use this function to view the access authorization to the parameters via the local display.
User interface	<ul style="list-style-type: none"> ▪ Operator ▪ Maintenance
Factory setting	Operator

Additional information	<p><i>Description</i></p> <p>If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.</p> <p> The access authorization can be modified via the Enter access code parameter (→  12).</p> <p> For information on the Enter access code parameter (→  12), see the "Disabling write protection via access code" section of the Operating Instructions for the device</p> <p> If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the Locking status parameter (→  11).</p> <p><i>User interface</i></p> <p> Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.</p>
-------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------


Access status tooling

Navigation	 Expert → Access stat.tool (0005)
Description	Use this function to view the access authorization to the parameters via the operating tool.
User interface	<ul style="list-style-type: none"> ▪ Operator ▪ Maintenance
Factory setting	Maintenance
Additional information	<p><i>Description</i></p> <p> The access authorization can be modified via the Enter access code parameter (→  12).</p> <p> If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the Locking status parameter (→  11).</p> <p><i>User interface</i></p> <p> Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.</p>

Enter access code

Navigation	 Expert → Ent. access code (0092)
Description	Use this function to enter the user-specific release code to remove parameter write protection on the local display.
User entry	0 to 9999





Enter access code

Navigation	 Expert → Ent. access code (0003)
Description	Use this function to enter the user-specific release code to remove parameter write protection in the operating tool.
User entry	0 to 9999
Factory setting	0



3.1 "System" submenu

Navigation   Expert → System








▶ System

- ▶ Display →  13
- ▶ Configuration backup display →  26
- ▶ Diagnostic handling →  29
- ▶ Administration →  35

3.1.1 "Display" submenu


Navigation   Expert → System → Display

▶ Display

- Language (0104) →  14
- Format display (0098) →  15
- Value 1 display (0107) →  16
- 0% bargraph value 1 (0123) →  17
- 100% bargraph value 1 (0125) →  17
- Decimal places 1 (0095) →  18
- Value 2 display (0108) →  18

Decimal places 2 (0117)	→  19
Value 3 display (0110)	→  19
0% bargraph value 3 (0124)	→  20
100% bargraph value 3 (0126)	→  20
Decimal places 3 (0118)	→  20
Value 4 display (0109)	→  21
Decimal places 4 (0119)	→  21
Display interval (0096)	→  22
Display damping (0094)	→  22
Header (0097)	→  23
Header text (0112)	→  23
Separator (0101)	→  24
Contrast display (0105)	→  24
Backlight (0111)	→  25
Access status display (0091)	→  25

Language

Navigation
 Expert → System → Display → Language (0104)
Prerequisite

A local display is provided.

Description

Use this function to select the configured language on the local display.

Selection


- English
- Deutsch *
- Français *
- Español *
- Italiano *
- Nederlands *
- Portuguesa *
- Polski *

* Visibility depends on order options or device settings

- русский язык (Russian) *
- Svenska *
- Türkçe *
- 中文 (Chinese) *
- 日本語 (Japanese) *
- 한국어 (Korean) *
- العربية (Arabic) *
- Bahasa Indonesia *
- ภาษาไทย (Thai) *
- tiếng Việt (Vietnamese) *
- čeština (Czech) *

Factory setting **English** option (alternatively, the ordered language is preset in the device)

Format display

Navigation  Expert → System → Display → Format display (0098)





Prerequisite A local display is provided.

Description Use this function to select how the measured value is shown on the local display.

- Selection**
- 1 value, max. size
 - 1 bargraph + 1 value
 - 2 values
 - 1 value large + 2 values
 - 4 values


Factory setting 1 value, max. size

Additional information *Description*
 The display format (size, bar graph etc.) and number of measured values displayed simultaneously (1 to 4) can be configured. This setting only applies to normal operation.

-  The **Value 1 display** parameter (→  16)...**Value 4 display** parameter (→  21) parameters are used to specify which measured values are shown on the display and in which order.
 - If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured using the **Display interval** parameter (→  22) parameter.


Possible measured values shown on the local display:

"1 value, max. size" option




A0016529

* Visibility depends on order options or device settings


"1 bargraph + 1 value" option

A0016530


"2 values" option

A0016531

3

"1 value large + 2 values" option

A0016532

"4 values" option

A0016533

Value 1 display**Navigation**

Expert → System → Display → Value 1 display (0107)

Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values to be shown on the local display.

Selection

- Volume flow
- Mass flow
- Totalizer 1

- Totalizer 2
- Totalizer 3
- Current output 1

Factory setting

Volume flow

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation.



The **Format display** parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how.

Selection

The unit of the displayed measured value is taken from the **System units** submenu (→ 45).

0% bargraph value 1**Navigation**

Expert → System → Display → 0% bargraph 1 (0123)

Prerequisite

A local display is provided.

Description

Use this function to enter the 0% bar graph value to be shown on the display for the measured value 1.

User entry

Signed floating-point number

Factory setting

0 l/h

Additional information*Description*

The **Format display** parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 45).

100% bargraph value 1**Navigation**

Expert → System → Display → 100% bargraph 1 (0125)

Prerequisite


A local display is provided.

Description



Use this function to enter the 100% bar graph value to be shown on the display for the measured value 1.

User entry



Signed floating-point number

Factory setting Depends on country and nominal diameter →  142



Additional information *Description*


 The **Format display** parameter (→  15) is used to specify that the measured value is to be displayed as a bar graph.

User entry

 The unit of the displayed measured value is taken from the **System units** submenu (→  45).

Decimal places 1

Navigation   Expert → System → Display → Decimal places 1 (0095)

Prerequisite A measured value is specified in the **Value 1 display** parameter (→  16).


Description Use this function to select the number of decimal places for measured value 1.

Selection



- x
- x.X
- x.XX
- x.XXX
- x.XXXX

Factory setting x.xx

Additional information *Description*


 This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 2 display

Navigation   Expert → System → Display → Value 2 display (0108)

Prerequisite A local display is provided.



Description Use this function to select one of the measured values to be shown on the local display.

Selection Picklist see **Value 1 display** parameter (→  16)



Factory setting None


Additional information *Description*

If several measured values are displayed at once, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation.

 The **Format display** parameter (→  15) is used to specify how many measured values are displayed simultaneously and how.

Selection

 The unit of the displayed measured value is taken from the **System units** submenu (→  45).

Decimal places 2 **Navigation**

 Expert → System → Display → Decimal places 2 (0117)

Prerequisite

A measured value is specified in the **Value 2 display** parameter (→  18).

Description

Use this function to select the number of decimal places for measured value 2.


Selection


- x
- x.x
- x.xx
- x.xxx
- x.xxxx

Factory setting

x.xx

Additional information*Description*

 This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 3 display **Navigation**

 Expert → System → Display → Value 3 display (0110)


Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values to be shown on the local display.

Selection



Picklist see **Value 1 display** parameter (→  16)

Factory setting



None








Additional information*Description*









If several measured values are displayed at once, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation.




 The **Format display** parameter (→  15) is used to specify how many measured values are displayed simultaneously and how.


Selection

 The unit of the displayed measured value is taken from the **System units** submenu (→  45).







0% bargraph value 3		
Navigation	 Expert → System → Display → 0% bargraph 3 (0124)	
Prerequisite	An option was selected in the Value 3 display parameter (→  19).	
Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 3.	
User entry	Signed floating-point number	
Factory setting	0	
Additional information	<i>Description</i>	
	 The Format display parameter (→  15) is used to specify that the measured value is to be displayed as a bar graph.	
	<i>User entry</i>	
	 The unit of the displayed measured value is taken from the System units submenu (→  45).	

100% bargraph value 3		
Navigation	 Expert → System → Display → 100% bargraph 3 (0126)	
Prerequisite	An option was selected in the Value 3 display parameter (→  19).	
Description	Use this function to enter the 100% bar graph value to be shown on the display for the measured value 3.	
User entry	Signed floating-point number	
Factory setting	Depends on country and nominal diameter →  142	
Additional information	<i>Description</i>	
	 The Format display parameter (→  15) is used to specify that the measured value is to be displayed as a bar graph.	
	<i>User entry</i>	
	 The unit of the displayed measured value is taken from the System units submenu (→  45).	



Decimal places 3		
Navigation	 Expert → System → Display → Decimal places 3 (0118)	
Prerequisite	A measured value is specified in the Value 3 display parameter (→  19).	


Description	Use this function to select the number of decimal places for measured value 3.
Selection	<ul style="list-style-type: none"> ■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx
Factory setting	x.xx
Additional information	<p><i>Description</i></p> <p> This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.</p>

Value 4 display






Navigation	 Expert → System → Display → Value 4 display (0109)
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values to be shown on the local display.
Selection	Picklist see Value 1 display parameter (→  16)
Factory setting	None
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→  15) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Selection</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→  45).</p>

Decimal places 4

Navigation	 Expert → System → Display → Decimal places 4 (0119)
Prerequisite	A measured value is specified in the Value 4 display parameter (→  21).
Description	Use this function to select the number of decimal places for measured value 4.


Selection	<ul style="list-style-type: none"> ■ X ■ X.X ■ X.XX ■ X.XXX ■ X.XXXX
Factory setting	x.xx
Additional information	<p><i>Description</i></p> <p> This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.</p>

Display interval

Navigation	 Expert → System → Display → Display interval (0096)
Prerequisite	A local display is provided.
Description	Use this function to enter the length of time the measured values are displayed if the values alternate on the display.
User entry	1 to 10 s
Factory setting	5 s
Additional information	<p><i>Description</i></p> <p>This type of alternating display only occurs automatically if the number of measured values defined exceeds the number of values the selected display format can display simultaneously.</p> <p> <ul style="list-style-type: none"> ■ The Value 1 display parameter (→  16)...Value 4 display parameter (→  21) are used to specify which measured values are shown on the display. ■ The display format of the displayed measured values is specified using the Format display parameter (→  15). </p>

Display damping



Navigation	 Expert → System → Display → Display damping (0094)
Prerequisite	A local display is provided.
Description	Use this function to enter the reaction time of the local display to fluctuations in the measured value caused by process conditions.
User entry	0.0 to 999.9 s
Factory setting	0.0 s

Additional information *User entry*

A time constant is entered:

- If a low time constant is entered, the display reacts particularly quickly to fluctuating measured variables.
- On the other hand, the display reacts more slowly if a high time constant is entered.

Header 🔒

Navigation 📁📁 Expert → System → Display → Header (0097)

Prerequisite A local display is provided.

Description Use this function to select the contents of the header of the local display.


Selection

- Device tag
- Free text

Factory setting Device tag

Additional information *Description*

The header text only appears during normal operation.



A0013375

1 Position of the header text on the display

Selection

- Device tag
Is defined in the **Device tag** parameter (→ 📄 122).
- Free text
Is defined in the **Header text** parameter (→ 📄 23).

Header text 🔒

Navigation 📁📁 Expert → System → Display → Header text (0112)


Prerequisite The **Free text** option is selected in the **Header** parameter (→ 📄 23).

Description Use this function to enter a customer-specific text for the header of the local display.

User entry Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting -----

Additional information	<i>Description</i> The header text only appears during normal operation.
-------------------------------	-----------------------------------------------------------------------------



A0013375

1 Position of the header text on the display

User entry

The number of characters displayed depends on the characters used.

Separator

Navigation Expert → System → Display → Separator (0101)

Prerequisite A local display is provided.

Description Use this function to select the decimal separator.

Selection

- .
- ,

Factory setting .

Contrast display

Navigation Expert → System → Display → Contrast display (0105)

Prerequisite A local display is provided.

Description Use this function to enter a value to adapt the display contrast to the ambient conditions (e.g. the lighting or viewing angle).


User entry 20 to 80 %

Factory setting Depends on the display










Additional information *Set the contrast via the push-buttons:*

- Brighter: Press and hold down the keys simultaneously.
- Darker: Press and hold down the keys simultaneously.

Backlight





Navigation	 Expert → System → Display → Backlight (0111)
Prerequisite	Order code for "Display; operation", option E "SD03 4-line, illum.; touch control + data backup function"
Description	Option for switching the backlight of the local display on and off.
Selection	<ul style="list-style-type: none"> ▪ Disable ▪ Enable
Factory setting	Disable

Access status display


Navigation	 Expert → System → Display → Access stat.disp (0091)
Prerequisite	A local display is provided.
Description	Use this function to view the access authorization to the parameters via the local display.
User interface	<ul style="list-style-type: none"> ▪ Operator ▪ Maintenance
Factory setting	Operator
Additional information	<p><i>Description</i></p> <p>If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.</p> <p> The access authorization can be modified via the Enter access code parameter (→  12).</p> <p> For information on the Enter access code parameter (→  12), see the "Disabling write protection via access code" section of the Operating Instructions for the device</p> <p> If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the Locking status parameter (→  11).</p> <p><i>User interface</i></p> <p> Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.</p>

3.1.2 "Configuration backup display" submenu


Navigation  Expert → System → Conf.backup disp

▶ Configuration backup display	
Operating time (0652)	→  26
Last backup (0102)	→  26
Configuration management (0100)	→  26
Comparison result (0103)	→  28


Operating time




Navigation	 Expert → System → Conf.backup disp → Operating time (0652)
Description	Use this function to display the length of time the device has been in operation.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i> The maximum number of days is 9999, which is equivalent to 27 years.

Last backup


Navigation	 Expert → System → Conf.backup disp → Last backup (0102)
Prerequisite	A local display is provided.
Description	Use this function to display the time since a backup copy of the data was last saved to the display module.
User interface	Days (d), hours (h), minutes (m) and seconds (s)

Configuration management

Navigation	 Expert → System → Conf.backup disp → Config. managem. (0100)
Prerequisite	A local display is provided.
Description	Use this function to select an action to save the data to the display module.

Selection	<ul style="list-style-type: none"> ■ Cancel ■ Execute backup ■ Restore ■ Duplicate ■ Compare ■ Clear backup data
Factory setting	Cancel
Additional information	<p><i>Description</i></p> <p>Configuration via the local display is disabled while the action is performed.</p> <p> For information on the status message in the operating tool, see the Backup state parameter (→  27)</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Cancel <ul style="list-style-type: none"> No action is executed and the user exits the parameter. ■ Execute backup <ul style="list-style-type: none"> – A backup copy of the current device configuration in the HistoROM is saved to the display module of the device. The backup copy includes the transmitter data of the device. – The following message appears on local display: Backup active, please wait! ■ Restore <ul style="list-style-type: none"> – The last backup copy of the device configuration is copied from the display module to the HistoROM of the device. The backup copy comprises the transmitter data of the device. – The following message appears on local display: Restore active! Do not interrupt power supply! ■ Duplicate <ul style="list-style-type: none"> – The transmitter configuration from another device is duplicated to the device using the display module. – The following message appears on local display: Copy active! Do not interrupt power supply! ■ Compare <ul style="list-style-type: none"> – The device configuration saved in the display module is compared to the current device configuration of the HistoROM. – The following message appears on local display: Comparing files – The result can be viewed in the Comparison result parameter (→  28). ■ Clear backup data <ul style="list-style-type: none"> – The backup copy of the device configuration is deleted from the display module of the device. – The following message appears on local display: Deleting file <p><i>HistoROM</i></p> <p>A HistoROM is a "non-volatile" device memory in the form of an EEPROM.</p>

Backup state

Navigation	 Expert → System → Conf.backup disp → Backup state (0121)
Prerequisite	A local display is provided.
Description	Use this function to view the status of the data backup process.

User interface	<ul style="list-style-type: none"> ■ None ■ Store in progress ■ Restore in progress ■ Import in progress ■ Delete in progress ■ Compare in progress
-----------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Factory setting	None
------------------------	------

Comparison result

Navigation	 Expert → System → Conf.backup disp → Compar. result (0103)
-------------------	----------------------------------------------------------------------------------------------------------------------------------------------



Prerequisite	A local display is provided.
---------------------	------------------------------

Description	Use this function to view the last result of comparing the current device configuration to the backup copy in the display module.
--------------------	-----------------------------------------------------------------------------------------------------------------------------------


User interface	<ul style="list-style-type: none"> ■ Settings identical ■ Settings not identical ■ No backup available ■ Backup settings corrupt ■ Check not done ■ Dataset incompatible
-----------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Factory setting	Check not done
------------------------	----------------

Additional information	<i>Description</i>
-------------------------------	--------------------

 The comparison is started via the **Compare** option in the **Configuration management** parameter (→  26).

Selection


- Settings identical
 - The current device configuration of the HistoROM is identical to the backup copy in the display module.
 - If the transmitter configuration of another device has been copied to the device via the display module and the **Duplicate** option in the **Configuration management** parameter (→  26), the current device configuration of the HistoROM only partly matches the backup copy in the display module: The settings for the transmitter are not identical.
- Settings not identical
 - The current device configuration of the HistoROM is not identical to the backup copy in the display module.
- No backup available
 - There is no backup copy of the device configuration of the HistoROM in the display module.
- Backup settings corrupt
 - The current device configuration of the HistoROM is corrupt or not compatible with the backup copy in the display module.
- Check not done
 - The device configuration of the HistoROM has not yet been compared to the backup copy in the display module.
- Dataset incompatible
 - The backup copy in the display module is not compatible with the device.

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.


3.1.3 "Diagnostic handling" submenu

Navigation  Expert → System → Diagn. handling



Alarm delay

Navigation

 Expert → System → Diagn. handling → Alarm delay (0651)

Description

Use this function to enter the time interval until the device generates a diagnostic message.

User entry

0 to 60 s

Factory setting

0 s


Additional information


Description

This setting affects the following diagnostic messages:



- 832 Electronic temperature too high
- 833 Electronic temperature too low

"Diagnostic behavior" submenu

 For a list of all the diagnostic events, see the Operating Instructions for the device.










 Modifying the diagnostic behavior of a diagnostic event. Each diagnostic event is assigned a certain diagnostic behavior at the factory. The user can change this assignment for certain diagnostics events.



The following options are available in the **Assign behavior of diagnostic no. xxx** parameters:


- **Off** option
The diagnostic event is ignored; it is neither entered into the Event logbook, nor is a diagnostic message generated.
- **Alarm** option
The device continues to measure. The signal outputs assume the defined alarm condition. A diagnostic message is generated.
- **Warning** option
The device continues to measure. A diagnostic message is generated.
- **Logbook entry only** option
The device continues to measure. The diagnostic message is entered in the **Event logbook** submenu (→  120) (**Event list** submenu (→  121)) only and is not displayed in alternation with the measured value display.





Navigation

 Expert → System → Diagn. handling → Diagn. behavior





► Diagnostic behavior	
Assign behavior of diagnostic no. 004 (0734)	→  31
Assign behavior of diagnostic no. 441 (0657)	→  31
Assign behavior of diagnostic no. 442 (0658)	→  31
Assign behavior of diagnostic no. 443 (0659)	→  32
Assign behavior of diagnostic no. 531 (0733)	→  32
Assign behavior of diagnostic no. 801 (0660)	→  33
Assign behavior of diagnostic no. 832 (0675)	→  33
Assign behavior of diagnostic no. 833 (0676)	→  33
Assign behavior of diagnostic no. 861 (0736)	→  34


Assign behavior of diagnostic no. 862 (0679)	→  34
Assign behavior of diagnostic no. 937 (0735)	→  34



Assign behavior of diagnostic no. 004 (Sensor) 



Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 004 (0734)
Description	Use this function to change the diagnostic behavior of the diagnostic message 004 Sensor .
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available for selection: →  30

Assign behavior of diagnostic no. 441 (Current output 1) 





Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 441 (0657)
Description	Use this function to change the diagnostic behavior of the diagnostic message 441 Current output 1 .
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available for selection: →  30

Assign behavior of diagnostic no. 442 (Frequency output) 





Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 442 (0658)
Prerequisite	The measuring device has a pulse/frequency/switch output.

Description	Use this function to change the diagnostic behavior of the diagnostic message 442 Frequency output .
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Alarm ▪ Warning ▪ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available for selection: →  30

Assign behavior of diagnostic no. 443 (Pulse output)

Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 443 (0659)
Prerequisite	The measuring device has a pulse/frequency/switch output.
Description	Use this function to change the diagnostic behavior of the diagnostic message 443 Pulse output .
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Alarm ▪ Warning ▪ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available for selection: →  30

Assign behavior of diagnostic no. 531 (Empty pipe detection)

Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 531 (0733)
Description	Use this function to change the diagnostic behavior of the diagnostic message 531 Empty pipe detection .
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Alarm ▪ Warning ▪ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available for selection: →  30

Assign behavior of diagnostic no. 801 (Supply voltage too low)


Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 801 (0660)
Description	Use this function to change the diagnostic behavior of the diagnostic message 801 Supply voltage too low .
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Alarm ▪ Warning ▪ Logbook entry only
Factory setting	Warning
Additional information	For a detailed description of the options available for selection: → 30

Assign behavior of diagnostic no. 832 (Electronic temperature too high)


Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 832 (0675)
Description	Use this function to change the diagnostic behavior of the diagnostic message 832 Electronic temperature too high .
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Alarm ▪ Warning ▪ Logbook entry only
Factory setting	Warning
Additional information	For a detailed description of the options available for selection: → 30

Assign behavior of diagnostic no. 833 (Electronic temperature too low)


Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 833 (0676)
Description	Use this function to change the diagnostic behavior of the diagnostic message 833 Electronic temperature too low .
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Alarm ▪ Warning ▪ Logbook entry only
Factory setting	Warning
Additional information	For a detailed description of the options available for selection: → 30

Assign behavior of diagnostic no. 861 (Process fluid)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 861 (0736)
Description	Use this function to change the diagnostic behavior of the diagnostic message 861 Process fluid .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Alarm
Additional information	For a detailed description of the options available for selection: → 30

Assign behavior of diagnostic no. 862 (Empty pipe)





Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 862 (0679)
Description	Use this function to change the diagnostic behavior of the diagnostic message 862 Empty pipe .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	For a detailed description of the options available for selection: → 30

Assign behavior of diagnostic no. 937 (EMC interference)









Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 937 (0735)
Description	Use this function to change the diagnostic behavior of the diagnostic message 937 EMC interference .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning

Additional information



 For a detailed description of the options available for selection: →  30

3.1.4 "Administration" submenu



Navigation  Expert → System → Administration

▶ Administration	
▶ Define access code	→  35
Device reset (0000)	→  37
Activate SW option (0029)	→  38
Software option overview (0015)	→  38
Activate sensor emergency mode (6611)	→  38
Reset write protection (0019)	→  39


"Define access code" wizard

 The **Define access code** wizard is only available if you are operating via the local display. If you are operating via the operating tool, the **Define access code** parameter (→  36) is directly in the **Administration** submenu. The **Confirm access code** parameter is not available if you are operating via the operating tool.

Navigation  Expert → System → Administration → Def. access code

▶ Define access code	
Define access code	→  35
Confirm access code	→  36

Define access code



Navigation  Expert → System → Administration → Def. access code → Def. access code



Description Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the local display.


User entry 0 to 9999

Factory setting 0

Additional information *Description*

The write protection affects all parameters in the document marked with the  symbol. On the local display, the  symbol in front of a parameter indicates that the parameter is write-protected.

 Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter (→  12).

 Please contact your Endress+Hauser Sales Center if you lose your access code.


User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

Confirm access code

Navigation  Expert → System → Administration → Def. access code → Confirm code


Description Enter the defined release code a second time to confirm the release code.

User entry 0 to 9999

Factory setting 0

Additional parameters in the "Administration" submenu

Define access code


Navigation  Expert → System → Administration → Def. access code (0093)



Description Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the operating tool.

User entry 0 to 9999

Factory setting 0

Additional information*Description*

The write protection affects all parameters in the document marked with the  symbol.

 Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter (→  12).

 Please contact your Endress+Hauser Sales Center if you lose your access code.

User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the **"Maintenance"** role.

Device reset**Navigation**

  Expert → System → Administration → Device reset (0000)

Description

Use this function to choose whether to reset the device configuration - either entirely or in part - to a defined state.

Selection

- Cancel
- To factory defaults
- To delivery settings
- Restart device

Factory setting

Cancel

Additional information*"Cancel" option*

No action is executed and the user exits the parameter.

"To factory defaults" option

Every parameter is reset to its factory setting.

"To delivery settings" option

Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.

 This option is not visible if no customer-specific settings have been ordered.

"Restart device" option

The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

Activate SW option





Navigation	Expert → System → Administration → Activate SW opt. (0029)
Description	Use this function to enter an activation code to enable an additional, ordered software option.
User entry	Positive integer
Factory setting	0
Additional information	<p><i>User entry</i></p> <p> Endress+Hauser provides the corresponding activation code for the software option with the order.</p> <p><i>Example</i></p> <p>Order code for "Application package", option EA "Extended HistoROM"</p>

Software option overview




Navigation	Expert → System → Administration → SW option overv. (0015)
Description	Use this function to display all the software options that are enabled in the device.
User interface	<ul style="list-style-type: none"> ■ Extended HistoROM ■ SIL ■ Heartbeat Verification
Additional information	<p><i>Description</i></p> <p>Displays all the options that are available if ordered by the customer.</p> <p><i>"Extended HistoROM" option</i></p> <p>Order code for "Application Package", option EA "Extended HistoROM"</p> <p><i>"SIL" option</i></p> <p>Order code for "Additional Approval", option LA "SIL"</p> <p><i>"Heartbeat Verification" option</i></p> <p>Order code for "Application Package", option EB "Heartbeat Verification"</p>

Activate sensor emergency mode


Navigation	Expert → System → Administration → Sens. emerg.mode (6611)
Prerequisite	The device has identified an error during verification of the characteristics in the sensor data storage or electronics module. A diagnostic message of status type ✘F is output.







Description	Use this function to switch on the emergency mode of the sensor to use the backup of the sensor characteristics or main electronics characteristics stored in the HistoROM.
Selection	<ul style="list-style-type: none"> ■ Cancel ■ Ok
Factory setting	Cancel
Additional information	<p><i>Description</i></p> <p>The status signal of the output diagnostic message changes from F (failure) to M (maintenance required), the diagnostic behavior changes from Alarm to Warning: ΔM. The diagnostic message is output until the characteristics in the sensor data storage are again correct.</p> <p> Information on what is causing the diagnostic message, and remedy measures, can be viewed by pressing the -button.</p> <p> Information on status signals and diagnostic behavior: Operating Instructions about the device, "Diagnostic message" chapter</p>

Reset write protection

Navigation	 Expert → System → Administration → Res. write prot. (0019)
Prerequisite	The SIL mode has been enabled.
Description	Use this function to enter the SIL locking code to disable write protection in the SIL mode.
User entry	0 to 65 535
Factory setting	0
Additional information	<p><i>Prerequisite</i></p> <p> For detailed information about enabling and disabling the SIL mode, see the Special Documentation for the device</p> <p><i>Description</i></p> <p> Once the SIL mode has been activated, the process-related parameters are write protected, and thereby locked, for security reasons. It is still possible to read the parameters. When SIL locking is enabled, restrictions apply on all communication options, such as the service interface, the HART protocol and the onsite display.</p>




3.2 "Sensor" submenu

Navigation  Expert → Sensor

▶ Sensor	
▶ Measured values	→  40
▶ System units	→  45
▶ Process parameters	→  53
▶ Calculated values	→  61
▶ Sensor adjustment	→  61
▶ Calibration	→  64



3.2.1 "Measured values" submenu

Navigation  Expert → Sensor → Measured val.


▶ Measured values	
▶ Process variables	→  40
▶ Totalizer	→  41
▶ Output values	→  43

"Process variables" submenu

Navigation  Expert → Sensor → Measured val. → Process variab.



▶ Process variables	
Volume flow (1838)	→  40
Mass flow (1847)	→  41

Volume flow


Navigation  Expert → Sensor → Measured val. → Process variab. → Volume flow (1838)

Description Use this function to view the volume flow currently measured.

User interface Signed floating-point number



Additional information *Dependency*
 The unit is taken from the **Volume flow unit** parameter (→  46)

Mass flow


Navigation  Expert → Sensor → Measured val. → Process variab. → Mass flow (1847)

Description Use this function to view the mass flow currently calculated.


User interface Signed floating-point number


Additional information *Dependency*
 The unit is taken from the **Mass flow unit** parameter (→  47)

Totalizer


Navigation  Expert → Sensor → Measured val. → Totalizer → Totalizer val. 1 to 3 (0911-1 to 3)


▶ **Totalizer**

Totalizer value 1 to 3 (0911-1 to 3) →  41

Totalizer overflow 1 to 3 (0910-1 to 3) →  42

Totalizer value 1 to 3

Navigation  Expert → Sensor → Measured val. → Totalizer → Totalizer val. 1 to 3 (0911-1 to 3)






Prerequisite In the **Assign process variable** parameter (→  110) in the **Totalizer 1 to 3** submenu, one of the following options is selected:

- Volume flow
- Mass flow






Description Use this function to check the current totalizer reading.

User interface Signed floating-point number

Factory setting 0 1

Additional information	<p><i>Description</i></p> <p>As it is only possible to display a maximum of 7 digits, the current counter value is the sum of the totalizer value and the overflow value from the Totalizer overflow 1 to 3 parameter if the display range is exceeded.</p> <p> In the event of an error, the totalizer adopts the mode defined in the Failure mode parameter (→  113).</p> <p><i>User interface</i></p> <p>The value of the process variable totalized since measuring began can be positive or negative. This depends on the settings in the Totalizer operation mode parameter (→  111).</p> <p> The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→  110).</p> <p><i>Example</i></p> <p>Calculation of the current totalizer reading when the value exceeds the 7-digit display range:</p> <ul style="list-style-type: none"> ▪ Value in the Totalizer value 1 parameter: 196 845.7 m³ ▪ Value in the Totalizer overflow 1 parameter: 1 10⁷ (1 overflow) = 10 000 000 [m³] ▪ Current totalizer reading: 10 196 845.7 m³
-------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Totalizer overflow 1 to 3

Navigation	  Expert → Sensor → Measured val. → Totalizer → Tot. overflow 1 to 3 (0910-1 to 3)
Prerequisite	<p>In the Assign process variable parameter (→  110) in the Totalizer 1 to 3 submenu, one of the following options is selected:</p> <ul style="list-style-type: none"> ▪ Volume flow ▪ Mass flow
Description	Use this function to display the current totalizer overflow.
User interface	Integer with sign
Factory setting	0
Additional information	<p><i>Description</i></p> <p>If the current reading has more than 7 digits, which is the maximum value range that can be displayed, the value above this range is given as an overflow. The current totalizer value is therefore the sum of the overflow value and the totalizer value from the Totalizer value 1 to 3 parameter</p> <p><i>User interface</i></p> <p> The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→  110).</p>

Example







Calculation of the current totalizer reading when the value exceeds the 7-digit display range:

- Value in the **Totalizer value 1** parameter: 196 845.7 m³
- Value in the **Totalizer overflow 1** parameter: 2 10⁷ (2 overflows) = 20 000 000 [m³]
- Current totalizer reading: 20 196 845.7 m³



"Output values" submenu

Navigation   Expert → Sensor → Measured val. → Output values



▶ **Output values**

Output current 1 (0361-1)	→  43
Measured current 1 (0366-1)	→  43
Terminal voltage 1 (0662)	→  44
Pulse output (0456)	→  44
Output frequency (0471)	→  45
Switch status (0461)	→  45


Output current 1

- Navigation**   Expert → Sensor → Measured val. → Output values → Output curr. 1 (0361-1)
- Description** Use this function to view the actual calculated value of the output current.
- User interface** 3.59 to 22.5 mA





Measured current 1


- Navigation**   Expert → Sensor → Measured val. → Output values → Measur. curr. 1 (0366-1)
- Description** Use this function to display the actual measured value of the output current.
- User interface** 0 to 30 mA

Terminal voltage 1

Navigation	 Expert → Sensor → Measured val. → Output values → Terminal volt. 1 (0662)
Description	Use this function to view the actual terminal voltage that is present at the current output.
User interface	0.0 to 50.0 V


Pulse output


Navigation	 Expert → Sensor → Measured val. → Output values → Pulse output (0456)
Prerequisite	The Pulse option is selected in the Operating mode parameter (→  79).
Description	Use this function to display the pulse frequency currently output.
User interface	Positive floating-point number
Additional information	<p><i>Description</i></p> <p>The pulse output is an open collector output. This is configured at the factory so that the transistor is conductive for the duration of the pulse (NO contact).</p> <p>With the Value per pulse parameter (→  80) and Pulse width parameter (→  80) it is possible to define the value - i.e. the measured value amount that is equivalent to a pulse, and the duration of the pulse.</p>






A0025816-EN

0 Non-conductive
 1 Conductive
 NC Normally closed
 NO Normally opened




The output behavior can be inverted via the **Invert output signal** parameter (→  89), i.e. the transistor is not conductive for the duration of the pulse.

In addition, the behavior of the output in the event of an error (**Failure mode** parameter (→  81)) can be configured.

Output frequency









Navigation	  Expert → Sensor → Measured val. → Output values → Output freq. (0471)
Prerequisite	The Frequency option is selected in the Operating mode parameter (→  79).
Description	Use this function to view the actual value of the output frequency which is currently measured.
User interface	0 to 1250 Hz

Switch status

Navigation	  Expert → Sensor → Measured val. → Output values → Switch status (0461)
Prerequisite	The Switch option is selected in the Operating mode parameter (→  79).
Description	Use this function to view the current switch status of the status output.
User interface	<ul style="list-style-type: none"> ▪ Open ▪ Closed

3.2.2 "System units" submenu

Navigation   Expert → Sensor → System units

▶ System units	
Volume flow unit (0553)	→  46
Volume unit (0563)	→  47
Mass flow unit (0554)	→  47
Mass unit (0574)	→  48
Density unit (0555)	→  49
Temperature unit (0557)	→  49
Date/time format (2812)	→  50
▶ User-specific units	→  50

Volume flow unit
**Navigation**

Expert → Sensor → System units → Volume flow unit (0553)

Description

Use this function to select the unit for the volume flow.

Selection*SI units*

- cm³/s
- cm³/min
- cm³/h
- cm³/d
- dm³/s
- dm³/min
- dm³/h
- dm³/d
- m³/s
- m³/min
- m³/h
- m³/d
- ml/s
- ml/min
- ml/h
- ml/d
- l/s
- l/min
- l/h
- l/d
- hl/s
- hl/min
- hl/h
- hl/d
- Ml/s
- Ml/min
- Ml/h
- Ml/d

US units

- af/s
- af/min
- af/h
- af/d
- ft³/s
- ft³/min
- ft³/h
- ft³/d
- fl oz/s (us)
- fl oz/min (us)
- fl oz/h (us)
- fl oz/d (us)
- gal/s (us)
- gal/min (us)
- gal/h (us)
- gal/d (us)
- kgal/s (us)
- kgal/min (us)
- kgal/h (us)
- kgal/d (us)
- Mgal/s (us)
- Mgal/min (us)
- Mgal/h (us)
- Mgal/d (us)
- bbl/s (us;liq.)
- bbl/min (us;liq.)
- bbl/h (us;liq.)
- bbl/d (us;liq.)
- bbl/s (us;beer)
- bbl/min (us;beer)
- bbl/h (us;beer)
- bbl/d (us;beer)
- bbl/s (us;oil)
- bbl/min (us;oil)
- bbl/h (us;oil)
- bbl/d (us;oil)
- bbl/s (us;tank)
- bbl/min (us;tank)
- bbl/h (us;tank)
- bbl/d (us;tank)

Imperial units

- gal/s (imp)
- gal/min (imp)
- gal/h (imp)
- gal/d (imp)
- Mgal/s (imp)
- Mgal/min (imp)
- Mgal/h (imp)
- Mgal/d (imp)
- bbl/s (imp;beer)
- bbl/min (imp;beer)
- bbl/h (imp;beer)
- bbl/d (imp;beer)
- bbl/s (imp;oil)
- bbl/min (imp;oil)
- bbl/h (imp;oil)
- bbl/d (imp;oil)

Custom-specific units


- User vol./s
- User vol./min
- User vol./h
- User vol./d

Factory setting



Country-specific:

- l/h
- gal/min (us)



Additional information*Result*

The selected unit applies for:
Volume flow (→  40)

Selection

 For an explanation of the abbreviated units: →  145

Customer-specific units

 The unit for the customer-specific volume is specified in the **User volume text** parameter (→  51).

Volume unit**Navigation**

  Expert → Sensor → System units → Volume unit (0563)

Description

Use this function to select the unit for the volume.

Selection*SI units*

- cm³
- dm³
- m³
- ml
- l
- hl
- Ml Mega

US units

- af
- ft³
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;oil)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;tank)

Imperial units

- gal (imp)
- Mgal (imp)
- bbl (imp;beer)
- bbl (imp;oil)

Custom-specific units

User vol.

Factory setting


Country-specific:

- m³
- gal (us)

Additional information*Selection*

 For an explanation of the abbreviated units: →  145

Customer-specific units

 The unit for the customer-specific volume is specified in the **User volume text** parameter (→  51).

Mass flow unit**Navigation**

  Expert → Sensor → System units → Mass flow unit (0554)

Description

Use this function to select the unit for the mass flow.

Selection*SI units*

- g/s
- g/min
- g/h
- g/d
- kg/s
- kg/min
- kg/h
- kg/d
- t/s
- t/min
- t/h
- t/d

US units

- oz/s
- oz/min
- oz/h
- oz/d
- lb/s
- lb/min
- lb/h
- lb/d
- STon/s
- STon/min
- STon/h
- STon/d

Custom-specific units


- User mass/s
- User mass/min
- User mass/h
- User mass/d

Factory setting

Country-specific:

- kg/h
- lb/min



Additional information*Result*

The selected unit applies for:
Mass flow (→  41)

Selection

 For an explanation of the abbreviated units: →  145

Customer-specific units

 The unit for the customer-specific mass is specified in the **User mass text** parameter (→  52).

Mass unit**Navigation**

  Expert → Sensor → System units → Mass unit (0574)

Description

Use this function to select the unit for the mass.

Selection*SI units*

- g
- kg
- t

US units

- oz
- lb
- STon

Custom-specific units



User mass

Factory setting



Country-specific:

- kg
- lb

Additional information*Selection*

 For an explanation of the abbreviated units: →  145

Customer-specific units

 The unit for the customer-specific mass is specified in the **User mass text** parameter (→  52).

Density unit**Navigation**

  Expert → Sensor → System units → Density unit (0555)

Description

Use this function to select the unit for the density.

Selection*SI units*

- g/cm³
- g/m³
- kg/dm³
- kg/l
- kg/m³
- SD4°C
- SD15°C
- SD20°C
- SG4°C
- SG15°C
- SG20°C

US units

- lb/ft³
- lb/gal (us)
- lb/bbl (us;liq.)
- lb/bbl (us;beer)
- lb/bbl (us;oil)
- lb/bbl (us;tank)

Imperial units


- lb/gal (imp)
- lb/bbl (imp;beer)
- lb/bbl (imp;oil)

Factory setting

Country-specific:

- kg/l
- lb/ft³

Additional information*Result*



The selected unit applies for:
Fixed density (→  61)

Selection

- SD = specific density
The specific density is the ratio of the density of the fluid to the density of water at a water temperature of +4 °C (+39 °F), +15 °C (+59 °F), +20 °C (+68 °F).
- SG = specific gravity








 For an explanation of the abbreviated units: →  145

Temperature unit**Navigation**





  Expert → Sensor → System units → Temperature unit (0557)

Description

Use this function to select the unit for the temperature.



Selection	<i>SI units</i> <ul style="list-style-type: none"> ■ °C ■ K 	<i>US units</i> <ul style="list-style-type: none"> ■ °F ■ °R
Factory setting	Country-specific: <ul style="list-style-type: none"> ■ °C ■ °F 	
Additional information	<i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> ■ Maximum value (→  134) ■ Minimum value (→  133) ■ Maximum value (→  135) ■ Minimum value (→  134) ■ Average value (→  135) <i>Selection</i>  For an explanation of the abbreviated units: →  145	

Date/time format


Navigation	  Expert → Sensor → System units → Date/time format (2812)
Description	Use this function to select the desired time format for calibration history.
Selection	<ul style="list-style-type: none"> ■ dd.mm.yy hh:mm ■ dd.mm.yy hh:mm am/pm ■ mm/dd/yy hh:mm ■ mm/dd/yy hh:mm am/pm
Factory setting	dd.mm.yy hh:mm
Additional information	<i>Selection</i>  For an explanation of the abbreviated units: →  145




"User-specific units" submenu

Navigation   Expert → Sensor → System units → User-spec. units




▶ User-specific units	
User volume text (0567)	→  51
User volume offset (0569)	→  51

User volume factor (0568)	→ ⓘ 52
User mass text (0560)	→ ⓘ 52
User mass offset (0562)	→ ⓘ 52
User mass factor (0561)	→ ⓘ 53



User volume text ⓘ

Navigation	  Expert → Sensor → System units → User-spec. units → Volume text (0567)
Description	Use this function to enter a text for the user-specific unit of volume and volume flow. The corresponding time units (s, min, h, d) for volume flow are generated automatically.
User entry	Max. 10 characters such as letters, numbers or special characters (@, %, /)
Factory setting	User vol.
Additional information	<p><i>Result</i></p> <p> The defined unit is shown as an option in the choose list of the following parameters:</p> <ul style="list-style-type: none"> ▪ Volume flow unit parameter (→ ⓘ 46) ▪ Volume unit parameter (→ ⓘ 47) <p><i>Example</i></p> <p>If the text GLAS is entered, the choose list of the Volume flow unit parameter (→ ⓘ 46) shows the following options:</p> <ul style="list-style-type: none"> ▪ GLAS/s ▪ GLAS/min ▪ GLAS/h ▪ GLAS/d







User volume offset ⓘ

Navigation	  Expert → Sensor → System units → User-spec. units → Volume offset (0569)
Description	Use this function to enter the offset for adapting the user-specific volume unit and volume flow unit (without time).
User entry	Signed floating-point number
Factory setting	0
Additional information	<p><i>Description</i></p> <p> Value in user-specific unit = (factor × value in base unit) + offset</p>



User volume factor 





Navigation	  Expert → Sensor → System units → User-spec. units → Volume factor (0568)
Description	Use this function to enter a quantity factor (without time) for the user-specific volume and volume flow unit.
User entry	Signed floating-point number
Factory setting	1.0

User mass text 

Navigation	  Expert → Sensor → System units → User-spec. units → Mass text (0560)
Description	Use this function to enter a text for the user-specific unit of mass and mass flow. The corresponding time units (s, min, h, d) for mass flow are generated automatically.
User entry	Max. 10 characters such as letters, numbers or special characters (@, %, /)
Factory setting	User mass
Additional information	<p><i>Result</i></p> <p> The defined unit is shown as an option in the choose list of the following parameters:</p> <ul style="list-style-type: none"> ▪ Mass flow unit parameter (→  47) ▪ Mass unit parameter (→  48) <p><i>Example</i></p> <p>If the text GLAS is entered, the choose list of the Mass flow unit parameter (→  47) shows the following options:</p> <ul style="list-style-type: none"> ▪ GLAS/s ▪ GLAS/min ▪ GLAS/h ▪ GLAS/d

User mass offset 





Navigation	  Expert → Sensor → System units → User-spec. units → Mass offset (0562)
Description	Use this function to enter the offset for adapting the user-specific mass unit and mass flow unit (without time).
User entry	Signed floating-point number
Factory setting	0





Additional information	<i>Description</i>  Value in user-specific unit = (factor × value in base unit) + offset
<hr/>	
User mass factor	
Navigation	  Expert → Sensor → System units → User-spec. units → Mass factor (0561)
Description	Use this function to enter a quantity factor (without time) for the user-specific mass and mass flow unit.
User entry	Signed floating-point number
Factory setting	1.0

3.2.3 "Process parameters" submenu

Navigation   Expert → Sensor → Process param.

▶ **Process parameters**

Flow override (1839)	→  53
Flow damping (6661)	→  54
▶ Low flow cut off	→  54
▶ Empty pipe detection	→  57

Flow override	
Navigation	  Expert → Sensor → Process param. → Flow override (1839)
Description	Use this function to select whether to interrupt the evaluation of measured values. This is useful for the cleaning process of a pipeline, for example.
Selection	<ul style="list-style-type: none"> ■ Off ■ On
Factory setting	Off
Additional information	<i>Result</i>  This setting affects all the functions and outputs of the measuring device.

*Description***Flow override is active**

- The diagnostic message diagnostic message \triangle C453 **Flow override** is displayed.
- Output values
 - Output: Value at zero flow
 - Temperature: Proceeding output
 - Totalizers 1-3: Stop being totalized

Flow damping**Navigation**

Expert → Sensor → Process param. → Flow damping (6661)

Description

Use this function to enter flow damping. Reduction of the variability of the flow measured value (in relation to interference). For this purpose, the depth of the flow filter is adjusted: when the filter setting increases, the reaction time of the device also increases.

User entry

0 to 15

Factory setting

7

Additional information*Result*

The damping has an effect on the following variables of the device:

- Outputs → 65
- Low flow cut off → 54
- Totalizer → 109

User entry

- Value = 0: no damping
- Value > 0: damping is increased

"Low flow cut off" submenu*Navigation*

Expert → Sensor → Process param. → Low flow cut off

▶ **Low flow cut off**

Assign process variable (1837)	→ 55
On value low flow cutoff (1805)	→ 55
Off value low flow cutoff (1804)	→ 55
Pressure shock suppression (1806)	→ 56

Assign process variable



Navigation	Expert → Sensor → Process param. → Low flow cut off → Assign variable (1837)
Description	Use this function to select a process variable for low flow cut off.
Selection	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Mass flow
Factory setting	Volume flow

On value low flow cutoff




Navigation	Expert → Sensor → Process param. → Low flow cut off → On value (1805)
Prerequisite	In the Assign process variable parameter (→ 55), one of the following options is selected: <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow
Description	Use this function to enter a switch-on value for low flow cut off. Low flow cut off is activated if the value entered is not equal to 0 → 55.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter → 142
Additional information	<p><i>Dependency</i></p> <p> The unit depends on the process variable selected in the Assign process variable parameter (→ 55).</p>

Off value low flow cutoff



Navigation	Expert → Sensor → Process param. → Low flow cut off → Off value (1804)
Prerequisite	In the Assign process variable parameter (→ 55), one of the following options is selected: <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow
Description	Use this function to enter a switch-off value for low flow cut off. The off value is entered as a positive hysteresis from the on value → 55.
User entry	0 to 100.0 %
Factory setting	50 %

Additional information *Example*

A0012887

- Q Flow
 t Time
 H Hysteresis
 A Low flow cut off active
 1 Low flow cut off is activated
 2 Low flow cut off is deactivated
 3 On value entered
 4 Off value entered

Pressure shock suppression

Navigation	Expert → Sensor → Process param. → Low flow cut off → Pres. shock sup. (1806)
Prerequisite	In the Assign process variable parameter (→ 55), one of the following options is selected: <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow
Description	Use this function to enter a time interval for signal suppression (= active pressure shock suppression).
User entry	0 to 100 s
Factory setting	0 s
Additional information	<i>Example</i>

While closing a valve, there can be brief but severe movements of the piping system's fluid that are registered by the measuring system. The pulses totaled in this way result in a totalizer reading error, particularly in the case of batching processes.


*Description***Activation of the surge suppression**

- Prerequisite: the flow rate is less than the switching-on-point for low flow cut off
- Output values
 - Current output: outputs the current corresponding to zero flow.
 - Flow displayed: 0
 - Totalizer: the totalizers are pegged at the last correct value

Deactivation of the surge suppression

- Prerequisite: the time interval set in this function has elapsed.
- If the flow exceeds the switch-off value of the low flow cut off, the actual flow value is then used and displayed.

Example



A0012888



- Q Flow
- t Time
- A After run
- B Surge
- C Pressure shock suppression active as specified by the time entered
- D Pressure shock suppression inactive
- 1 Valve closes
- 2 Flow falls below the on-value of the low flow cut off: pressure shock suppression is activated
- 3 The time entered has elapsed: pressure shock suppression is deactivated
- 4 The actual flow value is now displayed and output
- 5 On value for low flow cut off
- 6 Off value for low flow cut off

"Empty pipe detection" submenu



Navigation Expert → Sensor → Process param. → Empty pipe det.

▶ Empty pipe detection




Empty pipe detection (1860)	→ 58
Switch point empty pipe detection (6562)	→ 58
Response time empty pipe detection (1859)	→ 58
Empty pipe adjust value (6527)	→ 59
Full pipe adjust value (6548)	→ 59

Measured value EPD (6559)	→  59
▶ Empty pipe adjust	→  60




Empty pipe detection

Navigation	  Expert → Sensor → Process param. → Empty pipe det. → Empty pipe det. (1860)
Description	Use this function to switch empty pipe detection on and off.
Selection	<ul style="list-style-type: none"> ■ Off ■ On
Factory setting	Off




Switch point empty pipe detection

Navigation	  Expert → Sensor → Process param. → Empty pipe det. → Switch point EPD (6562)
Prerequisite	The On option is selected in the Empty pipe detection parameter (→  58).
Description	Use this function to enter the percentage threshold value of the resistance in relation to the adjustment values.
User entry	1 to 99 %
Factory setting	10 %




Response time empty pipe detection

Navigation	  Expert → Sensor → Process param. → Empty pipe det. → Response time (1859)
Prerequisite	The On option is selected in the Empty pipe detection parameter (→  58).
Description	Use this function to enter the time until the diagnostic message Δ S862 Empty pipe is displayed for an empty measuring pipe.
User entry	0 to 100 s
Factory setting	1 s




Empty pipe adjust value

Navigation	  Expert → Sensor → Process param. → Empty pipe det. → Empty pipe value (6527)
Prerequisite	<ul style="list-style-type: none"> ▪ The On option is selected in the Empty pipe detection parameter (→  58). ▪ Adjustment value > full pipe value.
Description	Use this function to display the adjustment value when the measuring pipe is empty.
User interface	Positive floating-point number
Factory setting	0 Ohm


Full pipe adjust value


Navigation	  Expert → Sensor → Process param. → Empty pipe det. → Full pipe value (6548)
Prerequisite	<ul style="list-style-type: none"> ▪ The On option is selected in the Empty pipe detection parameter (→  58). ▪ Adjustment value < empty pipe value.
Description	Use this function to display the adjustment value when the measuring pipe is full.
User interface	Positive floating-point number
Factory setting	0 Ohm



Measured value EPD

Navigation	  Expert → Sensor → Process param. → Empty pipe det. → Meas. value EPD (6559)
Prerequisite	The On option is selected in the Empty pipe detection parameter (→  58).
Description	Displays the current measured value.
User interface	Positive floating-point number
Factory setting	0 Ohm




"Empty pipe adjust" wizard

Navigation  Expert → Sensor → Process param. → Empty pipe det. → Empty pipe adj.

**New adjustment**

Navigation	 Expert → Sensor → Process param. → Empty pipe det. → Empty pipe adj. → New adjustment (6560)
Prerequisite	The On option is selected in the Empty pipe detection parameter (→  58).
Description	For selecting whether to perform an empty pipe or full pipe adjustment.
Selection	<ul style="list-style-type: none"> ▪ Cancel ▪ Empty pipe adjust ▪ Full pipe adjust
Factory setting	Cancel

Progress


Navigation	  Expert → Sensor → Process param. → Empty pipe det. → Empty pipe adj. → Progress (6571)
Prerequisite	The On option is selected in the Empty pipe detection parameter (→  58).
Description	Use this function to view the progress.
User interface	<ul style="list-style-type: none"> ▪ Ok ▪ Busy ▪ Not ok

3.2.4 "Calculated values" submenu

Navigation   Expert → Sensor → Calculated value

▶ Calculated values

▶ Reference values


→  61

"Reference values" submenu






Navigation   Expert → Sensor → Calculated value → Reference values

▶ Reference values

Fixed density (1862)

→  61

Fixed density


Navigation	  Expert → Sensor → Calculated value → Reference values → Fixed density (1862)
Prerequisite	The Mass flow option is selected in the Assign current output parameter (→  66).
Description	Use this function to enter a fixed value for the density. The density is used to calculate the mass flow.
User entry	Positive floating-point number
Factory setting	1 000 kg/l
Additional information	<i>User entry</i>  The unit is taken from the Density unit parameter (→  49).

3.2.5 "Sensor adjustment" submenu


Navigation   Expert → Sensor → Sensor adjustm.



▶ Sensor adjustment

Installation direction (1809)




→  62

Integration time (6533)



→  62

Measuring period (6536)	→  62
► Process variable adjustment	→  63



Installation direction

Navigation	  Expert → Sensor → Sensor adjustm. → Install. direct. (1809)
Description	Use this function to change the sign of the medium flow direction.
Selection	<ul style="list-style-type: none"> ■ Flow in arrow direction ■ Flow against arrow direction
Factory setting	Flow in arrow direction
Additional information	<p><i>Description</i></p> <p> Before changing the sign: ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor nameplate.</p>



Integration time

Navigation	  Expert → Sensor → Sensor adjustm. → Integration time (6533)
Description	Display the duration of an integration cycle.
User interface	5 to 100 ms
Factory setting	20 ms





Measuring period

Navigation	  Expert → Sensor → Sensor adjustm. → Measuring period (6536)
Description	Display the time of a full measuring period.
User interface	40 to 1 000 ms
Factory setting	100 ms

"Process variable adjustment" submenu



Navigation   Expert → Sensor → Sensor adjustm. → Variable adjust

▶ **Process variable adjustment**

Volume flow factor (1832)	→  63
Volume flow offset (1831)	→  63
Mass flow factor (1846)	→  64
Mass flow offset (1841)	→  64




Volume flow factor



Navigation	  Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow factor (1832)
Description	Use this function to enter a quantity factor (without time) for the volume flow. This multiplication factor is applied over the volume flow range.
User entry	Positive floating-point number
Factory setting	1

Volume flow offset



Navigation	  Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow offset (1831)
Description	Use this function to enter the zero point shift for the volume flow trim. The volume flow unit on which the shift is based is 1 m ³ /s.
User entry	Signed floating-point number
Factory setting	0 m ³ /s
Additional information	<p><i>Description</i></p> <p> Corrected value = (factor × value) + offset</p>

Mass flow factor

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow factor (1846)
Description	Use this function to enter a quantity factor (without time) for the mass flow. This multiplication factor is applied over the mass flow range.
User entry	Positive floating-point number
Factory setting	1

Mass flow offset

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow offset (1841)
Description	Use this function to enter the zero point shift for the mass flow trim. The mass flow unit on which the shift is based is 1 kg/s.
User entry	Signed floating-point number
Factory setting	0 kg/s
Additional information	<p><i>Description</i></p> <p> Corrected value = (factor × value) + offset</p>


3.2.6 "Calibration" submenu

Navigation Expert → Sensor → Calibration


► Calibration	
Nominal diameter (2807)	→ 64
Calibration factor (6522)	→ 65
Zero point (6546)	→ 65

Nominal diameter


Navigation	Expert → Sensor → Calibration → Nominal diameter (2807)
Description	Use this function to view the nominal diameter of the sensor.

User interface	DNxx / x'
Factory setting	Depends on the size of the sensor
Additional information	<i>Description</i>  The value is also specified on the sensor nameplate.

Calibration factor



Navigation	 Expert → Sensor → Calibration → Cal. factor (6522)
Description	This function is for entering the current calibration factor for the sensor.
User interface	Signed floating-point number
Factory setting	Depends on nominal diameter and calibration.

Zero point


Navigation	 Expert → Sensor → Calibration → Zero point (6546)
Description	This function shows the zero point correction value for the sensor.
User interface	Signed floating-point number
Factory setting	Depends on nominal diameter and calibration















3.3 "Output" submenu

Navigation  Expert → Output


▶ Output	
▶ Current output 1	→  66
▶ Pulse/frequency/switch output	→  78

3.3.1 "Current output 1" submenu

Navigation  Expert → Output → Curr.output 1

► Current output 1	
Assign current output (0359-1)	→  66
Current span (0353-1)	→  67
Fixed current (0365-1)	→  68
4 mA value (0367-1)	→  68
20 mA value (0372-1)	→  70
Measuring mode (0351-1)	→  70
Damping output (0363-1)	→  74
Failure mode (0364-1)	→  75
Failure current (0352-1)	→  76
Output current 1 (0361-1)	→  76
Start-up mode (0368-1)	→  76
Start-up current (0369-1)	→  77
Measured current 1 (0366-1)	→  77
Terminal voltage 1 (0662-1)	→  77

Assign current output

Navigation  Expert → Output → Curr.output 1 → Assign curr. (0359-1)

Description Options for the assignment of a process variable to the current output.

Selection

- Off
- Volume flow
- Mass flow

Factory setting Volume flow

Current span



Navigation

Expert → Output → Curr.output 1 → Current span (0353-1)

Description

The selection specifies the operational range for the process value and the upper and lower level for signal on alarm.

Selection

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- Fixed current

Factory setting

Country-specific:

- 4...20 mA NAMUR
- 4...20 mA US

Additional information

Description


- If an error occurs, the current output adopts the value defined in the **Failure mode** parameter (→ 75).
- If the measured value is outside the measuring range, the diagnostic message **△S441 Current output 1** is displayed.
- The measuring range is specified by the **4 mA value** parameter (→ 68) and **20 mA value** parameter (→ 70).

"Fixed current" option

The current value is set via the **Fixed current** parameter (→ 68).

Example





Shows the relationship between the current span for the output of the process variable and the lower and upper alarm levels:













A0013316

- I Current
- 1 Current span for process value
- 2 Lower level for signal on alarm
- 3 Upper level for signal on alarm

Options	1	2	3
4 to 20 mA NAMUR	3.8 to 20.5 mA	< 3.6 mA	> 21.95 mA
4 to 20 mA US	3.9 to 20.8 mA US	< 3.6 mA	> 21.95 mA
4 to 20 mA	4 to 20.5 mA	< 3.6 mA	> 21.95 mA

Fixed current 	
Navigation	  Expert → Output → Curr.output 1 → Fixed current (0365-1)
Prerequisite	The Fixed current option is selected in the Current span parameter (→  67).
Description	Use this function to enter a constant current value for the current output.
User entry	3.59 to 22.5 mA
Factory setting	4 mA
Additional information	<i>Example</i> This setting can be used for HART multidrop, for example.

4 mA value 	
Navigation	  Expert → Output → Curr.output 1 → 4 mA value (0367-1)
Prerequisite	In the Current span parameter (→  67), one of the following options is selected: <ul style="list-style-type: none"> ■ 4...20 mA NAMUR ■ 4...20 mA US ■ 4...20 mA
Description	Use this function to enter a value for the 4 mA current.
User entry	Signed floating-point number
Factory setting	Country-specific: <ul style="list-style-type: none"> ■ 0 l/h ■ 0 gal/min (us)
Additional information	<i>Description</i> Positive and negative values are permitted depending on the process variable assigned in the Assign current output parameter (→  66). In addition, the value can be greater or smaller than the value assigned for the 20mA current in the 20 mA value parameter (→  70). <i>User entry</i> The unit depends on the process variable selected in the Assign current output parameter (→  66). <i>Current output behavior</i> The current output behaves differently depending on the settings configured in the following parameters: <ul style="list-style-type: none"> ■ Current span (→  67) ■ Measuring mode (→  70) ■ Failure mode (→  75)


Configuration examples

Some examples of parameter settings and their effect on the current output are given in the following section.

Configuration example A

Measuring mode with the **Forward flow** option

- **4 mA value** parameter (→ 68) = not equal to zero flow (e.g. -250 m³/h)
- **20 mA value** parameter (→ 70) = not equal to zero flow (e.g. +750 m³/h)
- Calculated current value = 8 mA at zero flow




A0013757

- Q Flow
- I Current
- 1 Measuring range is exceeded or undershot

The operational range of the measuring device is defined by the values entered for the **4 mA value** parameter (→ 68) and **20 mA value** parameter (→ 70). If the effective flow falls outside this operational range, the diagnostic message **△S441 Current output 1** is displayed.

Configuration example B

Measuring mode with the **Forward/Reverse flow** option



A0013758














- I Current
- Q Flow
- 1 Value assigned to 4 mA current
- 2 Forward flow
- 3 Reverse flow






The current output signal is independent of the direction of flow (absolute amount of the measured variable). The values for the **4 mA value** parameter (→ 68) and **20 mA value** parameter (→ 70) must have the same sign. The value for the **20 mA value** parameter (→ 70) (e.g. reverse flow) corresponds to the mirrored value for the **20 mA value** parameter (→ 70) (e.g. forward flow).

Configuration example C

Measuring mode with **Reverse flow compensation** option

If flow is characterized by severe fluctuations (e.g. when using reciprocating pumps), flow components outside of the measuring range are buffered, balanced and output after a maximum delay of 60 s → 70.



20 mA value 	
Navigation	  Expert → Output → Curr.output 1 → 20 mA value (0372-1)
Prerequisite	In the Current span parameter (→  67), one of the following options is selected: <ul style="list-style-type: none"> ▪ 4...20 mA NAMUR ▪ 4...20 mA US ▪ 4...20 mA
Description	Enter a value for the 20 mA current.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter →  142
Additional information	<p><i>Description</i></p> <p>Positive and negative values are permitted depending on the process variable assigned in the Assign current output parameter (→  66). In addition, the value can be greater or smaller than the value assigned for the 4 mA current in the 4 mA value parameter (→  68).</p> <p><i>User entry</i></p> <p>The unit depends on the process variable selected in the Assign current output parameter (→  66).</p> <p><i>Example</i></p> <ul style="list-style-type: none"> ▪ Value assigned for 4 mA = -250 m³/h ▪ Value assigned for 20 mA = +750 m³/h ▪ Calculated current value = 8 mA (at zero flow) <p>If the Forward/Reverse flow option is selected in the Measuring mode parameter (→  70), different signs cannot be entered for the values of the 4 mA value parameter (→  68) and 20 mA value parameter (→  70). The diagnostic message △S441 Current output 1 is displayed.</p> <p> Pay attention to the configuration examples for the 4 mA value parameter (→  68).</p>

Measuring mode 	
Navigation	  Expert → Output → Curr.output 1 → Measuring mode (0351-1)
Prerequisite	In the Assign current output parameter (→  66), one of the following options is selected: <ul style="list-style-type: none"> ▪ Volume flow ▪ Mass flow <p>In the Current span parameter (→  67), one of the following options is selected:</p> <ul style="list-style-type: none"> ▪ 4...20 mA NAMUR ▪ 4...20 mA US ▪ 4...20 mA
Description	Use this function to select the measuring mode for the current output.

- Selection**
- Forward flow
 - Forward/Reverse flow
 - Reverse flow compensation

Factory setting Forward flow

Additional information *Description*


 The process variable that is assigned to the current output via the **Assign current output** parameter (→  66) is displayed below the parameter.

"Forward flow" option

The current output signal is proportional to the process variable assigned. The measuring range is defined by the values that are assigned to the 4 mA and 20 mA current value. The flow components outside the scaled measuring range are taken into account for signal output as follows:





Both values are defined such that they are not equal to zero flow (e.g. 4 mA current value = $-5 \text{ m}^3/\text{h}$, 20 mA current value = $10 \text{ m}^3/\text{h}$): if the effective flow falls outside this measuring range, the diagnostic message Δ **S441 Current output 1** is displayed.

"Forward/Reverse flow" option



A0013758

- I* Current
Q Flow
 1 Value assigned to 4 mA current
 2 Forward flow
 3 Reverse flow

The current output signal is independent of the direction of flow (absolute amount of the measured variable). The values for the **4 mA value** parameter (→  68) and **20 mA value** parameter (→  70) must have the same sign. The value for the **20 mA value** parameter (→  70) (e.g. reverse flow) corresponds to the mirrored value for the **20 mA value** parameter (→  70) (e.g. forward flow).

"Reverse flow compensation" option

If flow is characterized by severe fluctuations (e.g. when using reciprocating pumps), flow components outside of the measuring range are buffered, balanced and output after a maximum delay of 60 s.


If buffering is not processed within approx. 60 s, the diagnostic message Δ **S441 Current output 1** is displayed.

Under certain plant conditions, flow values can aggregate in the buffer, for example in the case of prolonged and unwanted fluid reverse flow. However, this buffer is reset in all relevant programming adjustments which affect the current output.

Examples of how the current output behaves

Example 1

Defined measuring range: lower range value and upper range value with the **same** sign




A0001248

4 Measuring range

- I Current
- Q Flow
- 1 Lower range value (value assigned to 4 mA current)
- 2 Upper range value (value assigned to 20 mA current)

With the following flow response:




A0001265

5 Flow response

- Q Flow
- t Time

With the **Forward flow** option

The current output signal is proportional to the process variable assigned. The flow components outside the scaled measuring range are not taken into account for signal output.




A0001267

- I Current
- t Time

With the **Forward/Reverse flow** option

The current output signal is independent of the direction of flow.




A0001268

- I Current
- t Time

With the **Reverse flow compensation** option

Flow components outside the span are buffered, balanced and output after a maximum delay of 60 s .




A0001269

- I* Current
- t* Time
- S* Flow components saved
- A* Balancing of saved flow components

Example 2

Defined measuring range: lower range value and upper range value with **different** signs




A0001273

6 Measuring range

- I* Current
- Q* Flow
- 1 Lower range value (value assigned to 4 mA current)
- 2 Upper range value (value assigned to 20 mA current)

With flow a (–) outside, b (– –) inside the measuring range




A0001273

- Q* Flow
- t* Time
- 1 Lower range value (value assigned to 4 mA current)
- 2 Upper range value (value assigned to 20 mA current)

With the **Forward flow** option

- a (–): The flow components outside the scaled measuring range cannot be taken into account for signal output.
The diagnostic message **△S441 Current output 1** is displayed.
- b (– –): The current output signal is proportional to the process variable assigned.



A0001274


I Current
 t Time

With the **Forward/Reverse flow** option

This option is not possible in this case because the values for the **4 mA value** parameter (→ 68) and **20 mA value** parameter (→ 70) have different signs.

With the **Reverse flow compensation** option

Flow components outside the span are buffered, balanced and output after a maximum delay of 60 s.



A0001275

I Current
 t Time
 S Flow components saved
 A Balancing of saved flow components

Damping output



Navigation

Expert → Output → Curr.output 1 → Damping out. (0363-1)

Prerequisite

In the **Assign current output** parameter (→ 66), one of the following options is selected:

- Volume flow
- Mass flow

In the **Current span** parameter (→ 67), one of the following options is selected:

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA

Description










Use this function to enter the reaction time of the current output signal to fluctuations in the measured value caused by process conditions.

User entry

0.0 to 999.9 s



Factory setting


1.0 s




Additional information	<p><i>Description</i></p> <p>Entry of a time constant:</p> <ul style="list-style-type: none"> ■ If a low time constant is entered, the current output reacts particularly quickly to fluctuating measured variables. ■ On the other hand, the current output reacts more slowly if a high time constant is entered.
<hr/>	
Failure mode	
<hr/>	
Navigation	 Expert → Output → Curr.output 1 → Failure mode (0364-1)
Prerequisite	<p>In the Assign current output parameter (→  66), one of the following options is selected:</p> <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow <p>In the Current span parameter (→  67), one of the following options is selected:</p> <ul style="list-style-type: none"> ■ 4...20 mA NAMUR ■ 4...20 mA US ■ 4...20 mA
Description	Use this function to select the value of the current output in the event of an alarm condition.
Selection	<ul style="list-style-type: none"> ■ Min. ■ Max. ■ Last valid value ■ Actual value ■ Defined value
Factory setting	Max.
Additional information	<p><i>Description</i></p> <p> This setting does not affect the failsafe mode of other outputs and totalizers. This is specified in separate parameters.</p> <p><i>"Min." option</i></p> <p>The current output adopts the value of the lower level for signal on alarm.</p> <p> The signal on alarm level is defined via the Current span parameter (→  67).</p> <p><i>"Max." option</i></p> <p>The current output adopts the value of the upper level for signal on alarm.</p> <p> The signal on alarm level is defined via the Current span parameter (→  67).</p> <p><i>"Last valid value" option</i></p> <p>The current output is based on the last measured value that was valid before the error occurred.</p> <p><i>"Actual value" option</i></p> <p>The current output is based on the actual measured value on the basis of the current flow measurement; the error is ignored.</p>

"Defined value" option



The current output adopts a defined measured value.


 The measured value is defined via the **Failure current** parameter (→  76).




Failure current


Navigation	  Expert → Output → Curr.output 1 → Failure current (0352-1)
Prerequisite	The Defined value option is selected in the Failure mode parameter (→  75).
Description	Use this function to enter a fixed value that the current output adopts in an alarm condition.
User entry	3.59 to 22.5 mA
Factory setting	22.5 mA

Output current 1

Navigation	  Expert → Output → Curr.output 1 → Output curr. 1 (0361-1)
Description	Use this function to view the actual calculated value of the output current.
User interface	3.59 to 22.5 mA
Factory setting	3.59 mA

Start-up mode


Navigation	  Expert → Output → Curr.output 1 → Start-up mode (0368-1)
Prerequisite	In the Current span parameter (→  67), one of the following options is selected: <ul style="list-style-type: none"> ■ 4...20 mA NAMUR ■ 4...20 mA US ■ 4...20 mA
Description	Use this function to select the current value that the current output adopts during the device start-up phase as long as no measured value is present.
Selection	<ul style="list-style-type: none"> ■ Min. ■ Max. ■ Defined value
Factory setting	Min.

Additional information*"Min." option*

The current output adopts the value of the lower level for signal on alarm.

The signal on alarm level is defined via the **Current span** parameter (→ 67).*"Max." option*

The current output adopts the value of the upper level for signal on alarm.

The signal on alarm level is defined via the **Current span** parameter (→ 67).*"Defined value" option*

The current output outputs a defined current value.

The current value is defined via the **Start-up current** parameter (→ 77).

Start-up current

**Navigation**

Expert → Output → Curr.output 1 → Start-up current (0369-1)

PrerequisiteThe **Defined value** option is selected in the **Start-up mode** parameter (→ 76).**Description**

Use this function to enter a fixed current value that the current output adopts during the device start-up phase as long as no measured value is present.

User entry

3.59 to 22.5 mA

Factory setting

3.6 mA

Measured current 1

Navigation

Expert → Output → Curr.output 1 → Measur. curr. 1 (0366-1)

Description

Use this function to display the actual measured value of the output current.

User interface

0 to 30 mA

Terminal voltage 1

Navigation

Expert → Output → Curr.output 1 → Terminal volt. 1 (0662-1)

Description






















Use this function to view the actual terminal voltage that is present at the current output.









User interface

0.0 to 50.0 V



3.3.2 "Pulse/frequency/switch output" submenu

Navigation  Expert → Output → PFS output




► Pulse/frequency/switch output	
Operating mode (0469)	→  79
Assign pulse output (0460)	→  79
Value per pulse (0455)	→  80
Pulse width (0452)	→  80
Measuring mode (0457)	→  80
Failure mode (0480)	→  81
Pulse output (0456)	→  81
Assign frequency output (0478)	→  82
Minimum frequency value (0453)	→  82
Maximum frequency value (0454)	→  82
Measuring value at minimum frequency (0476)	→  83
Measuring value at maximum frequency (0475)	→  83
Measuring mode (0479)	→  84
Damping output (0477)	→  84
Failure mode (0451)	→  84
Failure frequency (0474)	→  85
Output frequency (0471)	→  85
Switch output function (0481)	→  85
Assign diagnostic behavior (0482)	→  86
Assign limit (0483)	→  86
Switch-on value (0466)	→  86

Switch-off value (0464)	→  87
Assign flow direction check (0484)	→  87
Assign status (0485)	→  87
Switch-on delay (0467)	→  88
Switch-off delay (0465)	→  88
Failure mode (0486)	→  88
Switch status (0461)	→  88
Invert output signal (0470)	→  89

Operating mode

Navigation	  Expert → Output → PFS output → Operating mode (0469)
Description	Use this function to select the operating mode of the output as a pulse, frequency or switch output.
Selection	<ul style="list-style-type: none"> ■ Pulse ■ Frequency ■ Switch
Factory setting	Pulse

Assign pulse output

Navigation	  Expert → Output → PFS output → Assign pulse (0460)
Prerequisite	The Pulse option is selected in the Operating mode parameter (→  79).
Description	Use this function to select the process variable for the pulse output.
Selection	<ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Volume flow
Factory setting	Off

Value per pulse


Navigation	Expert → Output → PFS output → Value per pulse (0455)
Prerequisite	In the Assign pulse output parameter (→ 79), one of the following options is selected: <ul style="list-style-type: none"> ■ Mass flow ■ Volume flow
Description	Use this function to enter the measured value for the pulse output.
User entry	Signed floating-point number
Factory setting	0

Pulse width


Navigation	Expert → Output → PFS output → Pulse width (0452)
Prerequisite	In the Assign pulse output parameter (→ 79), one of the following options is selected: <ul style="list-style-type: none"> ■ Mass flow ■ Volume flow
Description	Use this function to enter the duration of the output pulse.
User entry	5 to 2 000 ms
Factory setting	100 ms

Measuring mode



Navigation	Expert → Output → PFS output → Measuring mode (0457)
Prerequisite	In the Assign pulse output parameter (→ 79), one of the following options is selected: <ul style="list-style-type: none"> ■ Mass flow ■ Volume flow
Description	Use this function to select the measuring mode for the pulse output.
Selection	<ul style="list-style-type: none"> ■ Forward flow ■ Forward/Reverse flow ■ Reverse flow ■ Reverse flow compensation
Factory setting	Forward flow

Failure mode


Navigation	Expert → Output → PFS output → Failure mode (0480)
Prerequisite	In the Assign pulse output parameter (→ 79), one of the following options is selected: <ul style="list-style-type: none"> ■ Mass flow ■ Volume flow
Description	Use this function to select an output behavior in the event of a device alarm.
Selection	<ul style="list-style-type: none"> ■ Actual value ■ No pulses
Factory setting	No pulses


Pulse output


Navigation	Expert → Output → PFS output → Pulse output (0456)
Prerequisite	The Pulse option is selected in the Operating mode parameter (→ 79).
Description	Use this function to display the pulse frequency currently output.
User interface	Positive floating-point number
Additional information	<p><i>Description</i></p> <p>The pulse output is an open collector output. This is configured at the factory so that the transistor is conductive for the duration of the pulse (NO contact).</p> <p>With the Value per pulse parameter (→ 80) and Pulse width parameter (→ 80) it is possible to define the value - i.e. the measured value amount that is equivalent to a pulse, and the duration of the pulse.</p>






A0025816-EN

0 Non-conductive
1 Conductive
NC Normally closed
NO Normally opened




The output behavior can be inverted via the **Invert output signal** parameter (→  89), i.e. the transistor is not conductive for the duration of the pulse.

In addition, the behavior of the output in the event of an error (**Failure mode** parameter (→  81)) can be configured.




Assign frequency output

Navigation	  Expert → Output → PFS output → Assign freq. (0478)
Prerequisite	The Frequency option is selected in the Operating mode parameter (→  79).
Description	Use this function to select the process variable for the frequency output.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Volume flow ▪ Mass flow
Factory setting	Off

Minimum frequency value

Navigation	  Expert → Output → PFS output → Min. freq. value (0453)
Prerequisite	In the Assign frequency output parameter (→  82), one of the following options is selected: <ul style="list-style-type: none"> ▪ Volume flow ▪ Mass flow
Description	Use this function to enter the start value frequency.
User entry	0 to 1 000 Hz
Factory setting	0 Hz

Maximum frequency value

Navigation	  Expert → Output → PFS output → Max. freq. value (0454)
Prerequisite	In the Assign frequency output parameter (→  82), one of the following options is selected: <ul style="list-style-type: none"> ▪ Volume flow ▪ Mass flow
Description	Use this function to enter the end value frequency.
User entry	0 to 1 000 Hz

Factory setting 1 000 Hz

Measuring value at minimum frequency






Navigation	Expert → Output → PFS output → Val. at min.freq (0476)
Prerequisite	In the Assign frequency output parameter (→ 82), one of the following options is selected: <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow
Description	Use this function to enter the measured value for the start value frequency.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter
Additional information	<i>Dependency</i> The unit depends on the process variable selected in the Assign frequency output parameter (→ 82).

Measuring value at maximum frequency







Navigation	Expert → Output → PFS output → Val. at max.freq (0475)
Prerequisite	In the Assign frequency output parameter (→ 82), one of the following options is selected: <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow
Description	Use this function to enter the measured value for the end value frequency.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter
Additional information	<i>Dependency</i> The unit depends on the process variable selected in the Assign frequency output parameter (→ 82).




Measuring mode 

Navigation	  Expert → Output → PFS output → Measuring mode (0479)
Prerequisite	In the Assign frequency output parameter (→  82), one of the following options is selected: <ul style="list-style-type: none">■ Volume flow■ Mass flow
Description	Use this function to select the measuring mode for the frequency output.
Selection	<ul style="list-style-type: none">■ Forward flow■ Forward/Reverse flow■ Reverse flow compensation
Factory setting	Forward flow

Damping output 

Navigation	  Expert → Output → PFS output → Damping out. (0477)
Prerequisite	In the Assign frequency output parameter (→  82), one of the following options is selected: <ul style="list-style-type: none">■ Volume flow■ Mass flow
Description	Use this function to enter the reaction time of the output signal to fluctuations in the measured value.
User entry	0 to 999.9 s
Factory setting	0.0 s

Failure mode 

Navigation	  Expert → Output → PFS output → Failure mode (0451)
Prerequisite	In the Assign frequency output parameter (→  82), one of the following options is selected: <ul style="list-style-type: none">■ Volume flow■ Mass flow
Description	Use this function to select an output behavior in the event of a device alarm.
Selection	<ul style="list-style-type: none">■ Actual value■ Defined value■ 0 Hz
Factory setting	0 Hz

Failure frequency



Navigation	Expert → Output → PFS output → Failure freq. (0474)
Prerequisite	In the Assign frequency output parameter (→ 82), one of the following options is selected: <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow
Description	Use this function to enter the value for the frequency output in the event of a device alarm.
User entry	0.0 to 1250.0 Hz
Factory setting	0.0 Hz





Output frequency





Navigation	Expert → Output → PFS output → Output freq. (0471)
Prerequisite	The Frequency option is selected in the Operating mode parameter (→ 79).
Description	Use this function to view the actual value of the output frequency which is currently measured.
User interface	0 to 1250 Hz






Switch output function



Navigation	Expert → Output → PFS output → Switch out funct (0481)
Prerequisite	The Switch option is selected in the Operating mode parameter (→ 79).
Description	Use this function to select a function for the switch output.
Selection	<ul style="list-style-type: none"> ■ Off ■ On ■ Diagnostic behavior ■ Limit ■ Flow direction check ■ Status
Factory setting	Off

Assign diagnostic behavior		
Navigation	  Expert → Output → PFS output → Assign diag. beh (0482)	
Prerequisite	The Diagnostic behavior option is selected in the Switch output function parameter (→  85).	
Description	Use this function to select a diagnostic behavior for the switch output.	
Selection	<ul style="list-style-type: none"> ▪ Alarm ▪ Alarm or warning ▪ Warning 	
Factory setting	Alarm	

Assign limit		
Navigation	  Expert → Output → PFS output → Assign limit (0483)	
Prerequisite	The Limit option is selected in the Switch output function parameter (→  85).	
Description	Use this function to select a process variable for the limit function.	
Selection	<ul style="list-style-type: none"> ▪ Volume flow ▪ Mass flow ▪ Totalizer 1 ▪ Totalizer 2 ▪ Totalizer 3 	
Factory setting	Volume flow	

Switch-on value		
Navigation	  Expert → Output → PFS output → Switch-on value (0466)	
Prerequisite	The Limit option is selected in the Switch output function parameter (→  85).	
Description	Use this function to enter the measured value for the switch-on point.	
User entry	Signed floating-point number	
Factory setting	Country-specific: <ul style="list-style-type: none"> ▪ 0 l/h ▪ 0 gal/min (us) 	
Additional information	<i>Dependency</i> The unit depends on the process variable selected in the Assign limit parameter (→  86).	

Switch-off value


Navigation	Expert → Output → PFS output → Switch-off value (0464)
Prerequisite	The Limit option is selected in the Switch output function parameter (→ 85).
Description	Use this function to enter the measured value for the switch-off point.
User entry	Signed floating-point number
Factory setting	Country-specific: <ul style="list-style-type: none"> ■ 0 l/h ■ 0 gal/min (us)
Additional information	<i>Dependency</i> The unit depends on the process variable selected in the Assign limit parameter (→ 86).


Assign flow direction check





Navigation	Expert → Output → PFS output → Assign dir.check (0484)
Prerequisite	The Flow direction check option is selected in the Switch output function parameter (→ 85).
Description	Use this function to select a process variable for monitoring the flow direction.
Selection	<ul style="list-style-type: none"> ■ Volume flow ■ Mass flow
Factory setting	Volume flow

Assign status



Navigation	Expert → Output → PFS output → Assign status (0485)
Prerequisite	The Status option is selected in the Switch output function parameter (→ 85).
Description	Use this function to select a device status for the switch output.
Selection	<ul style="list-style-type: none"> ■ Empty pipe detection ■ Low flow cut off
Factory setting	Empty pipe detection




Switch-on delay




Navigation	  Expert → Output → PFS output → Switch-on delay (0467)
Prerequisite	The Limit option is selected in the Switch output function parameter (→  85).
Description	Use this function to enter a delay time for switching on the switch output.
User entry	0.0 to 100.0 s
Factory setting	0.0 s



Switch-off delay






Navigation	  Expert → Output → PFS output → Switch-off delay (0465)
Prerequisite	The Limit option is selected in the Switch output function parameter (→  85).
Description	Use this function to enter a delay time for switching off the switch output.
User entry	0.0 to 100.0 s
Factory setting	0.0 s

Failure mode





Navigation	  Expert → Output → PFS output → Failure mode (0486)
Description	Use this function to select an output behavior in the event of a device alarm.
Selection	<ul style="list-style-type: none">■ Actual status■ Open■ Closed
Factory setting	Open

Switch status

Navigation	  Expert → Output → PFS output → Switch status (0461)
Prerequisite	The Switch option is selected in the Operating mode parameter (→  79).
Description	Use this function to view the current switch status of the status output.

- User interface**
- Open
 - Closed

Invert output signal 

Navigation   Expert → Output → PFS output → Invert outp.sig. (0470)

Description Use this function to select whether to invert the output signal.



- Selection**
- No
 - Yes

Factory setting No



3.4 "Communication" submenu

Navigation   Expert → Communication





▶ **Communication**

- ▶ HART output →  89
- ▶ Diagnostic configuration →  103


3.4.1 "HART output" submenu





Navigation   Expert → Communication → HART output

▶ **HART output**


- ▶ Configuration →  90
- ▶ Burst configuration →  91
- ▶ Information →  97
- ▶ Output →  100

"Configuration" submenu

Navigation  Expert → Communication → HART output → Configuration

► Configuration	
HART short tag (0220)	→  90
Device tag (0215)	→  90
HART address (0219)	→  90
No. of preambles (0217)	→  91

HART short tag**Navigation**

 Expert → Communication → HART output → Configuration → HART short tag (0220)

Description

Use this function to enter a brief description for the measuring point. This can be edited and displayed via HART protocol or using the local display.


User entry

Max. 8 characters: A-Z, 0-9 and certain special characters (e.g. punctuation marks, @, %).

Factory setting

PROMAG

Device tag**Navigation**

 Expert → Communication → HART output → Configuration → Device tag (0215)

Description

Use this function to enter the name for the measuring point.


User entry

Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Factory setting

Promag

HART address**Navigation**

 Expert → Communication → HART output → Configuration → HART address (0219)

Description



Use this function to enter the address via which the data exchange takes place via HART protocol.

User entry

0 to 63

Factory setting 0

No. of preambles 

Navigation   Expert → Communication → HART output → Configuration → No. of preambles (0217)



Description Use this function to enter the number of preambles in the HART protocol.

User entry 2 to 20

Factory setting 5











Additional information *User entry*
 As every modem component can "swallow" a byte, 2-byte preambles at least must be defined.





"Burst configuration" submenu

Navigation   Expert → Communication → HART output → Burst config. → Burst config. 1 to 3



▶ **Burst configuration**

▶ **Burst configuration 1 to 3**

Burst mode 1 to 3 (2032-1 to 3)	→  92
Burst command 1 to 3 (2031-1 to 3)	→  92
Burst variable 0 (2033-1 to 3)	→  93
Burst variable 1 (2034-1 to 3)	→  94
Burst variable 2 (2035-1 to 3)	→  94
Burst variable 3 (2036-1 to 3)	→  94
Burst variable 4 (2037-1 to 3)	→  94
Burst variable 5 (2038-1 to 3)	→  95
Burst variable 6 (2039-1 to 3)	→  95
Burst variable 7 (2040-1 to 3)	→  95

Burst trigger mode (2044-1 to 3)	→  95
Burst trigger level (2043-1 to 3)	→  96
Min. update period (2042-1 to 3)	→  96
Max. update period (2041-1 to 3)	→  97

Burst mode 1 to 3
**Navigation**

  Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst mode 1 to 3 (2032-1 to 3)

Description

Use this function to select whether to activate the HART burst mode for burst message X.

Selection

- Off
- On

Factory setting



Off

Additional information

Selection

- Off
The measuring device transmits data only when requested by the HART master.
- On
The measuring device transmits data regularly without being requested.

Burst command 1 to 3
**Navigation**

  Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst command 1 to 3 (2031-1 to 3)

Description

Use this function to select the HART command that is sent to the HART master.

Selection

- Command 1
- Command 2
- Command 3
- Command 9
- Command 33
- Command 48

Factory setting

Command 2

Additional information*Selection*

- Command 1
Read out the primary variable.
- Command 2
Read out the current and the main measured value as a percentage.
- Command 3
Read out the dynamic HART variables and the current.
- Command 9
Read out the dynamic HART variables including the related status.
- Command 33
Read out the dynamic HART variables including the related unit.
The HART device variables are defined via Command 107.
The following measured variables (HART device variables) can be read out:
 - Volume flow
 - Mass flow
 - Totalizer 1...3
 - Percent Of Range
 - Measured current
 - Primary variable (PV)
 - Secondary variable (SV)
 - Tertiary variable (TV)
 - Quaternary variable (QV)
- Command 48
Read out the complete device diagnostics.

Commands

Information about the defined details of the command: HART specifications



The measured variables (HART device variables) are assigned to the dynamic variables in the **Output** submenu (→ 65).

Burst variable 0**Navigation**

Expert → Communication → HART output → Burst config. → Burst config. 1 to 3
→ Burst variable 0 (2033-1 to 3)

Description

For HART command 9 and 33: select the HART device variable or the process variable.




Selection

- Volume flow
- Mass flow
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Percent Of Range
- Measured current
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)
- Not used




Factory setting

Volume flow




Burst variable 1 


Navigation	  Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst variable 1 (2034-1 to 3)
Description	For HART command 9 and 33: select the HART device variable or the process variable.
Selection	See Burst variable 0 parameter (→  93).
Factory setting	Not used




Burst variable 2 

Navigation	  Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst variable 2 (2035-1 to 3)
Description	For HART command 9 and 33: select the HART device variable or the process variable.
Selection	See Burst variable 0 parameter (→  93).
Factory setting	Not used

Burst variable 3 

Navigation	  Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst variable 3 (2036-1 to 3)
Description	For HART command 9 and 33: select the HART device variable or the process variable.
Selection	See Burst variable 0 parameter (→  93).
Factory setting	Not used

Burst variable 4 

Navigation	  Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst variable 4 (2037-1 to 3)
Description	For HART command 33: select the HART device variable or the process variable.
Selection	See Burst variable 0 parameter (→  93).
Factory setting	Not used

Burst variable 5



Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst variable 5 (2038-1 to 3)
Description	For HART command 33: select the HART device variable or the process variable.
Selection	See Burst variable 0 parameter (→ 93).
Factory setting	Not used

Burst variable 6



Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst variable 6 (2039-1 to 3)
Description	For HART command 33: select the HART device variable or the process variable.
Selection	See Burst variable 0 parameter (→ 93).
Factory setting	Not used





Burst variable 7






Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst variable 7 (2040-1 to 3)
Description	For HART command 33: select the HART device variable or the process variable.
Selection	See Burst variable 0 parameter (→ 93).
Factory setting	Not used

Burst trigger mode



Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Trigger mode (2044-1 to 3)
Description	Use this function to select the event that triggers burst message X.
Selection	<ul style="list-style-type: none"> ■ Continuous ■ Window ■ Rising ■ Falling ■ On change

Factory setting	Continuous
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Continuous The message is triggered in a time-controlled manner, at least observing the time interval defined in the Burst min period parameter (→  96). ■ Window The message is triggered if the specified measured value has changed by the value in the Burst trigger level parameter (→  96). ■ Rising The message is triggered if the specified measured value exceeds the value in the Burst trigger level parameter (→  96). ■ Falling The message is triggered if the specified measured value drops below the value in the Burst trigger level parameter (→  96). ■ On change The message is triggered if the measured value changes.



Burst trigger level

Navigation	  Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Trigger level (2043-1 to 3)
Description	For entering the burst trigger value.
User entry	Positive floating-point number
Additional information	<p><i>Description</i></p> <p>Together with the option selected in the Burst trigger mode parameter (→  95) the burst trigger value determines the time of burst message X.</p>



Min. update period

Navigation	  Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Min. upd. per. (2042-1 to 3)
Description	Use this function to enter the minimum time span between two burst commands of burst message X.
User entry	Positive integer
Factory setting	1 000 ms











Max. update period

Navigation	  Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Max. upd. per. (2041-1 to 3)
Description	Use this function to enter the maximum time span between two burst commands of burst message X.
User entry	Positive integer
Factory setting	2 000 ms



"Information" submenu

Navigation   Expert → Communication → HART output → Information

▶ **Information**

Device revision (0204)	→  97
Device ID (0221)	→  98
Device type (0209)	→  98
Manufacturer ID (0259)	→  98
HART revision (0205)	→  99
HART descriptor (0212)	→  99
HART message (0216)	→  99
Hardware revision (0206)	→  99
Software revision (0224)	→  100
HART date code (0202)	→  100

Device revision

Navigation	  Expert → Communication → HART output → Information → Device revision (0204)
Description	Use this function to view the device revision with which the device is registered with the HART Communication Foundation.

User interface 2-digit hexadecimal number

Factory setting 2

Additional information *Description*



The device revision is needed to assign the appropriate device description file (DD) to the device.

Device ID

Navigation Expert → Communication → HART output → Information → Device ID (0221)

Description Use this function to view the device ID for identifying the measuring device in a HART network.

User interface 6-digit hexadecimal number

Additional information *Description*



In addition to the device type and manufacturer ID, the device ID is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Device type

Navigation Expert → Communication → HART output → Information → Device type (0209)

Description Use this function to view the device type with which the measuring device is registered with the HART Communication Foundation.

User interface 2-digit hexadecimal number

Factory setting 0x48 (for Promag 200)

Additional information *Description*



The device type is specified by the manufacturer. It is needed to assign the appropriate device description file (DD) to the device.

Manufacturer ID


Navigation Expert → Communication → HART output → Information → Manufacturer ID (0259)

Description Use this function to view the manufacturer ID with which the measuring device is registered with the HART Communication Foundation.

User interface 2-digit hexadecimal number

Factory setting 0x11 (for Endress+Hauser)

HART revision

Navigation  Expert → Communication → HART output → Information → HART revision (0205)


Description Use this function to display the HART protocol revision of the measuring device.

User interface 5 to 7

Factory setting 7

HART descriptor



Navigation  Expert → Communication → HART output → Information → HART descriptor (0212)

Description Use this function to enter a description for the measuring point. This can be edited and displayed via HART protocol or using the local display.

User entry Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting Promag

HART message




Navigation  Expert → Communication → HART output → Information → HART message (0216)

Description Use this function to enter a HART message which is sent via the HART protocol when requested by the master.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting Promag

Hardware revision


Navigation  Expert → Communication → HART output → Information → Hardware rev. (0206)

Description Use this function to display the hardware revision of the measuring device.

User interface 0 to 255


Factory setting 1

Software revision

Navigation	 Expert → Communication → HART output → Information → Software rev. (0224)
Description	Use this function to display the software revision of the measuring device.
User interface	0 to 255
Factory setting	2









HART date code



Navigation	 Expert → Communication → HART output → Information → HART date code (0202)
Description	Use this function to enter the date information for individual use.
User entry	Date entry format: yyyy-mm-dd
Factory setting	2009-07-20
Additional information	<i>Example</i> Device installation date

"Output" submenu

Navigation  Expert → Communication → HART output → Output

► Output	
Assign PV (0234)	→  101
Primary variable (PV) (0201)	→  101
Assign SV (0235)	→  101
Secondary variable (SV) (0226)	→  102
Assign TV (0236)	→  102
Tertiary variable (TV) (0228)	→  102
Assign QV (0237)	→  103
Quaternary variable (QV) (0203)	→  103

Assign PV



Navigation	Expert → Communication → HART output → Output → Assign PV (0234)
Description	Use this function to select the assignment of a measured variable (HART device variable) to the primary dynamic variable (PV).
Selection	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Mass flow
Factory setting	Volume flow

Primary variable (PV)





Navigation	Expert → Communication → HART output → Output → Primary var (PV) (0201)
Description	Displays the current measured value of the primary dynamic variable (PV).
User interface	Signed floating-point number
Additional information	<p><i>User interface</i></p> <p>The displayed measured value depends on the option selected in the Assign PV parameter (→ 101).</p> <p> The unit of the value is taken from the System units submenu (→ 45).</p>

Assign SV




Navigation	Expert → Communication → HART output → Output → Assign SV (0235)
Description	Use this function to select the assignment of a measured variable (HART device variable) to the secondary dynamic variable (SV).
Selection	<ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3
Factory setting	Totalizer 1

Secondary variable (SV)





Navigation	 Expert → Communication → HART output → Output → Second.var(SV) (0226)
Description	Displays the current measured value of the secondary dynamic variable (SV).
User interface	Signed floating-point number
Additional information	<p><i>User interface</i></p> <p>The displayed measured value depends on the option selected in the Assign SV parameter (→  101).</p> <p> The unit of the value is taken from the System units submenu (→  45).</p>




Assign TV








Navigation	 Expert → Communication → HART output → Output → Assign TV (0236)
Description	Use this function to select the assignment of a measured variable (HART device variable) to the tertiary (third) dynamic variable (TV).
Selection	<ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3
Factory setting	Totalizer 2


Tertiary variable (TV)


Navigation	 Expert → Communication → HART output → Output → Tertiary var(TV) (0228)
Description	Displays the current measured value of the tertiary dynamic variable (TV).
User interface	Signed floating-point number
Additional information	<p><i>User interface</i></p> <p>The displayed measured value depends on the option selected in the Assign TV parameter (→  102).</p> <p> The unit of the value is taken from the System units submenu (→  45).</p>


Assign QV 	
Navigation	  Expert → Communication → HART output → Output → Assign QV (0237)
Description	Use this function to select the assignment of a measured variable (HART device variable) to the quaternary (fourth) dynamic variable (QV).
Selection	<ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3
Factory setting	Totalizer 3












Quaternary variable (QV)	
Navigation	  Expert → Communication → HART output → Output → Quaterna.var(QV) (0203)
Description	Displays the current measured value of the quaternary dynamic variable (QV).
User interface	Signed floating-point number
Additional information	<p><i>User interface</i></p> <p>The displayed measured value depends on the option selected in the Assign QV parameter (→  103).</p> <p> The unit of the value is taken from the System units submenu (→  45).</p>

3.4.2 "Diagnostic configuration" submenu


 For a list of all the diagnostic events, see the Operating Instructions for the device.

-  Assign a category to the particular diagnostic event:
- **Failure (F)** option
A device error has occurred. The measured value is no longer valid.
 - **Function check (C)** option
The device is in service mode (e.g. during a simulation).
 - **Out of specification (S)** option
The device is being operated:
 - Outside its technical specification limits (e.g. outside the process temperature range)
 - Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)
 - **Maintenance required (M)** option
Maintenance is required. The measured value is still valid.
 - **No effect (N)** option
Has no effect on the condensed status.

Navigation  Expert → Communication → Diag. config.

► Diagnostic configuration	
Event category 004 (0238)	→  104
Event category 441 (0210)	→  105
Event category 442 (0230)	→  105
Event category 443 (0231)	→  105
Event category 531 (0262)	→  106
Event category 801 (0232)	→  106
Event category 832 (0218)	→  107
Event category 833 (0225)	→  107
Event category 861 (0261)	→  107
Event category 862 (0214)	→  108
Event category 937 (0260)	→  108

Event category 004 (Sensor)

Navigation  Expert → Communication → Diag. config. → Event category 004 (0238)

Description Use this function to select the category assigned to diagnostic message **004 Sensor**.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional information  For a detailed description of the options available for selection: →  103

Event category 441 (Current output 1)



Navigation	Expert → Communication → Diag. config. → Event category 441 (0210)
Description	Use this function to select the category assigned to diagnostic message 441 Current output 1 .
Selection	<ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ No effect (N)
Factory setting	Out of specification (S)
Additional information	For a detailed description of the options available for selection: → 103

Event category 442 (Frequency output)





Navigation	Expert → Communication → Diag. config. → Event category 442 (0230)
Prerequisite	The pulse/frequency/switch output is available.
Description	Use this function to select the category assigned to diagnostic message 442 Frequency output .
Selection	<ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ No effect (N)
Factory setting	Out of specification (S)
Additional information	For a detailed description of the options available for selection: → 103

Event category 443 (Pulse output)






Navigation	Expert → Communication → Diag. config. → Event category 443 (0231)
Prerequisite	The pulse/frequency/switch output is available.
Description	Use this function to select the category assigned to diagnostic message 443 Pulse output .

Selection	<ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ No effect (N)
Factory setting	Out of specification (S)
Additional information	 For a detailed description of the options available for selection: →  103




Event category 531 (Empty pipe detection)



Navigation	 Expert → Communication → Diag. config. → Event category 531 (0262)
Description	Use this function to select the category assigned to diagnostic message 531 Empty pipe detection .
Selection	<ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ No effect (N)
Factory setting	Out of specification (S)
Additional information	 For a detailed description of the options available for selection: →  103

Event category 801 (Supply voltage too low)



Navigation	 Expert → Communication → Diag. config. → Event category 801 (0232)
Description	Use this function to select the category assigned to diagnostic message 801 Supply voltage too low .
Selection	<ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ No effect (N)
Factory setting	Out of specification (S)
Additional information	 For a detailed description of the options available for selection: →  103

Event category 832 (Electronic temperature too high)



Navigation	Expert → Communication → Diag. config. → Event category 832 (0218)
Description	Use this function to select the category assigned to diagnostic message 832 Electronic temperature too high .
Selection	<ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ No effect (N)
Factory setting	Out of specification (S)
Additional information	For a detailed description of the options available for selection: → 103

Event category 833 (Electronic temperature too low)




Navigation	Expert → Communication → Diag. config. → Event category 833 (0225)
Description	Use this function to select the category assigned to diagnostic message 833 Electronic temperature too low .
Selection	<ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ No effect (N)
Factory setting	Out of specification (S)
Additional information	For a detailed description of the options available for selection: → 103


Event category 861 (Process fluid)



Navigation	Expert → Communication → Diag. config. → Event category 861 (0261)
Description	Use this function to select the category assigned to diagnostic message 861 Process fluid .
Selection	<ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ No effect (N)
Factory setting	Out of specification (S)

Additional information  For a detailed description of the options available for selection: →  103

Event category 862 (Empty pipe)

Navigation  Expert → Communication → Diag. config. → Event category 862 (0214)

Description Use this function to select the category assigned to diagnostic message **862 Empty pipe**.


Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional information  For a detailed description of the options available for selection: →  103

Event category 937 (EMC interference)

Navigation  Expert → Communication → Diag. config. → Event category 937 (0260)

Description Use this function to select the category assigned to diagnostic message **937 EMC interference**.

Selection


- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)


Additional information  For a detailed description of the options available for selection: →  103

3.5 "Application" submenu


Navigation  Expert → Application






Reset all totalizers

Navigation	 Expert → Application → Reset all tot. (2806)
Description	Use this function to reset all totalizers to the value 0 and restart the totaling process. This deletes all the flow values previously totalized.
Selection	<ul style="list-style-type: none"> ■ Cancel ■ Reset + totalize
Factory setting	Cancel
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Cancel No action is executed and the user exits the parameter. ■ Reset + totalize All totalizers are reset to 0 and the totaling process is restarted.





3.5.1 "Totalizer 1 to 3" submenu

Navigation  Expert → Application → Totalizer 1 to 3






Preset value 1 to 3 (0913-1 to 3)	→  112
Failure mode (0901-1 to 3)	→  113

Assign process variable

Navigation	  Expert → Application → Totalizer 1 to 3 → Assign variable (0914-1 to 3)
Description	Use this function to select a process variable for totalizer 1-3.
Selection	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Mass flow
Factory setting	Volume flow
Additional information	<p><i>Description</i></p> <p> If the option selected is changed, the device resets the totalizer to 0.</p> <p><i>Selection</i></p> <p>If the Off option is selected, only the Assign process variable parameter (→  110) is displayed in the Totalizer 1 to 3 submenu. All other parameters in the submenu are hidden.</p>

Unit totalizer

Navigation	  Expert → Application → Totalizer 1 to 3 → Unit totalizer (0915-1 to 3)		
Prerequisite	In the Assign process variable parameter (→  110), one of the following options is selected: <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow 		
Description	Use this function to select the unit for the process variable of totalizer 1-3.		
Selection	<table style="width: 100%; border: none;"> <tr> <td style="vertical-align: top;"> <i>SI units</i> <ul style="list-style-type: none"> ■ g ■ kg ■ t </td> <td style="vertical-align: top; padding-left: 20px;"> <i>US units</i> <ul style="list-style-type: none"> ■ oz ■ lb ■ STon </td> </tr> </table> <p><i>Custom-specific units</i> User mass</p> <p>or</p>	<i>SI units</i> <ul style="list-style-type: none"> ■ g ■ kg ■ t 	<i>US units</i> <ul style="list-style-type: none"> ■ oz ■ lb ■ STon
<i>SI units</i> <ul style="list-style-type: none"> ■ g ■ kg ■ t 	<i>US units</i> <ul style="list-style-type: none"> ■ oz ■ lb ■ STon 		

SI units

- cm³
- dm³
- m³
- ml
- l
- hl
- Ml Mega

US units

- af
- ft³
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;oil)
- bbl (us;tank)

Imperial units

- gal (imp)
- Mgal (imp)
- bbl (imp;beer)
- bbl (imp;oil)

Custom-specific units



User vol.

Factory setting


Country-specific:

- l
- gal (us)


Additional information*Description*

 The unit is selected separately for each totalizer. It is independent of the option selected in the **System units** submenu (→  45).


Selection

The selection depends on the process variable selected in the **Assign process variable** parameter (→  110).

Totalizer operation mode**Navigation**

 Expert → Application → Totalizer 1 to 3 → Operation mode (0908-1 to 3)

Prerequisite

In the **Assign process variable** parameter (→  110), one of the following options is selected:

- Volume flow
- Mass flow

Description

Use this function to select how the totalizer summates the flow.

Selection

- Net flow total
- Forward flow total
- Reverse flow total





Factory setting

Net flow total



Additional information*Selection*

- Net flow total
Positive and negative flow values are totalized and balanced against one another. Net flow is registered in the flow direction.
- Forward flow total
Only the flow in the forward flow direction is totalized.
- Reverse flow total
Only the flow against the forward flow direction is totalized (= reverse flow total).

Control Totalizer 1 to 3

Navigation	 Expert → Application → Totalizer 1 to 3 → Control Tot. 1 to 3 (0912-1 to 3)
Prerequisite	In the Assign process variable parameter (→  110), one of the following options is selected: <ul style="list-style-type: none"> ▪ Volume flow ▪ Mass flow
Description	Use this function to select the control of totalizer value 1-3.
Selection	<ul style="list-style-type: none"> ▪ Totalize ▪ Reset + hold ▪ Preset + hold ▪ Reset + totalize ▪ Preset + totalize
Factory setting	Totalize
Additional information	<i>Selection</i> <ul style="list-style-type: none"> ▪ Totalize The totalizer is started or continues totalizing with the current counter reading. ▪ Reset + hold The totaling process is stopped and the totalizer is reset to 0. ▪ Preset + hold The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter (→  112). ▪ Reset + totalize The totalizer is reset to 0 and the totaling process is restarted. ▪ Preset + totalize The totalizer is set to the defined start value in the Preset value parameter (→  112) and the totaling process is restarted.

Preset value 1 to 3

Navigation	 Expert → Application → Totalizer 1 to 3 → Preset value 1 to 3 (0913-1 to 3)
Prerequisite	In the Assign process variable parameter (→  110), one of the following options is selected: <ul style="list-style-type: none"> ▪ Volume flow ▪ Mass flow
Description	Use this function to enter a start value for totalizer 1-3.
User entry	Signed floating-point number
Factory setting	Country-specific: <ul style="list-style-type: none"> ▪ 0 l ▪ 0 gal (us)

Additional information*User entry*

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→  110).


Example

This configuration is suitable for applications such as iterative filling processes with a fixed batch quantity.

Failure mode**Navigation**

  Expert → Application → Totalizer 1 to 3 → Failure mode (0901–1 to 3)

Prerequisite

In the **Assign process variable** parameter (→  110), one of the following options is selected:

- Volume flow
- Mass flow

Description

Use this function to select how a totalizer behaves in an alarm condition.


Selection

- Stop
- Actual value
- Last valid value

Factory setting

Stop

Additional information*Description*



 This setting does not affect the error response mode of other totalizers and the outputs. This is specified in separate parameters.


Selection











- Stop
Totalizing is stopped in an alarm condition.
- Actual value
The totalizer continues to count based on the actual measured value; the error is ignored.
- Last valid value
The totalizer continues to count based on the last valid measured value before the error occurred.

3.6 "Diagnostics" submenu








Navigation

  Expert → Diagnostics






Previous diagnostics (0690)	→  115
Operating time from restart (0653)	→  116
Operating time (0652)	→  116
▶ Diagnostic list	→  116
▶ Event logbook	→  120
▶ Device information	→  122
▶ Data logging	→  126
▶ Min/max values	→  131
▶ Heartbeat	→  135
▶ Simulation	→  136





Actual diagnostics

Navigation	  Expert → Diagnostics → Actual diagnos. (0691)
Prerequisite	A diagnostic event has occurred.
Description	Use this function to display the current diagnostics message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>User interface</i></p> <p> Additional pending diagnostic messages can be viewed in the Diagnostic list submenu (→  116).</p> <p> Information on what is causing the diagnostic message, and remedy measures, can be viewed by pressing the -button.</p> <p><i>Example</i></p> <p>For the display format: S442 Frequency output</p>




Timestamp

Navigation	 Expert → Diagnostics → Timestamp (0667)
Description	Displays the operating time at which the current diagnostic message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>User interface</i></p> <p> The diagnostic message can be viewed via the Actual diagnostics parameter (→  114).</p> <p><i>Example</i></p> <p>For the display format: 24d12h13m00s</p>

Previous diagnostics

Navigation	  Expert → Diagnostics → Prev.diagnostics (0690)
Prerequisite	Two diagnostic events have already occurred.
Description	Use this function to display the diagnostic message last displayed before the current message.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>User interface</i></p> <p> Information on what is causing the diagnostic message, and remedy measures, can be viewed by pressing the -button.</p> <p><i>Example</i></p> <p>For the display format: △S442 Frequency output</p>


Timestamp

Navigation	 Expert → Diagnostics → Timestamp (0672)
Description	Displays the operating time of the last diagnostic message that occurred before the current message.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>User interface</i></p> <p> The diagnostic message can be viewed via the Previous diagnostics parameter (→  115).</p>


Example

For the display format:
24d12h13m00s

Operating time from restart






Navigation	 Expert → Diagnostics → Time fr. restart (0653)
Description	Use this function to display the time the device has been in operation since the last device restart.
User interface	Days (d), hours (h), minutes (m) and seconds (s)

Operating time




Navigation	 Expert → Diagnostics → Operating time (0652)
Description	Use this function to display the length of time the device has been in operation.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i> The maximum number of days is 9999, which is equivalent to 27 years.

3.6.1 "Diagnostic list" submenu




Navigation  Expert → Diagnostics → Diagnostic list

▶ Diagnostic list	
Diagnostics 1 (0692)	→  117
Diagnostics 2 (0693)	→  117
Diagnostics 3 (0694)	→  118
Diagnostics 4 (0695)	→  119
Diagnostics 5 (0696)	→  119




Diagnostics 1

Navigation	 Expert → Diagnostics → Diagnostic list → Diagnostics 1 (0692)
Description	Use this function to display the current diagnostics message with the highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>Examples</i></p> <p>For the display format:</p> <ul style="list-style-type: none"> ■  S442 Frequency output ■  F276 I/O module failure

Timestamp

Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp (0683)
Description	Displays the operating time at which the diagnostic message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>User interface</i></p> <p> The diagnostic message can be viewed via the Diagnostics 1 parameter (→  117).</p> <p><i>Example</i></p> <p>For the display format: 24d12h13m00s</p>

Diagnostics 2

Navigation	 Expert → Diagnostics → Diagnostic list → Diagnostics 2 (0693)
Description	Use this function to display the current diagnostics message with the second-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>Examples</i></p> <p>For the display format:</p> <ul style="list-style-type: none"> ■  S442 Frequency output ■  F276 I/O module failure



Timestamp

Navigation  Expert → Diagnostics → Diagnostic list → Timestamp (0684)

Description Displays the operating time at which the diagnostic message occurred.

User interface Days (d), hours (h), minutes (m) and seconds (s)



Additional information *User interface*

 The diagnostic message can be viewed via the **Diagnostics 2** parameter (→  117).

Example

For the display format:
24d12h13m00s

Diagnostics 3



Navigation   Expert → Diagnostics → Diagnostic list → Diagnostics 3 (0694)

Description Use this function to display the current diagnostics message with the third-highest priority.

User interface Symbol for diagnostic behavior, diagnostic code and short message.

Additional information *Examples*

For the display format:

-  S442 Frequency output
-  F276 I/O module failure



Timestamp

Navigation  Expert → Diagnostics → Diagnostic list → Timestamp (0685)

Description Displays the operating time at which the diagnostic message occurred.

User interface Days (d), hours (h), minutes (m) and seconds (s)




Additional information *User interface*

 The diagnostic message can be viewed via the **Diagnostics 3** parameter (→  118).




Example

For the display format:
24d12h13m00s




Diagnostics 4

Navigation	 Expert → Diagnostics → Diagnostic list → Diagnostics 4 (0695)
Description	Use this function to display the current diagnostics message with the fourth-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>Examples</i></p> <p>For the display format:</p> <ul style="list-style-type: none"> ■  S442 Frequency output ■  F276 I/O module failure


Timestamp



Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp (0686)
Description	Displays the operating time at which the diagnostic message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>User interface</i></p> <p> The diagnostic message can be viewed via the Diagnostics 4 parameter (→  119).</p> <p><i>Example</i></p> <p>For the display format: 24d12h13m00s</p>

Diagnostics 5

Navigation	 Expert → Diagnostics → Diagnostic list → Diagnostics 5 (0696)
Description	Use this function to display the current diagnostics message with the fifth-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>Examples</i></p> <p>For the display format:</p> <ul style="list-style-type: none"> ■  S442 Frequency output ■  F276 I/O module failure

Timestamp

Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp (0687)
Description	Displays the operating time at which the diagnostic message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i>


 The diagnostic message can be viewed via the **Diagnostics 5** parameter (→  119).

Example

For the display format:
24d12h13m00s


3.6.2 "Event logbook" submenu

Navigation  Expert → Diagnostics → Event logbook



Filter options



Navigation	 Expert → Diagnostics → Event logbook → Filter options (0705)
Description	Use this function to select the category whose event messages are displayed in the events list.
Selection	<ul style="list-style-type: none"> ▪ All ▪ Failure (F) ▪ Function check (C) ▪ Out of specification (S) ▪ Maintenance required (M) ▪ Information (I)
Factory setting	All


Additional information*Description*

The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:

- F = Failure
- C = Function Check
- S = Out of Specification
- M = Maintenance Required

"Event list" submenu*Navigation*

Expert → Diagnostics → Event logbook → Event list

**Event list****Navigation**

Expert → Diagnostics → Event logbook → Event list

Description

Use this function to display the history of event messages that have occurred in the category selected in the **Filter options** parameter (→ 120).

User interface

- For a "Category I" event message
Information event, short message, symbol for event recording and operating time when error occurred
- For a "Category F, C, S, M" event message (status signal)
Diagnostics code, short message, symbol for event recording and operating time when error occurred

Additional information*Description*

A maximum of 20 event messages are displayed in chronological order. If the advanced HistoROM function is enabled in the device, the event list can contain up to 100 entries.

The following symbols indicate whether an event has occurred or has ended:

- : Occurrence of the event
- : End of the event

Examples

For the display format:


- I1091 Configuration modified
 24d12h13m00s
- ΔS442 Frequency output
 01d04h12min30s



Additional information, such as remedial measures, can be called up via the key.











HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

 To order the **HistoROM advanced capabilities** application package, see the "Accessories" section of the "Technical Information" document.


3.6.3 "Device information" submenu

Navigation  Expert → Diagnostics → Device info

▶ Device information	
Device tag (0011)	→  122
Serial number (0009)	→  123
Firmware version (0010)	→  123
Device name (0013)	→  123
Order code (0008)	→  124
Extended order code 1 (0023)	→  124
Extended order code 2 (0021)	→  124
Extended order code 3 (0022)	→  125
Configuration counter (0233)	→  125
ENP version (0012)	→  125

Device tag

Navigation

 Expert → Diagnostics → Device info → Device tag (0011)

Description


Use this function to display a unique name for the measuring point so it can be identified quickly within the plant. The name is displayed in the header.

User interface

Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

Promag

Additional information*User interface*

 7 Header text

The number of characters displayed depends on the characters used.

A0013375

Serial number**Navigation**

 Expert → Diagnostics → Device info → Serial number (0009)

Description

Use this function to view the serial number of the measuring device. It can also be found on the nameplate of the sensor and transmitter.

User interface

Max. 11-digit character string comprising letters and numbers.

Additional information*Description***Uses of the serial number**

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer:
www.endress.com/deviceviewer

Firmware version**Navigation**

 Expert → Diagnostics → Device info → Firmware version (0010)

Description

Use this function to view the device firmware version installed.

User interface

Character string with the following format:
xx.yy.zz

Factory setting

01.01.zz

Device name**Navigation**

 Expert → Diagnostics → Device info → Device name (0013)


Description

Use this function to view the name of the transmitter. It can also be found on the nameplate of the transmitter.

User interface Character string composed of letters, numbers and certain punctuation marks.

Factory setting Promag

Order code

Navigation  Expert → Diagnostics → Device info → Order code (0008)


Description Use this function to display the device order code.

User interface Character string composed of letters, numbers and certain punctuation marks

Additional information *Description*

 The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.

The order code is generated from the extended order code, which defines all the device features of the product structure. In contrast, the device features cannot be read directly from the order code.

 **Uses of the order code**

- To order an identical spare device.
- To identify the device quickly and easily, e.g. when contacting Endress+Hauser.

Extended order code 1


Navigation  Expert → Diagnostics → Device info → Ext. order cd. 1 (0023)

Description For displaying the first part of the extended order code.
On account of length restrictions, the extended order code is split into a maximum of 3 parameters.

User interface Character string

Additional information *Description*


The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.

 The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.




Extended order code 2

Navigation  Expert → Diagnostics → Device info → Ext. order cd. 2 (0021)



Description For displaying the second part of the extended order code.

User interface	Character string
Additional information	For additional information, see Extended order code 1 parameter (→  124)



Extended order code 3

Navigation	  Expert → Diagnostics → Device info → Ext. order cd. 3 (0022)
Description	For displaying the third part of the extended order code.
User interface	Character string
Additional information	For additional information, see Extended order code 1 parameter (→  124)

Configuration counter











Navigation	  Expert → Diagnostics → Device info → Config. counter (0233)
Description	Displays the number of parameter modifications for the device. When the user changes a parameter setting, this counter is incremented.
User interface	0 to 65 535
Factory setting	0

ENP version





Navigation	  Expert → Diagnostics → Device info → ENP version (0012)
Description	Displays the version of the electronic nameplate.
Factory setting	2.02.00
Additional information	<p><i>Description</i></p> <p>This electronic nameplate stores a data record for device identification that includes more data than the nameplates attached to the outside of the device.</p>

3.6.4 "Data logging" submenu

Navigation  Expert → Diagnostics → Data logging

▶ Data logging		
Assign channel 1 (0851)	→ 	126
Assign channel 2 (0852)	→ 	127
Assign channel 3 (0853)	→ 	127
Assign channel 4 (0854)	→ 	128
Logging interval (0856)	→ 	128
Clear logging data (0855)	→ 	129
▶ Display channel 1	→ 	129
▶ Display channel 2	→ 	130
▶ Display channel 3	→ 	130
▶ Display channel 4	→ 	131

Assign channel 1


Navigation	 Expert → Diagnostics → Data logging → Assign chan. 1 (0851)
	 Expert → Diagnostics → Data logging → Assign chan. 1 (0851)
Prerequisite	The Extended HistoROM application package is available.  The software options currently enabled are displayed in the Software option overview parameter (→  38).
Description	Options for the assignment of a process variable to the data logging channel.
Selection	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Mass flow ■ Electronic temperature ■ Current output 1 ■ Current difference potential
Factory setting	Off

Additional information*Description*



A total of 1000 measured values can be logged. This means:

- 1000 data points if 1 logging channel is used
- 500 data points if 2 logging channels are used
- 333 data points if 3 logging channels are used
- 250 data points if 4 logging channels are used

Once the maximum number of data points is reached, the oldest data points in the data log are cyclically overwritten in such a way that the last 1000, 500, 333 or 250 measured values are always in the log (ring memory principle).

 The log contents are cleared if the option selected is changed.

Assign channel 2**Navigation**

-  Expert → Diagnostics → Data logging → Assign chan. 2 (0852)
-  Expert → Diagnostics → Data logging → Assign chan. 2 (0852)

Prerequisite

The **Extended HistoROM** application package is available.

 The software options currently enabled are displayed in the **Software option overview** parameter (→  38).

Description

Options for the assignment of a process variable to the data logging channel.



Selection

Picklist, see **Assign channel 1** parameter (→  126)

Factory setting



Off

Assign channel 3**Navigation**

-  Expert → Diagnostics → Data logging → Assign chan. 3 (0853)
-  Expert → Diagnostics → Data logging → Assign chan. 3 (0853)

Prerequisite

The **Extended HistoROM** application package is available.

 The software options currently enabled are displayed in the **Software option overview** parameter (→  38).

Description

Options for the assignment of a process variable to the data logging channel.

Selection

Picklist, see **Assign channel 1** parameter (→  126)

Factory setting

Off

Assign channel 4


Navigation	Expert → Diagnostics → Data logging → Assign chan. 4 (0854)
	Expert → Diagnostics → Data logging → Assign chan. 4 (0854)

Prerequisite The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter (→ 38).

Description Options for the assignment of a process variable to the data logging channel.

Selection Picklist, see **Assign channel 1** parameter (→ 126)

Factory setting Off

Logging interval


Navigation	Expert → Diagnostics → Data logging → Logging interval (0856)
	Expert → Diagnostics → Data logging → Logging interval (0856)

Prerequisite The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter (→ 38).

Description Use this function to enter the logging interval t_{\log} for data logging.

User entry 1.0 to 3 600.0 s

Factory setting 10.0 s

Additional information *Description*

This defines the interval between the individual data points in the data log, and thus the maximum loggable process time T_{\log} :

- If 1 logging channel is used: $T_{\log} = 1000 \times t_{\log}$
- If 2 logging channels are used: $T_{\log} = 500 \times t_{\log}$
- If 3 logging channels are used: $T_{\log} = 333 \times t_{\log}$
- If 4 logging channels are used: $T_{\log} = 250 \times t_{\log}$

Once this time elapses, the oldest data points in the data log are cyclically overwritten such that a time of T_{\log} always remains in the memory (ring memory principle).

The log contents are cleared if the length of the logging interval is changed.

Example

If 1 logging channel is used:

- $T_{\log} = 1000 \times 1 \text{ s} = 1\,000 \text{ s} \approx 15 \text{ min}$
- $T_{\log} = 1000 \times 10 \text{ s} = 10\,000 \text{ s} \approx 3 \text{ h}$
- $T_{\log} = 1000 \times 80 \text{ s} = 80\,000 \text{ s} \approx 1 \text{ d}$
- $T_{\log} = 1000 \times 3\,600 \text{ s} = 3\,600\,000 \text{ s} \approx 41 \text{ d}$

Clear logging data
**Navigation**

Expert → Diagnostics → Data logging → Clear logging (0855)

Expert → Diagnostics → Data logging → Clear logging (0855)

Prerequisite

The **Extended HistorOM** application package is available.



The software options currently enabled are displayed in the **Software option overview** parameter (→ 38).

Description

Option to clear the entire logging data.

Selection

- Cancel
- Clear data

Factory setting

Cancel

Additional information

Selection

- Cancel
The data is not cleared. All the data is retained.
- Clear data
The logging data is cleared. The logging process starts from the beginning.

"Display channel 1" submenu

Navigation



Expert → Diagnostics → Data logging → Displ.channel 1



Display channel 1
Navigation

Expert → Diagnostics → Data logging → Displ.channel 1


Prerequisite

In the **Assign channel 1** parameter (→ 126), one of the following options is selected:

- Volume flow
- Mass flow
- Electronic temperature
- Current output 1
- Current difference potential


Description

Use this function to view the measured value trend for the logging channel in the form of a chart.


Additional information*Description*

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

"Display channel 2" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 2

**Display channel 2****Navigation**

 Expert → Diagnostics → Data logging → Displ.channel 2

Prerequisite


In the **Assign channel 2** parameter, one of the following options is selected:


- Volume flow
- Mass flow
- Electronic temperature
- Current output 1
- Current difference potential

Description


See the **Display channel 1** parameter →  129

"Display channel 3" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 3



Display channel 3


Navigation  Expert → Diagnostics → Data logging → Displ.channel 3

Prerequisite In the **Assign channel 3** parameter, one of the following options is selected:

- Volume flow
- Mass flow
- Electronic temperature
- Current output 1
- Current difference potential


Description See the **Display channel 1** parameter →  129

"Display channel 4" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 4



Display channel 4

Navigation  Expert → Diagnostics → Data logging → Displ.channel 4


Prerequisite In the **Assign channel 4** parameter, one of the following options is selected:

- Volume flow
- Mass flow
- Electronic temperature
- Current output 1
- Current difference potential

Description See the **Display channel 1** parameter →  129

3.6.5 "Min/max values" submenu

Navigation   Expert → Diagnostics → Min/max val.



▶ Terminal voltage	→ 132
▶ Main electronic temperature	→ 133
▶ IO module temperature	→ 134

Reset min/max values
**Navigation**

Expert → Diagnostics → Min/max val. → Reset min/max (6541)

Description

Use this function to select measured variables whose minimum, maximum and average measured values are to be reset.

Selection

- Cancel
- Terminal voltage
- IO module temperature

Factory setting

Cancel

"Terminal voltage" submenu

Navigation Expert → Diagnostics → Min/max val. → Terminal volt.

▶ Terminal voltage	
Minimum value (0689)	→ 132
Maximum value (0663)	→ 133
Average value (0698)	→ 133

Minimum value
Navigation

Expert → Diagnostics → Min/max val. → Terminal volt. → Minimum value (0689)


Description

Use this function to display the smallest previously measured terminal voltage value in Volts.


User interface

0.0 to 50.0 V


Maximum value



Navigation	 Expert → Diagnostics → Min/max val. → Terminal volt. → Maximum value (0663)
Description	Use this function to view the largest previously measured terminal voltage value in Volts.
User interface	0.0 to 50.0 V

Average value


Navigation	 Expert → Diagnostics → Min/max val. → Terminal volt. → Average value (0698)
Description	Use this function to view the average of all previously measured terminal voltage values in Volts.
User interface	Signed floating-point number

"Main electronic temperature" submenu


Navigation  Expert → Diagnostics → Min/max val. → Main elect.temp.

▶ Main electronic temperature	
Minimum value (6547)	→  133
Maximum value (6545)	→  134




Minimum value

Navigation	 Expert → Diagnostics → Min/max val. → Main elect.temp. → Minimum value (6547)
Description	Use this function to view the lowest previously measured temperature value of the main electronics module.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>







The unit is taken from the **Temperature unit** parameter (→  49).

Maximum value




Navigation	 Expert → Diagnostics → Min/max val. → Main elect.temp. → Maximum value (6545)
Description	Use this function to view the highest previously measured temperature value of the main electronics module.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  49).

"IO module temperature" submenu




Navigation  Expert → Diagnostics → Min/max val. → IO module temp.

▶ IO module temperature	
Minimum value (0688)	→  134
Maximum value (0665)	→  135
Average value (0697)	→  135




Minimum value

Navigation	 Expert → Diagnostics → Min/max val. → IO module temp. → Minimum value (0688)
Description	Use this function to view the lowest previously measured temperature value of the I/O electronics module.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  49).


Maximum value

Navigation	 Expert → Diagnostics → Min/max val. → IO module temp. → Maximum value (0665)
Description	Use this function to view the highest previously measured temperature value of the I/O electronics module.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  49).


Average value

Navigation	 Expert → Diagnostics → Min/max val. → IO module temp. → Average value (0697)
Description	Use this function to view the average value of all previously measured temperature values of the I/O electronics module.
User interface	-1273.15 to 726.85 °C
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  49).

3.6.6 "Heartbeat" submenu














 For detailed information on the parameter descriptions of the **Heartbeat Verification** application package, see the Special Documentation for the device

Navigation  Expert → Diagnostics → Heartbeat




3.6.7 "Simulation" submenu

Navigation  Expert → Diagnostics → Simulation

▶ Simulation	
Assign simulation process variable (1810)	→  136
Process variable value (1811)	→  137
Simulation current output 1 (0354-1)	→  137
Value current output 1 (0355-1)	→  138
Frequency output simulation (0472)	→  138
Frequency value (0473)	→  138
Pulse output simulation (0458)	→  139
Pulse value (0459)	→  139
Switch output simulation (0462)	→  140
Switch status (0463)	→  140
Simulation device alarm (0654)	→  141
Diagnostic event category (0738)	→  141
Diagnostic event simulation (0737)	→  141

Assign simulation process variable














Navigation  Expert → Diagnostics → Simulation → Assign proc.var. (1810)

Description Use this function to select a process variable for the simulation process that is activated. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.



Selection

- Off
- Volume flow
- Mass flow





Factory setting Off


Additional information	<p><i>Description</i></p> <p> The simulation value of the selected process variable is defined in the Process variable value parameter (→  137).</p>
<hr/>	
Process variable value 	
Navigation	  Expert → Diagnostics → Simulation → Proc. var. value (1811)
Prerequisite	<p>In the Assign simulation process variable parameter (→  136), one of the following options is selected:</p> <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow
Description	Use this function to enter a simulation value for the selected process variable. Subsequent measured value processing and the signal output use this simulation value. In this way, users can verify whether the measuring device has been configured correctly.
User entry	Depends on the process variable selected
Factory setting	0
Additional information	<p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→  45).</p>
<hr/>	
Simulation current output 1 	
Navigation	  Expert → Diagnostics → Simulation → Sim.curr.out. 1 (0354-1)
Description	Use this function to switch simulation of the current output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none"> ■ Off ■ On
Factory setting	Off
Additional information	<p><i>Description</i></p> <p> The desired simulation value is defined in the Value current output 1 parameter (→  138).</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Off Current simulation is switched off. The device is in normal measuring mode or another process variable is being simulated. ■ On Current simulation is active.



Value current output 1


Navigation	 Expert → Diagnostics → Simulation → Value curr.out 1 (0355-1)
Prerequisite	The On option is selected in the Simulation current output 1 parameter (→  137).
Description	Use this function to enter a current value for the simulation. In this way, users can verify the correct adjustment of the current output and the correct function of downstream switching units.
User entry	3.59 to 22.5 mA

Frequency output simulation


Navigation	 Expert → Diagnostics → Simulation → Freq.outp.sim. (0472)
Prerequisite	The Frequency option is selected in the Operating mode parameter (→  79).
Description	Use this function to switch simulation of the frequency output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ On
Factory setting	Off
Additional information	<p><i>Description</i></p> <p> The desired simulation value is defined in the Frequency value parameter (→  138).</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Off Current simulation is switched off. The device is in normal measuring mode or another process variable is being simulated. ▪ On Current simulation is active.

Frequency value


Navigation	 Expert → Diagnostics → Simulation → Freq. value (0473)
Prerequisite	The On option is selected in the Frequency output simulation parameter (→  138).
Description	Use this function to enter a frequency value for the simulation. In this way, users can verify the correct adjustment of the frequency output and the correct function of downstream switching units.

User entry 0.0 to 1 250.0 Hz

Factory setting 0.0 Hz

Pulse output simulation

Navigation   Expert → Diagnostics → Simulation → Puls.outp.sim. (0458)

Prerequisite The **Pulse** option is selected in the **Operating mode** parameter (→  79).

Description Use this function to switch simulation of the pulse output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection



- Off
- Fixed value
- Down-counting value

Factory setting Off



Additional information *Description*


 The desired simulation value is defined in the **Pulse value** parameter (→  139).

Selection

- Off
Pulse simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- Fixed value
Pulses are continuously output with the pulse width specified in the **Pulse width** parameter (→  80).
- Down-counting value
The pulses specified in the **Pulse value** parameter (→  139) are output.

Pulse value









Navigation   Expert → Diagnostics → Simulation → Pulse value (0459)

Prerequisite The **Down-counting value** option is selected in the **Pulse output simulation** parameter (→  139).

Description Use this function to enter a pulse value for the simulation. In this way, users can verify the correct adjustment of the pulse output and the correct function of downstream switching units.

User entry 0 to 65 535

Factory setting 0

Switch output simulation 	
Navigation	 Expert → Diagnostics → Simulation → Switch sim. (0462)
Prerequisite	The Switch option is selected in the Operating mode parameter (→  79).
Description	Use this function to switch simulation of the switch output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ On
Factory setting	Off
Additional information	<p><i>Description</i></p> <p> The desired simulation value is defined in the Switch status parameter (→  140).</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Off Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated. ▪ On Switch simulation is active.
Switch status 	
Navigation	 Expert → Diagnostics → Simulation → Switch status (0463)
Prerequisite	The On option is selected in the Switch output simulation parameter (→  140).
Description	Use this function to select a switch value for the simulation. In this way, users can verify the correct adjustment of the switch output and the correct function of downstream switching units.
Selection	<ul style="list-style-type: none"> ▪ Open ▪ Closed
Factory setting	Open
Additional information	<p><i>Options</i></p> <ul style="list-style-type: none"> ▪ Open Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated. ▪ Closed Switch simulation is active.

Simulation device alarm


Navigation	Expert → Diagnostics → Simulation → Sim. alarm (0654)
Description	Use this function to switch the device alarm on and off. In this way, users can verify the correct adjustment of the current output and the correct function of downstream switching units. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ On
Factory setting	Off

Diagnostic event category


Navigation	Expert → Diagnostics → Simulation → Event category (0738)
Description	Use this function to select the category of the diagnostic events that are displayed for the simulation in the Diagnostic event simulation parameter (→ 141).
Selection	<ul style="list-style-type: none"> ▪ Sensor ▪ Electronics ▪ Configuration ▪ Process
Factory setting	Process

Diagnostic event simulation


Navigation	Expert → Diagnostics → Simulation → Diag. event sim. (0737)
Description	Use this function to select a diagnostic event for the simulation process that is activated.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Diagnostic event picklist (depends on the category selected)
Factory setting	Off
Additional information	<p><i>Description</i></p> <p> For the simulation, you can choose from the diagnostic events of the category selected in the Diagnostic event category parameter (→ 141).</p>

4 Country-specific factory settings


4.1 SI units

 Not valid for USA and Canada.

4.1.1 System units

Mass	kg
Mass flow	kg/h
Volume	m ³
Volume flow	l/h
Density	kg/l
Temperature	°C

4.1.2 Full scale values

 The factory settings apply to the following parameters:


- 20 mA value (full scale value of the current output)
- 100% bar graph value 1
- 100% bar graph value 3

Nominal diameter [mm]	Full scale value current output (v ~ 2.5 m/s) [dm ³ /min]
2	0.5
4	2
8	8
15	25
25	75
32	125
40	200
50	300
65	500
80	750
100	1200
125	1850
150	150 m ³ /h
200	300 m ³ /h

4.1.3 Output current span

Current output 1	4 to 20 mA NAMUR
------------------	------------------

4.1.4 On value low flow cut off

 The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [mm]	On value low flow cut off ($v \sim 0.04$ m/s) [m ³ /h]
2	0.01
4	0.05
8	0.1
15	0.5
25	1
32	2
40	3
50	5
65	8
80	12
100	20
125	30
150	2.5
200	5


4.2 US units

 Only valid for USA and Canada.

4.2.1 System units

Mass	lb
Mass flow	lb/min
Volume	gal (us)
Volume flow	gal/min (us)
Density	lb/ft ³
Temperature	°F

4.2.2 Full scale values

 The factory settings apply to the following parameters:

- 20 mA value (full scale value of the current output)
- 100% bar graph value 1
- 100% bar graph value 3


Nominal diameter [in]	Full scale value current output ($v \sim 2.5$ m/s) [gal/min]
$\frac{1}{12}$	0.1
$\frac{1}{8}$	0.5
$\frac{3}{8}$	2
$\frac{1}{2}$	6
1	18
$1\frac{1}{2}$	50

Nominal diameter [in]	Full scale value current output ($v \sim 2.5$ m/s) [gal/min]
2	75
3	200
4	300
6	600
8	1200

4.2.3 Output current span

Current output 1	4 to 20 mA US
------------------	---------------

4.2.4 On value low flow cut off

 The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [in]	On value low flow cut off ($v \sim 0.04$ m/s) [gal/min]
$\frac{1}{12}$	0.002
$\frac{1}{8}$	0.008
$\frac{3}{8}$	0.025
$\frac{1}{2}$	0.1
1	0.25
$1\frac{1}{2}$	0.75
2	1.25
3	2.5
4	4
6	12
8	15

5 Explanation of abbreviated units

5.1 SI units

Process variable	Units	Explanation
Density	g/cm ³ , g/m ³	Gram/volume unit
	kg/dm ³ , kg/l, kg/m ³	Kilogram/volume unit
	SD4°C, SD15°C, SD20°C	Specific density: The specific density is the ratio of the density of the fluid to the density of water at a water temperature of 4 °C (39 °F), 15 °C (59 °F), 20 °C (68 °F).
	SG4°C, SG15°C, SG20°C	Specific gravity: The specific gravity is the ratio of the density of the fluid to the density of water at a water temperature of 4 °C (39 °F), 15 °C (59 °F), 20 °C (68 °F).
Mass	g, kg, t	Gram, kilogram, metric ton
Mass flow	g/s, g/min, g/h, g/d	Gram/time unit
	kg/s, kg/min, kg/h, kg/d	Kilogram/time unit
	t/s, t/min, t/h, t/d	Metric ton/time unit
Temperature	°C, °F, K, °R	Celsius, Fahrenheit, Kelvin, Rankine
Volume	cm ³ , dm ³ , m ³	Cubic centimeter, cubic decimeter, cubic meter,
	ml, l, hl, Ml	Milliliter, liter, hectoliter, megaliter
Volume flow	cm ³ /s, cm ³ /min, cm ³ /h, cm ³ /d	Cubic centimeter/time unit
	dm ³ /s, dm ³ /min, dm ³ /h, dm ³ /d	Cubic decimeter/time unit
	m ³ /s, m ³ /min, m ³ /h, m ³ /d	Cubic meter/time unit
	ml/s, ml/min, ml/h, ml/d	Milliliter/time unit
	l/s, l/min, l/h, l/d	Liter/time unit
Time	s, min, h, d	Second, minute, hour, day

5.2 US units

Process variable	Units	Explanation
Density	lb/ft ³ , lb/gal (us)	Pound/cubic foot, pound/gallon
	lb/bbl (us;liq.), lb/bbl (us;beer), lb/bbl (us;oil), lb/bbl (us;tank)	Pound/volume unit
Mass	oz, lb, STon	Ounce, pound, standard ton
Mass flow	oz/s, oz/min, oz/h, oz/d	Ounce/time unit
	lb/s, lb/min, lb/h, lb/d	Pound/time unit
	STon/s, STon/min, STon/h, STon/d	Standard ton/time unit
Temperature	°C, °F, K, °R	Celsius, Fahrenheit, Kelvin, Rankine
Volume	af, ft ³	Acre foot, cubic foot
	fl oz (us), gal (us), kgal (us), Mgal (us)	Fluid ounce, gallon, kilogallon, million gallon
	bbl (us;liq.), bbl (us;beer), bbl (us;oil), bbl (us;tank)	Barrel (normal liquids), barrel (beer), barrel (petrochemicals), barrel (filling tanks)
Volume flow	af/s, af/min, af/h, af/d	Acre foot/time unit
	ft ³ /s, ft ³ /min, ft ³ /h, ft ³ /d	Cubic foot/time unit

Process variable	Units	Explanation
	fl oz/s (us), fl oz/min (us), fl oz/h (us), fl oz/d (us)	Fluid ounce/time unit
	gal/s (us), gal/min (us), gal/h (us), gal/d (us)	Gallon/time unit
	kgal/s (us), kgal/min (us), kgal/h (us), kgal/d (us)	Kilogallon/time unit
	Mgal/s (us), Mgal/min (us), Mgal/h (us), Mgal/d (us)	Million gallon/time unit
	bbbl/s (us;liq.), bbl/min (us;liq.), bbl/h (us;liq.), bbl/d (us;liq.)	Barrel/time unit (normal liquids) Normal liquids: 31.5 gal/bbl
	bl/s (us;beer), bbl/min (us;beer), bbl/h (us;beer), bbl/d (us;beer)	Barrel /time unit (beer) beer: 31.0 gal/bbl
	bbl/s (us;oil), bbl/min (us;oil), bbl/h (us;oil), bbl/d (us;oil)	Barrel /time unit (petrochemicals) Petrochemicals: 42.0 gal/bbl
	bbl/s (us;tank), bbl/min (us;tank), bbl/h (us;tank), bbl/d (us;tank)	Barrel/time unit (filling tank) Filling tanks: 55.0 gal/bbl
Time	s, min, h, d	Second, minute, hour, day

5.3 Imperial units

Process variable	Units	Explanation
Density	lb/gal (imp), lb/bbl (imp;beer), lb/bbl (imp;oil)	Pound/volume unit
Temperature	°C, °F, K, °R	Celsius, Fahrenheit, Kelvin, Rankine
Volume	gal (imp), Mgal (imp), bbl (imp;oil)	Gallon, mega gallon, barrel (petrochemicals), barrel (beer)
Volume flow	gal/s (imp), gal/min (imp), gal/h (imp), gal/d (imp)	Gallon/time unit
	Mgal/s (imp), Mgal/min (imp), Mgal/h (imp), Mgal/d (imp)	Mega gallon/time unit
	bbl/s (imp;oil), bbl/min (imp;oil), bbl/h (imp;oil), bbl/d (imp;oil)	Barrel/time unit (petrochemicals) Petrochemicals: 34.97 gal/bbl
Time	s, min, h, d	Second, minute, hour, day

Index

0 ... 9

0% bargraph value 1 (Parameter)	17
0% bargraph value 3 (Parameter)	20
4 mA value (Parameter)	68
20 mA value (Parameter)	70
100% bargraph value 1 (Parameter)	17
100% bargraph value 3 (Parameter)	20

A

Access status display (Parameter)	11, 25
Access status tooling (Parameter)	12
Activate sensor emergency mode (Parameter)	38
Activate SW option (Parameter)	38
Actual diagnostics (Parameter)	114
Administration (Submenu)	35
Alarm delay (Parameter)	29
Application (Submenu)	109
Assign behavior of diagnostic no. 004 (Parameter)	31
Assign behavior of diagnostic no. 441 (Parameter)	31
Assign behavior of diagnostic no. 442 (Parameter)	31
Assign behavior of diagnostic no. 443 (Parameter)	32
Assign behavior of diagnostic no. 531 (Parameter)	32
Assign behavior of diagnostic no. 801 (Parameter)	33
Assign behavior of diagnostic no. 832 (Parameter)	33
Assign behavior of diagnostic no. 833 (Parameter)	33
Assign behavior of diagnostic no. 861 (Parameter)	34
Assign behavior of diagnostic no. 862 (Parameter)	34
Assign behavior of diagnostic no. 937 (Parameter)	34
Assign channel 1 (Parameter)	126
Assign channel 2 (Parameter)	127
Assign channel 3 (Parameter)	127
Assign channel 4 (Parameter)	128
Assign current output (Parameter)	66
Assign diagnostic behavior (Parameter)	86
Assign flow direction check (Parameter)	87
Assign frequency output (Parameter)	82
Assign limit (Parameter)	86
Assign process variable (Parameter)	55, 110
Assign pulse output (Parameter)	79
Assign PV (Parameter)	101
Assign QV (Parameter)	103
Assign simulation process variable (Parameter)	136
Assign status (Parameter)	87
Assign SV (Parameter)	101
Assign TV (Parameter)	102
Average value (Parameter)	133, 135

B

Backlight (Parameter)	25
Backup state (Parameter)	27
Burst command 1 to 3 (Parameter)	92
Burst configuration 1 to 3 (Submenu)	91
Burst mode 1 to 3 (Parameter)	92
Burst trigger level (Parameter)	96
Burst trigger mode (Parameter)	95
Burst variable 0 (Parameter)	93

Burst variable 1 (Parameter)	94
Burst variable 2 (Parameter)	94
Burst variable 3 (Parameter)	94
Burst variable 4 (Parameter)	94
Burst variable 5 (Parameter)	95
Burst variable 6 (Parameter)	95
Burst variable 7 (Parameter)	95

C

Calculated values (Submenu)	61
Calibration (Submenu)	64
Calibration factor (Parameter)	65
Clear logging data (Parameter)	129
Communication (Submenu)	89
Comparison result (Parameter)	28
Configuration (Submenu)	90
Configuration backup display (Submenu)	26
Configuration counter (Parameter)	125
Configuration management (Parameter)	26
Confirm access code (Parameter)	36
Contrast display (Parameter)	24
Control Totalizer 1 to 3 (Parameter)	112
Current output 1 (Submenu)	66
Current span (Parameter)	67

D

Damping output (Parameter)	74, 84
Data logging (Submenu)	126
Date/time format (Parameter)	50
Decimal places 1 (Parameter)	18
Decimal places 2 (Parameter)	19
Decimal places 3 (Parameter)	20
Decimal places 4 (Parameter)	21
Define access code (Parameter)	35, 36
Define access code (Wizard)	35
Density unit (Parameter)	49
Device ID (Parameter)	98
Device information (Submenu)	122
Device name (Parameter)	123
Device reset (Parameter)	37
Device revision (Parameter)	97
Device tag (Parameter)	90, 122
Device type (Parameter)	98
Diagnostic behavior (Submenu)	30
Diagnostic configuration (Submenu)	103
Diagnostic event category (Parameter)	141
Diagnostic event simulation (Parameter)	141
Diagnostic handling (Submenu)	29
Diagnostic list (Submenu)	116
Diagnostics (Submenu)	113
Diagnostics 1 (Parameter)	117
Diagnostics 2 (Parameter)	117
Diagnostics 3 (Parameter)	118
Diagnostics 4 (Parameter)	119
Diagnostics 5 (Parameter)	119
Direct access	

- 0% bargraph value 1 (0123) 17
- 0% bargraph value 3 (0124) 20
- 4 mA value
 - Current output 1 (0367-1) 68
- 20 mA value
 - Current output 1 (0372-1) 70
- 100% bargraph value 1 (0125) 17
- 100% bargraph value 3 (0126) 20
- Access status display (0091) 11, 25
- Access status tooling (0005) 12
- Activate sensor emergency mode (6611) 38
- Activate SW option (0029) 38
- Actual diagnostics (0691) 114
- Alarm delay (0651) 29
- Assign behavior of diagnostic no. 004 (0734) 31
- Assign behavior of diagnostic no. 441 (0657) 31
- Assign behavior of diagnostic no. 442 (0658) 31
- Assign behavior of diagnostic no. 443 (0659) 32
- Assign behavior of diagnostic no. 531 (0733) 32
- Assign behavior of diagnostic no. 801 (0660) 33
- Assign behavior of diagnostic no. 832 (0675) 33
- Assign behavior of diagnostic no. 833 (0676) 33
- Assign behavior of diagnostic no. 861 (0736) 34
- Assign behavior of diagnostic no. 862 (0679) 34
- Assign behavior of diagnostic no. 937 (0735) 34
- Assign channel 1 (0851) 126
- Assign channel 2 (0852) 127
- Assign channel 3 (0853) 127
- Assign channel 4 (0854) 128
- Assign current output
 - Current output 1 (0359-1) 66
- Assign diagnostic behavior (0482) 86
- Assign flow direction check (0484) 87
- Assign frequency output (0478) 82
- Assign limit (0483) 86
- Assign process variable
 - Totalizer 1 to 3 (0914-1 to 3) 110
- Assign process variable (1837) 55
- Assign pulse output (0460) 79
- Assign PV (0234) 101
- Assign QV (0237) 103
- Assign simulation process variable (1810) 136
- Assign status (0485) 87
- Assign SV (0235) 101
- Assign TV (0236) 102
- Average value (0697) 135
- Average value (0698) 133
- Backlight (0111) 25
- Backup state (0121) 27
- Burst command 1 to 3 (2031-1 to 3) 92
- Burst mode 1 to 3 (2032-1 to 3) 92
- Burst trigger level
 - Burst configuration 1 to 3 (2043-1 to 3) 96
- Burst trigger mode
 - Burst configuration 1 to 3 (2044-1 to 3) 95
- Burst variable 0
 - Burst configuration 1 to 3 (2033-1 to 3) 93
- Burst variable 1
 - Burst configuration 1 to 3 (2034-1 to 3) 94
- Burst variable 2
 - Burst configuration 1 to 3 (2035-1 to 3) 94
- Burst variable 3
 - Burst configuration 1 to 3 (2036-1 to 3) 94
- Burst variable 4
 - Burst configuration 1 to 3 (2037-1 to 3) 94
- Burst variable 5
 - Burst configuration 1 to 3 (2038-1 to 3) 95
- Burst variable 6
 - Burst configuration 1 to 3 (2039-1 to 3) 95
- Burst variable 7
 - Burst configuration 1 to 3 (2040-1 to 3) 95
- Calibration factor (6522) 65
- Clear logging data (0855) 129
- Comparison result (0103) 28
- Configuration counter (0233) 125
- Configuration management (0100) 26
- Confirm access code 36
- Contrast display (0105) 24
- Control Totalizer 1 to 3 (0912-1 to 3) 112
- Current span
 - Current output 1 (0353-1) 67
- Damping output
 - Current output 1 (0363-1) 74
- Damping output (0477) 84
- Date/time format (2812) 50
- Decimal places 1 (0095) 18
- Decimal places 2 (0117) 19
- Decimal places 3 (0118) 20
- Decimal places 4 (0119) 21
- Define access code 35
- Define access code (0093) 36
- Density unit (0555) 49
- Device ID (0221) 98
- Device name (0013) 123
- Device reset (0000) 37
- Device revision (0204) 97
- Device tag (0011) 122
- Device tag (0215) 90
- Device type (0209) 98
- Diagnostic event category (0738) 141
- Diagnostic event simulation (0737) 141
- Diagnostics 1 (0692) 117
- Diagnostics 2 (0693) 117
- Diagnostics 3 (0694) 118
- Diagnostics 4 (0695) 119
- Diagnostics 5 (0696) 119
- Direct access (0106) 10
- Display damping (0094) 22
- Display interval (0096) 22
- Empty pipe adjust value (6527) 59
- Empty pipe detection (1860) 58
- ENP version (0012) 125
- Enter access code (0003) 13
- Enter access code (0092) 12
- Event category 004 (0238) 104
- Event category 441 (0210) 105
- Event category 442 (0230) 105
- Event category 443 (0231) 105

Event category 531 (0262)	106	Measured value EPD (6559)	59
Event category 801 (0232)	106	Measuring mode	
Event category 832 (0218)	107	Current output 1 (0351-1)	70
Event category 833 (0225)	107	Measuring mode (0457)	80
Event category 861 (0261)	107	Measuring mode (0479)	84
Event category 862 (0214)	108	Measuring period (6536)	62
Event category 937 (0260)	108	Measuring value at maximum frequency (0475) . .	83
Extended order code 1 (0023)	124	Measuring value at minimum frequency (0476) . .	83
Extended order code 2 (0021)	124	Min. update period	
Extended order code 3 (0022)	125	Burst configuration 1 to 3 (2042-1 to 3)	96
Failure current		Minimum frequency value (0453)	82
Current output 1 (0352-1)	76	Minimum value (0688)	134
Failure frequency (0474)	85	Minimum value (0689)	132
Failure mode		Minimum value (6547)	133
Current output 1 (0364-1)	75	New adjustment (6560)	60
Totalizer 1 to 3 (0901-1 to 3)	113	No. of preambles (0217)	91
Failure mode (0451)	84	Nominal diameter (2807)	64
Failure mode (0480)	81	Off value low flow cutoff (1804)	55
Failure mode (0486)	88	On value low flow cutoff (1805)	55
Filter options (0705)	120	Operating mode (0469)	79
Firmware version (0010)	123	Operating time (0652)	26, 116
Fixed current		Operating time from restart (0653)	116
Current output 1 (0365-1)	68	Order code (0008)	124
Fixed density (1862)	61	Output current 1 (0361-1)	43, 76
Flow damping (6661)	54	Output frequency (0471)	45, 85
Flow override (1839)	53	Preset value 1 to 3 (0913-1 to 3)	112
Format display (0098)	15	Pressure shock suppression (1806)	56
Frequency output simulation (0472)	138	Previous diagnostics (0690)	115
Frequency value (0473)	138	Primary variable (PV) (0201)	101
Full pipe adjust value (6548)	59	Process variable value (1811)	137
Hardware revision (0206)	99	Progress (6571)	60
HART address (0219)	90	Pulse output (0456)	44, 81
HART date code (0202)	100	Pulse output simulation (0458)	139
HART descriptor (0212)	99	Pulse value (0459)	139
HART message (0216)	99	Pulse width (0452)	80
HART revision (0205)	99	Quaternary variable (QV) (0203)	103
HART short tag (0220)	90	Reset all totalizers (2806)	109
Header (0097)	23	Reset min/max values (6541)	132
Header text (0112)	23	Reset write protection (0019)	39
Installation direction (1809)	62	Response time empty pipe detection (1859)	58
Integration time (6533)	62	Secondary variable (SV) (0226)	102
Invert output signal (0470)	89	Separator (0101)	24
Language (0104)	14	Serial number (0009)	123
Last backup (0102)	26	Simulation current output 1 (0354-1)	137
Locking status (0004)	11	Simulation device alarm (0654)	141
Logging interval (0856)	128	Software option overview (0015)	38
Manufacturer ID (0259)	98	Software revision (0224)	100
Mass flow (1847)	41	Start-up current	
Mass flow factor (1846)	64	Current output 1 (0369-1)	77
Mass flow offset (1841)	64	Start-up mode	
Mass flow unit (0554)	47	Current output 1 (0368-1)	76
Mass unit (0574)	48	Switch output function (0481)	85
Max. update period		Switch output simulation (0462)	140
Burst configuration 1 to 3 (2041-1 to 3)	97	Switch point empty pipe detection (6562)	58
Maximum frequency value (0454)	82	Switch status (0461)	45, 88
Maximum value (0663)	133	Switch status (0463)	140
Maximum value (0665)	135	Switch-off delay (0465)	88
Maximum value (6545)	134	Switch-off value (0464)	87
Measured current 1 (0366-1)	43, 77	Switch-on delay (0467)	88

- Switch-on value (0466) 86
- Temperature unit (0557) 49
- Terminal voltage 1
 - Current output 1 (0662-1) 77
- Terminal voltage 1 (0662) 44
- Tertiary variable (TV) (0228) 102
- Timestamp (0667) 115
- Timestamp (0672) 115
- Timestamp (0683) 117
- Timestamp (0684) 118
- Timestamp (0685) 118
- Timestamp (0686) 119
- Timestamp (0687) 120
- Totalizer operation mode
 - Totalizer 1 to 3 (0908-1 to 3) 111
- Totalizer overflow 1 to 3 (0910-1 to 3) 42
- Totalizer value 1 to 3 (0911-1 to 3) 41
- Unit totalizer
 - Totalizer 1 to 3 (0915-1 to 3) 110
- User mass factor (0561) 53
- User mass offset (0562) 52
- User mass text (0560) 52
- User volume factor (0568) 52
- User volume offset (0569) 51
- User volume text (0567) 51
- Value 1 display (0107) 16
- Value 2 display (0108) 18
- Value 3 display (0110) 19
- Value 4 display (0109) 21
- Value current output 1 (0355-1) 138
- Value per pulse (0455) 80
- Volume flow (1838) 40
- Volume flow factor (1832) 63
- Volume flow offset (1831) 63
- Volume flow unit (0553) 46
- Volume unit (0563) 47
- Zero point (6546) 65
- Direct access (Parameter) 10
- Display (Submenu) 13
- Display channel 1 (Submenu) 129
- Display channel 2 (Submenu) 130
- Display channel 3 (Submenu) 130
- Display channel 4 (Submenu) 131
- Display damping (Parameter) 22
- Display interval (Parameter) 22
- Document
 - Explanation of the structure of a parameter
 - description 6
 - Function 4
 - Structure 4
 - Symbols used 6
 - Target group 4
 - Using the document 4
- Document function 4
- E**
 - Empty pipe adjust (Wizard) 60
 - Empty pipe adjust value (Parameter) 59
 - Empty pipe detection (Parameter) 58
 - Empty pipe detection (Submenu) 57
 - ENP version (Parameter) 125
 - Enter access code (Parameter) 12, 13
 - Event category 004 (Parameter) 104
 - Event category 441 (Parameter) 105
 - Event category 442 (Parameter) 105
 - Event category 443 (Parameter) 105
 - Event category 531 (Parameter) 106
 - Event category 801 (Parameter) 106
 - Event category 832 (Parameter) 107
 - Event category 833 (Parameter) 107
 - Event category 861 (Parameter) 107
 - Event category 862 (Parameter) 108
 - Event category 937 (Parameter) 108
 - Event list (Submenu) 121
 - Event logbook (Submenu) 120
 - Extended order code 1 (Parameter) 124
 - Extended order code 2 (Parameter) 124
 - Extended order code 3 (Parameter) 125
- F**
 - Factory settings 142
 - SI units 142
 - US units 143
 - Failure current (Parameter) 76
 - Failure frequency (Parameter) 85
 - Failure mode (Parameter) 75, 81, 84, 88, 113
 - Filter options (Parameter) 120
 - Firmware version (Parameter) 123
 - Fixed current (Parameter) 68
 - Fixed density (Parameter) 61
 - Flow damping (Parameter) 54
 - Flow override (Parameter) 53
 - Format display (Parameter) 15
 - Frequency output simulation (Parameter) 138
 - Frequency value (Parameter) 138
 - Full pipe adjust value (Parameter) 59
 - Function
 - see Parameter
- H**
 - Hardware revision (Parameter) 99
 - HART address (Parameter) 90
 - HART date code (Parameter) 100
 - HART descriptor (Parameter) 99
 - HART message (Parameter) 99
 - HART output (Submenu) 89
 - HART revision (Parameter) 99
 - HART short tag (Parameter) 90
 - Header (Parameter) 23
 - Header text (Parameter) 23
 - Heartbeat (Submenu) 135
- I**
 - Information (Submenu) 97
 - Installation direction (Parameter) 62
 - Integration time (Parameter) 62
 - Invert output signal (Parameter) 89
 - IO module temperature (Submenu) 134

L

Language (Parameter)	14
Last backup (Parameter)	26
Locking status (Parameter)	11
Logging interval (Parameter)	128
Low flow cut off (Submenu)	54

M

Main electronic temperature (Submenu)	133
Manufacturer ID (Parameter)	98
Mass flow (Parameter)	41
Mass flow factor (Parameter)	64
Mass flow offset (Parameter)	64
Mass flow unit (Parameter)	47
Mass unit (Parameter)	48
Max. update period (Parameter)	97
Maximum frequency value (Parameter)	82
Maximum value (Parameter)	133, 134, 135
Measured current 1 (Parameter)	43, 77
Measured value EPD (Parameter)	59
Measured values (Submenu)	40
Measuring mode (Parameter)	70, 80, 84
Measuring period (Parameter)	62
Measuring value at maximum frequency (Parameter)	83
Measuring value at minimum frequency (Parameter)	83
Min. update period (Parameter)	96
Min/max values (Submenu)	131
Minimum frequency value (Parameter)	82
Minimum value (Parameter)	132, 133, 134

N

New adjustment (Parameter)	60
No. of preambles (Parameter)	91
Nominal diameter (Parameter)	64

O

Off value low flow cutoff (Parameter)	55
On value low flow cutoff (Parameter)	55
Operating mode (Parameter)	79
Operating time (Parameter)	26, 116
Operating time from restart (Parameter)	116
Order code (Parameter)	124
Output (Submenu)	65, 100
Output current 1 (Parameter)	43, 76
Output frequency (Parameter)	45, 85
Output values (Submenu)	43

P

Parameter	
Structure of a parameter description	6
Preset value 1 to 3 (Parameter)	112
Pressure shock suppression (Parameter)	56
Previous diagnostics (Parameter)	115
Primary variable (PV) (Parameter)	101
Process parameters (Submenu)	53
Process variable adjustment (Submenu)	63
Process variable value (Parameter)	137
Process variables (Submenu)	40
Progress (Parameter)	60

Pulse output (Parameter)	44, 81
Pulse output simulation (Parameter)	139
Pulse value (Parameter)	139
Pulse width (Parameter)	80
Pulse/frequency/switch output (Submenu)	78

Q

Quaternary variable (QV) (Parameter)	103
------------------------------------------------	-----

R

Reference values (Submenu)	61
Reset all totalizers (Parameter)	109
Reset min/max values (Parameter)	132
Reset write protection (Parameter)	39
Response time empty pipe detection (Parameter)	58

S

Secondary variable (SV) (Parameter)	102
Sensor (Submenu)	40
Sensor adjustment (Submenu)	61
Separator (Parameter)	24
Serial number (Parameter)	123
Simulation (Submenu)	136
Simulation current output 1 (Parameter)	137
Simulation device alarm (Parameter)	141
Software option overview (Parameter)	38
Software revision (Parameter)	100
Start-up current (Parameter)	77
Start-up mode (Parameter)	76
Submenu	
Administration	35
Application	109
Burst configuration 1 to 3	91
Calculated values	61
Calibration	64
Communication	89
Configuration	90
Configuration backup display	26
Current output 1	66
Data logging	126
Device information	122
Diagnostic behavior	30
Diagnostic configuration	103
Diagnostic handling	29
Diagnostic list	116
Diagnostics	113
Display	13
Display channel 1	129
Display channel 2	130
Display channel 3	130
Display channel 4	131
Empty pipe detection	57
Event list	121
Event logbook	120
HART output	89
Heartbeat	135
Information	97
IO module temperature	134
Low flow cut off	54

- Main electronic temperature 133
 - Measured values 40
 - Min/max values 131
 - Output 65, 100
 - Output values 43
 - Process parameters 53
 - Process variable adjustment 63
 - Process variables 40
 - Pulse/frequency/switch output 78
 - Reference values 61
 - Sensor 40
 - Sensor adjustment 61
 - Simulation 136
 - System 13
 - System units 45
 - Terminal voltage 132
 - Totalizer 41
 - Totalizer 1 to 3 109
 - User-specific units 50
 - Switch output function (Parameter) 85
 - Switch output simulation (Parameter) 140
 - Switch point empty pipe detection (Parameter) 58
 - Switch status (Parameter) 45, 88, 140
 - Switch-off delay (Parameter) 88
 - Switch-off value (Parameter) 87
 - Switch-on delay (Parameter) 88
 - Switch-on value (Parameter) 86
 - System (Submenu) 13
 - System units (Submenu) 45
- T**
- Target group 4
 - Temperature unit (Parameter) 49
 - Terminal voltage (Submenu) 132
 - Terminal voltage 1 (Parameter) 44, 77
 - Tertiary variable (TV) (Parameter) 102
 - Timestamp (Parameter) 115, 117, 118, 119, 120
 - Totalizer (Submenu) 41
 - Totalizer 1 to 3 (Submenu) 109
 - Totalizer operation mode (Parameter) 111
 - Totalizer overflow 1 to 3 (Parameter) 42
 - Totalizer value 1 to 3 (Parameter) 41
- U**
- Unit totalizer (Parameter) 110
 - User mass factor (Parameter) 53
 - User mass offset (Parameter) 52
 - User mass text (Parameter) 52
 - User volume factor (Parameter) 52
 - User volume offset (Parameter) 51
 - User volume text (Parameter) 51
 - User-specific units (Submenu) 50
- V**
- Value 1 display (Parameter) 16
 - Value 2 display (Parameter) 18
 - Value 3 display (Parameter) 19
 - Value 4 display (Parameter) 21
 - Value current output 1 (Parameter) 138
 - Value per pulse (Parameter) 80
 - Volume flow (Parameter) 40
 - Volume flow factor (Parameter) 63
 - Volume flow offset (Parameter) 63
 - Volume flow unit (Parameter) 46
 - Volume unit (Parameter) 47
- W**
- Wizard
 - Define access code 35
 - Empty pipe adjust 60
- Z**
- Zero point (Parameter) 65

www.addresses.endress.com
